



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services




Solutions

Operating Instructions

Proline Promag 50

Electromagnetic Flow Measuring System



Brief operating instructions

These brief operating instructions show you how to configure the measuring device quickly and easily:


Safety instructions	Page 7
▼	
Installation	Page 13
▼	
Wiring	Page 47
▼	
Display and operating elements	Page 61
▼	
Commissioning with "QUICK SETUP"	Page 80 ff.
<p>You can commission the measuring device quickly and easily, using the special "Quick Setup" menu. It enables to configure important basic functions using the local display, for example display language, measured variables, units engineering, type of signal, etc.</p> <p>The following adjustments can be made separately as necessary:</p> <ul style="list-style-type: none"> – Empty-pipe/full-pipe adjustment for empty pipe detection (EPD) – Configuration of current output (active/passive) 	
▼	
Customer-specific configuration	Page 62
<p>Complex measuring operations necessitate additional functions that you can configure as necessary with the aid of the function matrix, and customize to suit the process parameters. All functions are described in detail, as is the function matrix itself, in the "Description of Device Functions" manual, which is a separate part of this Operating Instruction.</p>	



Note!

Always start trouble-shooting with the checklist on Page 89, if faults occur after commissioning or during operation. The routine takes you directly to the cause of the problem and the appropriate remedial measures.

"QUICK SETUP" commissioning



F06-50xxxxxx-19-xx-xx-en-000

Contents

1	Safety instructions	7	5	Operation	61
1.1	Designated use	7	5.1	Display and operating elements	61
1.2	Installation, commissioning and operation	7	5.2	Brief operating instruction to the function matrix	62
1.3	Operational safety	7	5.2.1	General notes	63
1.4	Return	8	5.2.2	Enabling the programming mode	63
1.5	Notes on safety conventions and icons	8	5.2.3	Disabling the programming mode	63
2	Identification	9	5.3	Error messages	64
2.1	Device designation	9	5.4	Communication	65
2.1.1	Nameplate of the transmitter	9	5.4.1	Operating options	66
2.1.2	Nameplate of the sensor	10	5.4.2	Current device description files	67
2.1.3	Nameplate, connections	11	5.4.3	Device and process variables	68
2.2	CE mark, declaration of conformity	11	5.4.4	Universal / Common practice HART commands	69
2.3	Registered trademarks	12	5.4.5	Device status / Error messages	74
3	Installation	13	6	Commissioning	79
3.1	Incoming acceptance, transport and storage	13	6.1	Function check	79
3.1.1	Incoming acceptance	13	6.1.1	Switching on the measuring device	79
3.1.2	Transport	13	6.2	Application-specific commissioning	80
3.1.3	Storage	14	6.2.1	"Commissioning" Quick Setup menu	80
3.2	Installation conditions	15	6.2.2	Empty-pipe/full-pipe adjustment	81
3.2.1	Dimensions	15	6.2.3	Current output: active/passive	82
3.2.2	Mounting location	15	6.3	Data storage device (HistoROM)	82
3.2.3	Orientation	17	6.3.1	HistoROM/S-DAT (sensor-DAT)	82
3.2.4	Vibrations	18	7	Maintenance	83
3.2.5	Foundations, supports	19	7.1	Exterior cleaning	83
3.2.6	Adapters	20	7.2	Seals	83
3.2.7	Nominal diameter and flow rate	20	8	Accessories	85
3.2.8	Length of connecting cable	25	8.1	Device-specific accessories	85
3.3	Installation instructions	26	8.2	Measuring principle-specific accessories	86
3.3.1	Installing the Promag W sensor	26	8.3	Communication-specific accessories	87
3.3.2	Installing the Promag P sensor	33	8.4	Communication-specific accessories	87
3.3.3	Installing the Promag H sensor	39	9	Trouble-shooting	89
3.3.4	Turning the transmitter housing	42	9.1	Trouble-shooting instructions	89
3.3.5	Turning the local display	43	9.2	System error messages	90
3.3.6	Installing the wall-mount transmitter housing	44	9.3	Process error messages	93
3.4	Installation check	46	9.4	Process errors without messages	94
4	Wiring	47	9.5	Response of outputs to errors	95
4.1	Connecting the remote version	47	9.6	Spare parts	97
4.1.1	Connecting Promag W / P / H	47	9.7	Removing and installing printed circuit boards	98
4.1.2	Cable specifications	51	9.8	Replacing the device fuse	102
4.2	Connecting the measuring unit	52	9.9	Replacing exchangeable measuring electrodes	103
4.2.1	Transmitter	52	9.10	Software history	105
4.2.2	Terminal assignment	54	10	Technical data	107
4.2.3	HART connection	55	10.1	Technical data at a glance	107
4.3	Potential equalisation	56	10.1.1	Application	107
4.3.1	Standard case	56	10.1.2	Function and system design	107
4.3.2	Special cases	57			
4.4	Degree of protection	59			
4.5	Electrical connection check	60			

10.1.3	Input	107
10.1.4	Output	108
10.1.5	Power supply	108
10.1.6	Performance characteristics	109
10.1.7	Operating conditions	110
10.1.8	Mechanical construction	114
10.1.9	Human interface	118
10.1.10	Certificates and approvals	118
10.1.11	Ordering information	119
10.1.12	Accessories	119
10.1.13	Supplementary documentation	119
11	Index	121

1 Safety instructions

1.1 Designated use

The measuring device described in this Operating Manual is to be used only for measuring the flow rate of conductive fluids in closed pipes. A minimum conductivity of 20 $\mu\text{S}/\text{cm}$ is required for measuring demineralized water. Most fluids can be metered, provided they have a minimum conductivity of 5 $\mu\text{S}/\text{cm}$, for example:

- acids, alkalis,
- drinking water, wastewater, sewage sludge,
- milk, beer, wine, mineral water, etc.

Resulting from incorrect use or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.




1.2 Installation, commissioning and operation

Note the following points:

- Installation, connection to the electricity supply, commissioning and maintenance of the device must be carried out by trained, qualified specialists authorized to perform such work by the facility's owner-operator. The specialist must have read and understood this Operating Manual and must follow the instructions it contains.
- The device must be operated by persons authorized and trained by the facility's owner-operator. Strict compliance with the instructions in the Operating Manual is mandatory.
- Endress+Hauser will be happy to assist in clarifying the chemical resistance properties of parts wetted by special fluids, including fluids used for cleaning.
- If welding work is performed on the piping system, do not ground the welding appliance through the Promag flowmeter.
- The installer must ensure that the measuring system is correctly wired in accordance with the wiring diagrams. The transmitter must be grounded, unless the power supply is galvanically insulated.
- Invariably, local regulations governing the opening and repair of electrical devices apply.

1.3 Operational safety

Note the following points:

- Measuring systems for use in hazardous environments are accompanied by separate Ex documentation, which is an *integral part* of this Operating Manual. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory. The symbol on the front of this supplementary Ex documentation indicates the approval and the certification body ( Europe,  USA,  Canada).
- The measuring device complies with the general safety requirements in accordance with EN 61010, the EMC requirements of EN 61326/A1, and NAMUR recommendation NE 21.
- Depending on the application, the seals of the process connections of the Promag H sensor require periodic replacement.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and updates to this Operating Manual.

1.4 Return

The following procedures must be carried out before a flowmeter requiring repair or calibration, for example, is returned to Endress+Hauser:

- Always enclose a duly completed “Declaration of contamination” form. Only then can Endress+Hauser transport, examine and repair a returned device.
- Enclose special handling instructions if necessary, for example a safety data sheet as per EN 91/155/EEC.
- Remove all residues. Pay special attention to the grooves for seals and crevices which could contain residues. This is particularly important if the substance is hazardous to health, e.g. flammable, toxic, caustic, carcinogenic, etc.



Note!

You will find a *preprinted* “Declaration of contamination” form at the back of this manual.



Warning!

- Do not return a measuring device if you are not absolutely certain that all traces of hazardous substances have been removed, e.g. substances which have penetrated crevices or diffused through plastic.
- Costs incurred for waste disposal and injury (burns, etc.) due to inadequate cleaning will be charged to the owner-operator.

1.5 Notes on safety conventions and icons

The devices are designed to meet state-of-the-art safety requirements, have been tested, and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010 “Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures”. They can, however, be a source of danger if used incorrectly or for other than the designated use.

Consequently, always pay particular attention to the safety instructions indicated in this Operating Manual by the following icons:



Warning!

“Warning” indicates an action or procedure which, if not performed correctly, can result in injury or a safety hazard. Comply strictly with the instructions and proceed with care.



Caution!

“Caution” indicates an action or procedure which, if not performed correctly, can result in incorrect operation or destruction of the device. Comply strictly with the instructions.



Note!

“Note” indicates an action or procedure which, if not performed correctly, can have an indirect effect on operation or trigger an unexpected response on the part of the device.

2 Identification

2.1 Device designation

The "Promag 50" flow measuring system consists of the following components:

- Promag 50 transmitter
- Promag W, Promag P or Promag H sensor

In the *compact version*, transmitter and sensor form a single mechanical unit; in the *remote version* they are installed separately.

2.1.1 Nameplate of the transmitter




Fig. 1: Nameplate specifications for the "Promag 50" transmitter (example)

- 1 Ordering code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits.
- 2 Power supply / frequency: 16...62 V DC / 20...55 V AC / 50...60 Hz
Power consumption: 15 VA / W
- 3 Additional functions and software:
 - EPD/MSU: with Empty Pipe Detection
 - ECC: with Electrode Cleaning Circuitry
- 4 Outputs / inputs:
 - I-OUT (HART): with current output (HART)
 - f-OUT: with pulse/frequency output
 - STATUS-IN: with status input (auxiliary input)
 - STATUS-OUT: with status output (switch output)
- 5 Reserved for information on special products
- 6 Ambient temperature range
- 7 Degree of protection

2.1.2 Nameplate of the sensor




Fig. 2: Nameplate specifications for the "Promag" sensor (example)

- 1 Ordering code/serial number: See the specifications on the order confirmation for the meanings of the individual letters and digits.
- 2 Calibration factor: 0.5328; zero point: -5
- 3 Nominal diameter: DN 100
Pressure rating: EN (DIN) PN 16 bar
- 4 TMmax +150 °C (max. fluid temperature)
- 5 Materials:
- Lining: PFA
- Measuring electrodes: stainless steel 1.4435
- 6 Additional information (examples):
- EPD/MSU: with Empty Pipe Detection electrode
- R/B: with reference electrode
- 7 Reserved for information on special products
- 8 Ambient temperature range
- 9 Degree of protection
- 10 Reserved for additional information on device version (approvals, certificates)
- 11 Flow direction

2.1.3 Nameplate, connections

See operating manual
Betriebsanleitung beachten
Observer manuel d'instruction

A: active
P: passive
NO: normally open contact
NC: normally closed contact

1 Ser.No.: 12345678912

4 Supply / Versorgung / Tension d'alimentation

L1/L+
N/L-
PE

I-OUT (HART) Active: 0/4...20mA, RL max. = 700 Ohm
Passive: 4...20mA, max. 30VDC, Ri < 150 Ohm
(HART: RL.min. = 250 OHM)

f-OUT fmax = 1kHz
Passive: 30VDC, 250mA

5 STATUS-OUT Passive: 30VDC, 250mA

STATUS-IN 3...30VDC, Ri = 5kOhm

20(+)/21(-)
22(+)/23(-)
24(+)/25(-)
26(+)/27(-)

6 ex-works Version info
Device SW: XX.XX.XX
7 Communication: XXXXXXXXXX
8 Revision: XX.XX.XX
9 Date: DD.MMM.YYYY

Update 1 Update 2

319475-00XX

10

Fig. 3: Nameplate specifications for Proline transmitter (example)

- 1 Serial number
- 2 Possible configuration of current output
- 3 Possible configuration of relay contacts
- 4 Terminal assignment, cable for power supply: 85...260 V AC, 20...55 V AC, 16...62 V DC
Terminal No. 1: L1 for AC, L+ for DC
Terminal No. 2: N for AC, L- for DC
- 5 Signals present at inputs and outputs, possible configuration and terminal assignment (20...27),
see also "Electrical values of inputs/outputs"
- 6 Version of device software currently installed
- 7 Installed communication type, e.g.: HART, PROFIBUS PA, etc.
- 8 Information on current communication software (Device Revision and Device Description), e.g.:
Dev. 01 / DD 01 for HART
- 9 Date of installation
- 10 Current updates to data specified in points 6 to 9

2.2 CE mark, declaration of conformity

The devices are designed to meet state-of-the-art safety requirements in accordance with sound engineering practice. They have been tested and left the factory in a condition in which they are safe to operate. The devices comply with the applicable standards and regulations in accordance with EN 61010 "Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures" and with the EMC requirements of EN 61326/A1. The measuring system described in this Operating Manual is therefore in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

2.3 Registered trademarks

KALREZ[®], VITON[®]

are registered trademarks of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP[®]

is a registered trademark of Ladish & Co., Inc., Kenosha, USA

HART[®]

is a registered trademark of HART Communication Foundation, Austin, USA

HistoROM[™], S-DAT[®], ToF Tool – Fieldtool[®] Package, Fieldcheck[®], Applicator[®]
are registered trademarks of Endress+Hauser Flowtec AG, Reinach, CH

3 Installation

3.1 Incoming acceptance, transport and storage

3.1.1 Incoming acceptance

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport

The following instructions apply to unpacking and to transporting the device to its final location:

- Transport the devices in the containers in which they are delivered.
- Do not remove the protective plates or caps on the process connections until the device is ready to install. This is particularly important in the case of sensors with PTFE linings.

Special notes on flanged devices



Caution!

- The wooden covers mounted on the flanges before the device leaves the factory protect the linings on the flanges during storage and transportation. Do not remove these covers until *immediately before* the device is installed in the pipe.
- Do not lift flanged devices by the transmitter housing, or the connection housing in the case of the remote version.

Transporting flanged devices ($DN \leq 300$):

Use webbing slings slung round the two process connections (Fig. 4). Do not use chains, as they could damage the housing.



Warning!

Risk of injury if the measuring device slips. The center of gravity of the assembled measuring device might be higher than the points around which the slings are slung.

At all times, therefore, make sure that the device does not unexpectedly turn around its axis or slip.




Fig. 4: Transporting transmitters with $DN \leq 300$


F06-xxxxxxx-22-00-00-xx-000

Transporting flanged devices ($DN \geq 350$):

Use only the metal eyes on the flanges for transporting the device, lifting it and positioning the sensor in the piping.

**Caution!**

Do not attempt to lift the sensor with the tines of a fork-lift truck beneath the metal casing. This would buckle the casing and damage the internal magnetic coils.



F06-5xFxxxxx-22-xx-xx-xx-001

Fig. 5: Transporting sensors with $DN \geq 350$

3.1.3 Storage

Note the following points:

- Pack the measuring device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.
- The measuring device must be protected against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Choose a storage location where moisture does not collect in the measuring device. This will help prevent fungus and bacteria infestation which can damage the liner.
- Do not remove the protective plates or caps on the process connections until you are ready to install the device. This is particularly important in the case of sensors with PTFE linings.

3.2 Installation conditions


3.2.1 Dimensions

All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation "Technical Information".

3.2.2 Mounting location

Correct measuring is possible only if the pipe is full. **Avoid** the following locations:

- Highest point of a pipeline. Risk of air accumulating
- Directly upstream a free pipe outlet in a vertical pipeline.




F06-5xxxxxxx-11-00-00-xx-000

Fig. 6: Location

Installation of pumps

Do not install the sensor on the intake side of a pump. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. Information on the lining's resistance to partial vacuum can be found on → Page 113.

It might be necessary to install pulse dampers in systems incorporating reciprocating, diaphragm or peristaltic pumps. Information on the measuring system's resistance to vibration and shock can be found on → Page 110.



F06-5xxxxxxx-11-00-00-xx-001


Fig. 7: Installation of pumps

Partially filled pipes

Partially filled pipes with gradients necessitate a drain-type configuration. The Empty Pipe Detection function (see Page 81) offers additional protection by detecting empty or partially filled pipes.

**Caution!**

Risk of solids accumulating. Do not install the sensor at the lowest point in the drain. It is advisable to install a cleaning valve.




F06-5xxxxxxx-11-00-00-xx-002

Fig. 8: Installation in partially filled pipe

Down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes longer than 5 meters. This precaution is to avoid low pressure and the consequent risk of damage to the lining of the measuring tube. These measures also prevent the system losing prime, which could cause air inclusions. Information on the lining's resistance to partial vacuum can be found on Page 113.



F06-5xxxxxxx-11-00-00-xx-003

Fig. 9: Measures for installation in a down pipe (a = vent valve; b = siphon)


3.2.3 Orientation

An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube. Promag, nevertheless, supplies a range of functions and accessories for correct measuring of problematic fluids:

- Electrode Cleaning Circuit (ECC) for applications with accretive fluids, e.g. electrically conductive deposits → “Description of Device Functions” manual.
- Empty Pipe Detection (EPD) ensures the detection of partially filled measuring tubes, e.g. in the case of degassing fluids or varying process pressure (see Page 81)
- Exchangeable Measuring Electrodes for abrasive fluids (see Page 103)

Vertical orientation

This is the ideal orientation for self-emptying piping systems and for use in conjunction with Empty Pipe Detection.



F06-5xxxxxxx-11-00-00-xx-004

Fig. 10: Vertical orientation


Horizontal orientation

The measuring electrode plane should be horizontal. This prevents brief insulation of the two electrodes by entrained air bubbles.



Caution!

Empty Pipe Detection functions correctly only when the measuring device is installed horizontally and the transmitter housing is facing upward (Fig. 11). Otherwise there is no guarantee that Empty Pipe Detection will respond if the measuring tube is only partially filled or empty.



F06-5xxxxxxx-11-00-xx-xx-000


Fig. 11: Horizontal orientation

- 1 EPD electrode for the detection of empty pipes (not with Promag H, DN 2...4)
- 2 Measurement electrodes for the signal acquisition
- 3 Reference electrode for the potential equalisation (not with Promag H)

Inlet and outlet runs

If possible, install the sensor well clear of fittings such as valves, T-pieces, elbows, etc. Compliance with the following requirements for the inlet and outlet runs is necessary in order to ensure measuring accuracy.

- Inlet run $\geq 5 \times \text{DN}$
- Outlet run $\geq 2 \times \text{DN}$



F06-5xxxxxxx-11-00-00-xx-005


Fig. 12: Inlet and outlet runs

3.2.4 Vibrations

Secure the piping and the sensor if vibration is severe.

**Caution!**

It is advisable to install sensor and transmitter separately if vibration is excessively severe. Information on resistance to vibration and shock can be found on → Page 110.



F06-5xxxxxxx-11-00-00-xx-006

Fig. 13: Measures to prevent vibration of the measuring device


3.2.5 Foundations, supports

If the nominal diameter is $DN \geq 350$, mount the transmitter on a foundation of adequate load-bearing strength.



Caution!

Risk of damage. Do not support the weight of the sensor on the metal casing: the casing would buckle and damage the internal magnetic coils.



F06-5xFxxxxx-11-05-xx-xx-000

Fig. 14: Correct support for large nominal diameters ($DN \geq 350$)

3.2.6 Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids.

The nomogram shown here can be used to calculate the pressure loss caused by cross-section reduction:



Note!

The nomogram applies to fluids of viscosity similar to water.

1. Calculate the ratio of the diameters d/D .
2. From the nomogram read off the pressure loss as a function of flow velocity (*downstream* from the reduction) and the d/D ratio.




Fig. 15: Pressure loss due to adapters

F06-5xxxxxx-05-05-xx-xx-000

3.2.7 Nominal diameter and flow rate

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is 2...3 m/s. The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- $v < 2$ m/s: for abrasive fluids such as potter's clay, lime milk, ore slurry, etc.
- $v > 2$ m/s: for fluids producing build-up such as wastewater sludge, etc.



Note!

Flow velocity can be increased, if necessary, by reducing the nominal diameter of the sensor (see Chap. 3.2.6).

Promag W

Flow rate characteristic values – Promag W (SI units)						
Nominal diameter		Recommended flow rate	Factory setting			
[mm]	[inch]	min./max. full scale value (v ~ 0.3 or 10 m/s)	Full scale value (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cutoff (v ~ 0.04 m/s)	
25	1"	9...300 dm ³ /min	75 dm ³ /min	0.50 dm ³	1 dm ³ /min	
32	1 1/4"	15...500 dm ³ /min	125 dm ³ /min	1.00 dm ³	2 dm ³ /min	
40	1 1/2"	25...700 dm ³ /min	200 dm ³ /min	1.50 dm ³	3 dm ³ /min	
50	2"	35...1100 dm ³ /min	300 dm ³ /min	2.50 dm ³	5 dm ³ /min	
65	2 1/2"	60...2000 dm ³ /min	500 dm ³ /min	5.00 dm ³	8 dm ³ /min	
80	3"	90...3000 dm ³ /min	750 dm ³ /min	5.00 dm ³	12 dm ³ /min	
100	4"	145...4700 dm ³ /min	1200 dm ³ /min	10.00 dm ³	20 dm ³ /min	
125	5"	220...7500 dm ³ /min	1850 dm ³ /min	15.00 dm ³	30 dm ³ /min	
150	6"	20...600 m ³ /h	150 m ³ /h	0.025 m ³	2.5 m ³ /h	
200	8"	35...1100 m ³ /h	300 m ³ /h	0.05 m ³	5.0 m ³ /h	
250	10"	55...1700 m ³ /h	500 m ³ /h	0.05 m ³	7.5 m ³ /h	
300	12"	80...2400 m ³ /h	750 m ³ /h	0.10 m ³	10 m ³ /h	
350	14"	110...3300 m ³ /h	1000 m ³ /h	0.10 m ³	15 m ³ /h	
400	16"	140...4200 m ³ /h	1200 m ³ /h	0.15 m ³	20 m ³ /h	
450	18"	180...5400 m ³ /h	1500 m ³ /h	0.25 m ³	25 m ³ /h	
500	20"	220...6600 m ³ /h	2000 m ³ /h	0.25 m ³	30 m ³ /h	
600	24"	310...9600 m ³ /h	2500 m ³ /h	0.30 m ³	40 m ³ /h	
700	28"	420...13500 m ³ /h	3500 m ³ /h	0.50 m ³	50 m ³ /h	
—	30"	480...15000 m ³ /h	4000 m ³ /h	0.50 m ³	60 m ³ /h	
800	32"	550...18000 m ³ /h	4500 m ³ /h	0.75 m ³	75 m ³ /h	
900	36"	690...22500 m ³ /h	6000 m ³ /h	0.75 m ³	100 m ³ /h	
1000	40"	850...28000 m ³ /h	7000 m ³ /h	1.00 m ³	125 m ³ /h	
—	42"	950...30000 m ³ /h	8000 m ³ /h	1.00 m ³	125 m ³ /h	
1200	48"	1250...40000 m ³ /h	10000 m ³ /h	1.50 m ³	150 m ³ /h	
—	54"	1550...50000 m ³ /h	13000 m ³ /h	1.50 m ³	200 m ³ /h	
1400	—	1700...55000 m ³ /h	14000 m ³ /h	2.00 m ³	225 m ³ /h	
—	60"	1950...60000 m ³ /h	16000 m ³ /h	2.00 m ³	250 m ³ /h	
1600	—	2200...70000 m ³ /h	18000 m ³ /h	2.50 m ³	300 m ³ /h	
—	66"	2500...80000 m ³ /h	20500 m ³ /h	2.50 m ³	325 m ³ /h	
1800	72"	2800...90000 m ³ /h	23000 m ³ /h	3.00 m ³	350 m ³ /h	
—	78"	3300...100000 m ³ /h	28500 m ³ /h	3.50 m ³	450 m ³ /h	
2000	—	3400...110000 m ³ /h	28500 m ³ /h	3.50 m ³	450 m ³ /h	

Flow rate characteristic values – Promag W (US units)					
Nominal diameter		Recommended flow rate	Factory setting		
[inch]	[mm]	min./max. full scale value (v ~ 0.3 or 10 m/s)	Full scale value (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cutoff (v ~ 0.04 m/s)
1"	25	2.5...80 gal/min	18 gal/min	0.20 gal	0.25 gal/min
1 1/4"	32	4...130 gal/min	30 gal/min	0.20 gal	0.50 gal/min
1 1/2"	40	7...190 gal/min	50 gal/min	0.50 gal	0.75 gal/min
2"	50	10...300 gal/min	75 gal/min	0.50 gal	1.25 gal/min
2 1/2"	65	16...500 gal/min	130 gal/min	1 gal	2.0 gal/min
3"	80	24...800 gal/min	200 gal/min	2 gal	2.5 gal/min
4"	100	40...1250 gal/min	300 gal/min	2 gal	4.0 gal/min
5"	125	60...1950 gal/min	450 gal/min	5 gal	7.0 gal/min
6"	150	90...2650 gal/min	600 gal/min	5 gal	12 gal/min
8"	200	155...4850 gal/min	1200 gal/min	10 gal	15 gal/min
10"	250	250...7500 gal/min	1500 gal/min	15 gal	30 gal/min
12"	300	350...10600 gal/min	2400 gal/min	25 gal	45 gal/min
14"	350	500...15000 gal/min	3600 gal/min	30 gal	60 gal/min
16"	400	600...19000 gal/min	4800 gal/min	50 gal	60 gal/min
18"	450	800...24000 gal/min	6000 gal/min	50 gal	90 gal/min
20"	500	1000...30000 gal/min	7500 gal/min	75 gal	120 gal/min
24"	600	1400...44000 gal/min	10500 gal/min	100 gal	180 gal/min
28"	700	1900...60000 gal/min	13500 gal/min	125 gal	210 gal/min
30"	–	2150...67000 gal/min	16500 gal/min	150 gal	270 gal/min
32"	800	2450...80000 gal/min	19500 gal/min	200 gal	300 gal/min
36"	900	3100...100000 gal/min	24000 gal/min	225 gal	360 gal/min
40"	1000	3800...125000 gal/min	30000 gal/min	250 gal	480 gal/min
42"	–	4200...135000 gal/min	33000 gal/min	250 gal	600 gal/min
48"	1200	5500...175000 gal/min	42000 gal/min	400 gal	600 gal/min
54"	–	9...300 Mgal/d	75 Mgal/d	0.0005 Mgal	1.3 Mgal/d
–	1400	10...340 Mgal/d	85 Mgal/d	0.0005 Mgal	1.3 Mgal/d
60"	–	12...380 Mgal/d	95 Mgal/d	0.0005 Mgal	1.3 Mgal/d
–	1600	13...450 Mgal/d	110 Mgal/d	0.0008 Mgal	1.7 Mgal/d
66"	–	14...500 Mgal/d	120 Mgal/d	0.0008 Mgal	2.2 Mgal/d
72"	1800	16...570 Mgal/d	140 Mgal/d	0.0008 Mgal	2.6 Mgal/d
78"	–	18...650 Mgal/d	175 Mgal/d	0.001 Mgal	3.0 Mgal/d
–	2000	20...700 Mgal/d	175 Mgal/d	0.001 Mgal	3.0 Mgal/d

Promag P

Flow rate characteristic values – Promag P (SI units)

Nominal diameter		Recommended flow rate	Factory setting		
[mm]	[inch]	min./max. full scale value (v ~ 0.3 or 10 m/s)	Full scale value (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cutoff (v ~ 0.04 m/s)
15	1/2"	4...100 dm ³ /min	25 dm ³ /min	0.20 dm ³	0.5 dm ³ /min
25	1"	9...300 dm ³ /min	75 dm ³ /min	0.50 dm ³	1 dm ³ /min
32	1 1/4"	15...500 dm ³ /min	125 dm ³ /min	1.00 dm ³	2 dm ³ /min
40	1 1/2"	25...700 dm ³ /min	200 dm ³ /min	1.50 dm ³	3 dm ³ /min
50	2"	35...1100 dm ³ /min	300 dm ³ /min	2.50 dm ³	5 dm ³ /min
65	2 1/2"	60...2000 dm ³ /min	500 dm ³ /min	5.00 dm ³	8 dm ³ /min
80	3"	90...3000 dm ³ /min	750 dm ³ /min	5.00 dm ³	12 dm ³ /min
100	4"	145...4700 dm ³ /min	1200 dm ³ /min	10.00 dm ³	20 dm ³ /min
125	5"	220...7500 dm ³ /min	1850 dm ³ /min	15.00 dm ³	30 dm ³ /min
150	6"	20...600 m ³ /h	150 m ³ /h	0.025 m ³	2.5 m ³ /h
200	8"	35...1100 m ³ /h	300 m ³ /h	0.05 m ³	5.0 m ³ /h
250	10"	55...1700 m ³ /h	500 m ³ /h	0.05 m ³	7.5 m ³ /h
300	12"	80...2400 m ³ /h	750 m ³ /h	0.10 m ³	10 m ³ /h
350	14"	110...3300 m ³ /h	1000 m ³ /h	0.10 m ³	15 m ³ /h
400	16"	140...4200 m ³ /h	1200 m ³ /h	0.15 m ³	20 m ³ /h
450	18"	180...5400 m ³ /h	1500 m ³ /h	0.25 m ³	25 m ³ /h
500	20"	220...6600 m ³ /h	2000 m ³ /h	0.25 m ³	30 m ³ /h
600	24"	310...9600 m ³ /h	2500 m ³ /h	0.30 m ³	40 m ³ /h

Flow rate characteristic values – Promag P (US units)

Nominal diameter		Recommended flow rate min./max. full scale value (v ~ 0.3 or ~ 10 m/s)	Factory setting		
[inch]	[mm]		Full scale value (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cutoff (v ~ 0.04 m/s)
1/2"	15	1.0...27 gal/min	6 gal/min	0.05 gal	0.10 gal/min
1"	25	2.5...80 gal/min	18 gal/min	0.20 gal	0.25 gal/min
1 1/4"	32	4...130 gal/min	30 gal/min	0.20 gal	0.50 gal/min
1 1/2"	40	7...190 gal/min	50 gal/min	0.50 gal	0.75 gal/min
2"	50	10...300 gal/min	75 gal/min	0.50 gal	1.25 gal/min
2 1/2"	65	16...500 gal/min	130 gal/min	1 gal	2.0 gal/min
3"	80	24...800 gal/min	200 gal/min	2 gal	2.5 gal/min
4"	100	40...1250 gal/min	300 gal/min	2 gal	4.0 gal/min
5"	125	60...1950 gal/min	450 gal/min	5 gal	7.0 gal/min
6"	150	90...2650 gal/min	600 gal/min	5 gal	12 gal/min
8"	200	155...4850 gal/min	1200 gal/min	10 gal	15 gal/min
10"	250	250...7500 gal/min	1500 gal/min	15 gal	30 gal/min
12"	300	350...10600 gal/min	2400 gal/min	25 gal	45 gal/min
14"	350	500...15000 gal/min	3600 gal/min	30 gal	60 gal/min
16"	400	600...19000 gal/min	4800 gal/min	50 gal	60 gal/min
18"	450	800...24000 gal/min	6000 gal/min	50 gal	90 gal/min
20"	500	1000...30000 gal/min	7500 gal/min	75 gal	120 gal/min
24"	600	1400...44000 gal/min	10500 gal/min	100 gal	180 gal/min

Promag H

Flow rate characteristic values – Promag H (SI units)

Nominal diameter		Recommended flow rate min./max. full scale value (v ~ 0.3 or 10 m/s)	Factory settings		
[mm]	[inch]		Full scale value (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cutoff (v ~ 0.04 m/s)
2	1/12"	0.06...1.8 dm ³ /min	0.5 dm ³ /min	0.005 dm ³	0.01 dm ³ /min
4	5/32"	0.25...7 dm ³ /min	2 dm ³ /min	0.025 dm ³	0.05 dm ³ /min
8	5/16"	1...30 dm ³ /min	8 dm ³ /min	0.10 dm ³	0.1 dm ³ /min
15	1/2"	4...100 dm ³ /min	25 dm ³ /min	0.20 dm ³	0.5 dm ³ /min
25	1"	9...300 dm ³ /min	75 dm ³ /min	0.50 dm ³	1 dm ³ /min
40	1 1/2"	25...700 dm ³ /min	200 dm ³ /min	1.50 dm ³	3 dm ³ /min
50	2"	35...1100 dm ³ /min	300 dm ³ /min	2.50 dm ³	5 dm ³ /min
65	2 1/2"	60...2000 dm ³ /min	500 dm ³ /min	5.00 dm ³	8 dm ³ /min
80	3"	90...3000 dm ³ /min	750 dm ³ /min	5.00 dm ³	12 dm ³ /min
100	4"	145...4700 dm ³ /min	1200 dm ³ /min	10.00 dm ³	20 dm ³ /min

Flow rate characteristic values – Promag H (US units)

Nominal diameter		Recommended flow rate min./max. full scale value (v ~ 0.3 or 10 m/s)	Factory settings		
[inch]	[mm]		Full scale value (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s)	Low flow cutoff (v ~ 0.04 m/s)
1/12"	2	0.015...0.5 gal/min	0.1 gal/min	0.001 gal	0.002 gal/min
5/32"	4	0.07...2 gal/min	0.5 gal/min	0.005 gal	0.008 gal/min
5/16"	8	0.25...8 gal/min	2 gal/min	0.02 gal	0.025 gal/min
1/2"	15	1.0...27 gal/min	6 gal/min	0.05 gal	0.10 gal/min
1"	22	2.5...65 gal/min	18 gal/min	0.20 gal	0.25 gal/min
1 1/2"	40	7...190 gal/min	50 gal/min	0.50 gal	0.75 gal/min
2"	50	10...300 gal/min	75 gal/min	0.50 gal	1.25 gal/min
2 1/2"	65	16...500 gal/min	130 gal/min	1 gal	2.0 gal/min
3"	80	24...800 gal/min	200 gal/min	2 gal	2.5 gal/min
4"	100	40...1250 gal/min	300 gal/min	2 gal	4.0 gal/min

3.2.8 Length of connecting cable

In order to ensure measuring accuracy, comply with the following instructions when installing the remote version:

- Secure the cable run or route the cable in a conduit. Movement of the cable can falsify the measuring signal, particularly if the fluid conductivity is low.
- Route the cable well clear of electrical machines and switching elements.
- Ensure potential equalisation between sensor and transmitter, if necessary.
- The permissible cable length L_{max} depends on the fluid conductivity (Fig. 16).
A minimum conductivity of 20 $\mu\text{S}/\text{cm}$ is required for measuring demineralized water.




Fig. 16: Permissible cable length for the remote version

Gray shaded area = permissible range

L_{max} = length of connecting cable in [m]

Fluid conductivity in [$\mu\text{S}/\text{cm}$]

F06-xxxxxxx-05-xx-xx-xx-006

3.3 Installation instructions

3.3.1 Installing the Promag W sensor



Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges:

- Observe in any case the necessary screw tightening torques on Page 28 ff.
- The mounting of additional ground disks is described on Page 27.




Fig. 17: Installing the Promag W sensor

F06-5xFxxxxx-17-05-xx-xx-000

Seals

Comply with the following instructions when installing seals:

- Hard rubber lining → additional seals are **always** necessary.
- Polyurethane lining → additional seals are recommended.
- For DIN flanges, use only seals according to DIN EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit. Do not use electrically conductive sealing compound such as graphite. An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable (DN 25...2000)


If necessary, the special ground cable for potential equalisation can be ordered as an accessory (see Page 85). Detailed assembly instructions → Page 57 ff.

Assembly with ground disks (DN 25...300)

Depending on the application, e.g. with lined or ungrounded pipes (see Page 56 ff.), it may be necessary to mount ground disks between the sensor and the pipe flange for potential equalisation. Ground disks can be ordered separately as an accessory from Endress+Hauser (see Page 85).

**Caution!**

- In this case, when using ground disks (including seals) the total fitting length increases! All the dimensions are provided in the separate documentation "Technical Information"
 - Hard rubber lining → install additional seals between the sensor and ground disk and between the ground disk and pipe flange.
 - Polyurethane lining → only install additional seals between the ground disk and pipe flange.
1. Place the ground disk and additional seal(s) between the instrument and the pipe flange (Fig. 18).
 2. Insert the bolts through the flange holes. Tighten the nuts so that they are still loose.
 3. Now rotate the ground disk as shown in Fig. 18 until the handle strikes the bolts. This will center the ground disk automatically.
 4. Now tighten the bolts to the required torque (see Page 28 ff.)
 5. Connect the ground disk to ground → Page 58.



F06-5xPxxxxx-17-05-xx-xx-001

Fig. 18: Assembly with ground disks (Promag W, DN 25...300)

Screw tightening torques (Promag W)

Note the following points:

- The tightening torques listed below are for lubricated threads only.
- Always tighten threaded fasteners uniformly and in diagonally opposite sequence.
- Overtightening the fasteners will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Promag W Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
25	PN 40	4 x M 12	–	15
32	PN 40	4 x M 16	–	24
40	PN 40	4 x M 16	–	31
50	PN 40	4 x M 16	–	40
65 *	PN 16	8 x M 16	32	27
65	PN 40	8 x M 16	32	27
80	PN 16	8 x M 16	40	34
80	PN 40	8 x M 16	40	34
100	PN 16	8 x M 16	43	36
100	PN 40	8 x M 20	59	50
125	PN 16	8 x M 16	56	48
125	PN 40	8 x M 24	83	71
150	PN 16	8 x M 20	74	63
150	PN 40	8 x M 24	104	88
200	PN 10	8 x M 20	106	91
200	PN 16	12 x M 20	70	61
200	PN 25	12 x M 24	104	92
250	PN 10	12 x M 20	82	71
250	PN 16	12 x M 24	98	85
250	PN 25	12 x M 27	150	134
300	PN 10	12 x M 20	94	81
300	PN 16	12 x M 24	134	118
300	PN 25	16 x M 27	153	138
350	PN 10	16 x M 20	112	118
350	PN 16	16 x M 24	152	165
350	PN 25	16 x M 30	227	252
400	PN 10	16 x M 24	151	167
400	PN 16	16 x M 27	193	215
400	PN 25	16 x M 33	289	326
450	PN 10	20 x M 24	153	133
450	PN 16	20 x M 27	198	196
450	PN 25	20 x M 33	256	253
500	PN 10	20 x M 24	155	171
500	PN 16	20 x M 30	275	300
500	PN 25	20 x M 33	317	360

Promag W Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
600	PN 10	20 x M 27	206	219
600 *	PN 16	20 x M 33	415	443
600	PN 25	20 x M 36	431	516
700	PN 10	24 x M 27	246	246
700	PN 16	24 x M 33	278	318
700	PN 25	24 x M 39	449	507
800	PN 10	24 x M 30	331	316
800	PN 16	24 x M 36	369	385
800	PN 25	24 x M 45	664	721
900	PN 10	28 x M 30	316	307
900	PN 16	28 x M 36	353	398
900	PN 25	28 x M 45	690	716
1000	PN 10	28 x M 33	402	405
1000	PN 16	28 x M 39	502	518
1000	PN 25	28 x M 52	970	971
1200	PN 6	32 x M 30	319	299
1200	PN 10	32 x M 36	564	568
1200	PN 16	32 x M 45	701	753
1400	PN 6	36 x M 33	430	398
1400	PN 10	36 x M 39	654	618
1400	PN 16	36 x M 45	729	762
1600	PN 6	40 x M 33	440	417
1600	PN 10	40 x M 45	946	893
1600	PN 16	40 x M 52	1007	1100
1800	PN 6	44 x M 36	547	521
1800	PN 10	44 x M 45	961	895
1800	PN 16	44 x M 52	1108	1003
2000	PN 6	48 x M 39	629	605
2000	PN 10	48 x M 45	1047	1092
2000	PN 16	48 x M 56	1324	1261
* Designed acc. to EN 1092-1 (not to DIN 2501)				

Promag W Nominal diameter		AWWA Pressure rating	Threaded fasteners	Max. tightening torque [Nm]	
[mm]	[inch]			Hard rubber	Polyurethane
700	28"	Class D	28 x 1 1/4"	247	292
750	30"	Class D	28 x 1 1/4"	287	302
800	32"	Class D	28 x 1 1/2"	394	422
900	36"	Class D	32 x 1 1/2"	419	430
1000	40"	Class D	36 x 1 1/2"	420	477
1050	42"	Class D	36 x 1 1/2"	528	518
1200	48"	Class D	44 x 1 1/2"	552	531
1350	54"	Class D	44 x 1 3/4"	730	633
1500	60"	Class D	52 x 1 3/4"	758	832
1650	66"	Class D	52 x 1 3/4"	946	955
1800	72"	Class D	60 x 1 3/4"	975	1087
2000	78"	Class D	64 x 2"	853	786

Promag W Nominal diameter		ANSI Pressure rating [lbs]	Threaded fasteners	Max. tightening torque [Nm]	
[mm]	[inch]			Hard rubber	Polyurethane
25	1"	Class 150	4 x 1/2"	—	7
25	1"	Class 300	4 x 5/8"	—	8
40	1 1/2"	Class 150	4 x 1/2"	—	10
40	1 1/2"	Class 300	4 x 3/4"	—	15
50	2"	Class 150	4 x 5/8"	—	22
50	2"	Class 300	8 x 5/8"	—	11
80	3"	Class 150	4 x 5/8"	60	43
80	3"	Class 300	8 x 3/4"	38	26
100	4"	Class 150	8 x 5/8"	42	31
100	4"	Class 300	8 x 3/4"	58	40
150	6"	Class 150	8 x 3/4"	79	59
150	6"	Class 300	12 x 3/4"	70	51
200	8"	Class 150	8 x 3/4"	107	80
250	10"	Class 150	12 x 7/8"	101	75
300	12"	Class 150	12 x 7/8"	133	103
350	14"	Class 150	12 x 1"	135	158
400	16"	Class 150	16 x 1"	128	150
450	18"	Class 150	16 x 1 1/8"	204	234
500	20"	Class 150	20 x 1 1/8"	183	217
600	24"	Class 150	20 x 1 1/4"	268	307

Promag W Nominal diameter [mm]	JIS Pressure rating	Threaded fasteners	Max. tightening torque [Nm]	
			Hard rubber	Polyurethane
25	10K	4 x M 16	—	19
25	20K	4 x M 16	—	19
32	10K	4 x M 16	—	22
32	20K	4 x M 16	—	22
40	10K	4 x M 16	—	24
40	20K	4 x M 16	—	24
50	10K	4 x M 16	—	33
50	20K	8 x M 16	—	17
65	10K	4 x M 16	55	45
65	20K	8 x M 16	28	23
80	10K	8 x M 16	29	23
80	20K	8 x M 20	42	35
100	10K	8 x M 16	35	29
100	20K	8 x M 20	56	48
125	10K	8 x M 20	60	51
125	20K	8 x M 22	91	79
150	10K	8 x M 20	75	63
150	20K	12 x M 22	81	72
200	10K	12 x M 20	61	52
200	20K	12 x M 22	91	80
250	10K	12 x M 22	100	87
250	20K	12 x M 24	159	144
300	10K	16 x M 22	74	63
300	20K	16 x M 24	138	124

Promag W Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque [Nm]
			Hard rubber
80	Table E	4 x M 16	49
100	Table E	8 x M 16	38
150	Table E	8 x M 20	64
200	Table E	8 x M 20	96
250	Table E	12 x M 20	98
300	Table E	12 x M 24	123
350	Table E	12 x M 24	203
400	Table E	12 x M 24	226
500	Table E	16 x M 24	271
600	Table E	16 x M 30	439

Promag W Nominal diameter [mm]	AS 4087 Pressure rating	Threaded fasteners	Max. tightening torque [Nm] Hard rubber
80	Cl.14	4 x M 16	49
100 *	Cl.14	8 x M 16	38
150	Cl.14	8 x M 20	52
200	Cl.14	8 x M 20	77
250	Cl.14	8 x M 20	147
300	Cl.14	12 x M 24	103
350	Cl.14	12 x M 24	203
400	Cl.14	12 x M 24	226
500	Cl.14	16 x M 24	271
600	Cl.14	16 x M 30	393
* Designed acc. to EN 2129 (not to DIN 4087)			

3.3.2 Installing the Promag P sensor



Caution!

- The protective covers mounted on the two sensor flanges guard the PTFE lining, which is turned over the flanges. Consequently, do not remove these covers until *immediately before* the sensor is installed in the pipe.
- The covers must remain in place while the device is in storage.
- Make sure that the lining is not damaged or removed from the flanges.




Note!

Bolts, nuts, seals, etc. are not included in the scope of supply and must be supplied by the customer.

The sensor is designed for installation between the two piping flanges.

- Observe in any case the necessary screw tightening torques on Page 36 ff.
- The mounting of additional ground disks is described on Seite 34.



F-5xPxxxxxx-17-05-xx-xx-000

Fig. 19: Installing the Promag P sensor

Seals

Comply with the following instructions when installing seals:

- Measuring tube linings with PFA or PTFE → **No** seals are required.
- In case you use seals with DIN flanges, use only seals according to DIN EN 1514-1.
- Make sure that the seals do not protrude into the piping cross-section.



Caution!

Risk of short circuit. Do not use electrically conductive sealing compound such as graphite. An electrically conductive layer could form on the inside of the measuring tube and short-circuit the measuring signal.

Ground cable (DN 15...600)


If necessary, a special ground cable for potential equalisation can be ordered as an accessory (see Page 85). Detailed assembly instructions → Page 57 ff.

Assembly with ground disks (DN 15...300)

Depending on the application, e.g. with lined or ungrounded pipes (see Page 56 ff.), it may be necessary to mount ground disks between the sensor and the pipe flange for the potential equalisation. Ground disks can be ordered separately as an accessory from Endress+Hauser (see Page 85).

**Caution!**

- In this case, when using ground disks (including seals) the total fitting length increases!
All the dimensions are provided in the separate documentation "Technical Information".
 - PTFE and PFA lining → only install additional seals between the ground disk and pipe flange.
1. Place the ground disk and the additional seal between the instrument and the pipe flange (Fig. 20).
 2. Insert the bolts through the flange holes. Tighten the nuts so that they are still loose.
 3. Now rotate the ground disk as shown in Fig. 20 until the handle strikes the bolts. This will center the ground disk automatically.
 4. Now tighten the bolts to the required torque (see Page 36 ff.)
 5. Connect the ground disk to ground → Page 58.



F06-5xFxxxxx-17-05-xx-xx-001

Fig. 20: Assembly with ground disks (Promag P, DN 15...300)

Installing the high-temperature version (with PFA lining)

The high-temperature version has a housing support for the thermal separation of sensor and transmitter. The high-temperature version is always used for applications in which high ambient temperatures are encountered *in conjunction with* high fluid temperatures. The high-temperature version is obligatory if the fluid temperature exceeds +150 °C.

**Note!**


You will find information on permissible temperature ranges on → Page 111

Insulation

Pipes generally have to be insulated if they carry very hot fluids, in order to avoid energy losses and to prevent accidental contact with pipes at temperatures that could cause injury. Guidelines regulating the insulation of pipes have to be taken into account.

**Caution!**

Risk of measuring electronics overheating. The housing support dissipates heat and its entire surface area must remain uncovered. Make sure that the sensor insulation does not extend past the top of the two sensor shells (Fig. 21).



F06-5xPxxxxx-17-05-00-xx-000

Fig. 21: Promag P (high-temperature version): Insulating the pipe

Tightening torques for threaded fasteners (Promag P)

Note the following points:

- The tightening torques listed below are for lubricated threads only.
- Always tighten threaded fasteners uniformly and in diagonally opposite sequence.
- Overtightening the fasteners will deform the sealing faces or damage the seals.
- The tightening torques listed below apply only to pipes not subjected to tensile stress.

Promag P Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]	
			PTFE	PFA
15	PN 40	4 x M 12	11	—
25	PN 40	4 x M 12	26	20
32	PN 40	4 x M 16	41	35
40	PN 40	4 x M 16	52	47
50	PN 40	4 x M 16	65	59
65 *	PN 16	8 x M 16	43	40
65	PN 40	8 x M 16	43	40
80	PN 16	8 x M 16	53	48
80	PN 40	8 x M 16	53	48
100	PN 16	8 x M 16	57	51
100	PN 40	8 x M 20	78	70
125	PN 16	8 x M 16	75	67
125	PN 40	8 x M 24	111	99
150	PN 16	8 x M 20	99	85
150	PN 40	8 x M 24	136	120
200	PN 10	8 x M 20	141	101
200	PN 16	12 x M 20	94	67
200	PN 25	12 x M 24	138	105
250	PN 10	12 x M 20	110	—
250	PN 16	12 x M 24	131	—
250	PN 25	12 x M 27	200	—
300	PN 10	12 x M 20	125	—
300	PN 16	12 x M 24	179	—
300	PN 25	16 x M 27	204	—
350	PN 10	16 x M 20	188	—
350	PN 16	16 x M 24	254	—
350	PN 25	16 x M 30	380	—
400	PN 10	16 x M 24	260	—
400	PN 16	16 x M 27	330	—
400	PN 25	16 x M 33	488	—
450	PN 10	20 x M 24	235	—
450	PN 16	20 x M 27	300	—
450	PN 25	20 x M 33	385	—
500	PN 10	20 x M 24	265	—
500	PN 16	20 x M 30	448	—

Promag P Nominal diameter [mm]	EN (DIN) Pressure rating [bar]	Threaded fasteners	Max. tightening torque [Nm]	
			PTFE	PFA
500	PN 25	20 x M 33	533	—
600	PN 10	20 x M 27	345	—
600 *	PN 16	20 x M 33	658	—
600	PN 25	20 x M 36	731	—
* Designed acc. to EN 1092-1 (not to DIN 2501)				

Promag P Nominal diameter [mm] [inch]		ANSI Pressure rating [lbs]	Threaded fasteners	Max. tightening torque [Nm]	
				PTFE	PFA
15	1/2"	Class 150	4 x 1/2"	6	—
15	1/2"	Class 300	4 x 1/2"	6	—
25	1"	Class 150	4 x 1/2"	11	10
25	1"	Class 300	4 x 5/8"	14	12
40	1 1/2"	Class 150	4 x 1/2"	24	21
40	1 1/2"	Class 300	4 x 3/4"	34	31
50	2"	Class 150	4 x 5/8"	47	44
50	2"	Class 300	8 x 5/8"	23	22
80	3"	Class 150	4 x 5/8"	79	67
80	3"	Class 300	8 x 3/4"	47	42
100	4"	Class 150	8 x 5/8"	56	50
100	4"	Class 300	8 x 3/4"	67	59
150	6"	Class 150	8 x 3/4"	106	86
150	6"	Class 300	12 x 3/4"	73	67
200	8"	Class 150	8 x 3/4"	143	109
250	10"	Class 150	12 x 7/8"	135	—
300	12"	Class 150	12 x 7/8"	178	—
350	14"	Class 150	12 x 1"	260	—
400	16"	Class 150	16 x 1"	246	—
450	18"	Class 150	16 x 1 1/8"	371	—
500	20"	Class 150	20 x 1 1/8"	341	—
600	24"	Class 150	20 x 1 1/4"	477	—

Promag P Nominal diameter [mm]	JIS Pressure rating	Threaded fasteners	Max. tightening torque [Nm]	
			PTFE	PFA
15	10K	4 x M 12	16	—
15	20K	4 x M 12	16	—
25	10K	4 x M 16	32	—
25	20K	4 x M 16	32	—
32	10K	4 x M 16	38	—
32	20K	4 x M 16	38	—
40	10K	4 x M 16	41	—
40	20K	4 x M 16	41	—
50	10K	4 x M 16	54	—
50	20K	8 x M 16	27	—
65	10K	4 x M 16	74	—
65	20K	8 x M 16	37	—
80	10K	8 x M 16	38	—
80	20K	8 x M 20	57	—
100	10K	8 x M 16	47	—
100	20K	8 x M 20	75	—
125	10K	8 x M 20	80	—
125	20K	8 x M 22	121	—
150	10K	8 x M 20	99	—
150	20K	12 x M 22	108	—
200	10K	12 x M 20	82	—
200	20K	12 x M 22	121	—
250	10K	12 x M 22	133	—
250	20K	12 x M 24	212	—
300	10K	16 x M 22	99	—
300	20K	16 x M 24	183	—

Promag P Nominal diameter [mm]	AS 2129 Pressure rating	Threaded fasteners	Max. tightening torque [Nm]
			PTFE
25	Table E	4 x M 12	21
50	Table E	4 x M 16	42

Promag P Nominal diameter [mm]	AS 4087 Pressure rating	Threaded fasteners	Max. tightening torque [Nm]
			PTFE
50	Cl.14	4 x M 16	42

3.3.3 Installing the Promag H sensor

The Promag H is supplied to order, with or without pre-installed process connections. Pre-installed process connections are secured to the sensor with hex-head threaded fasteners.



Caution!

- The sensor might require support or additional attachments, depending on the application and the length of the piping run. When plastic process connections are used, the sensor must be additionally supported mechanically. A wall-mounting kit can be ordered separately from Endress+Hauser as an accessory (see Page 85).




Fig. 22: Promag H process connections (DN 2...25, DN 40...100)

A: DN 2...25 / process connections with O-rings:

Welding flanges (DIN EN ISO 1127, ODT / SMS), flange (EN (DIN), ANSI, JIS), flange PVDF (EN (DIN), ANSI, JIS), external and internal pipe threads, hose connection, PVC adhesive fitting

B: DN 2...25 / process connections with aseptic gasket seals:

Weld nipples (DIN 11850, ODT / SMS), Clamp (ISO 2852, DIN 32676, L14 AM7), coupling (DIN 11851, DIN 11864-1, SMS 1145), flange DIN 11864-2

C: DN 40...100 / process connections with aseptic gasket seals:

Weld nipples (DIN 11850, ODT / SMS), Clamp (ISO 2852, DIN 32676), L14 AM7, coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145), flange DIN 11864-2

Seals

When installing the process connections, make sure that the seals are clean and correctly centered.



Caution!

- With metallic process connections, you must fully tighten the screws. The process connection forms a metallic connection with the sensor, which ensures a defined compression of the seal.
- With plastic process connections, note the max. torques for lubricated threads (7 Nm). With plastic flanges, always use seals between connection and counter flange.
- The seals must be replaced periodically, depending on the application, particularly in the case of gasket seals (aseptic version)! The period between changes depends on the frequency of cleaning cycles, the cleaning temperature and the fluid temperature. Replacement seals can be ordered as accessories → Page 85.

Usage and assembly of ground rings (DN 2...25)

In case the process connections are made of plastic (e.g. flanges or adhesive fittings), the potential between the sensor and the fluid must be equalised using additional ground rings.

If the ground rings are not installed this can affect the accuracy of the measurements or cause the destruction of the sensor through the electrochemical erosion of the electrodes.



Caution!

- Depending on the option ordered, plastic disks may be installed at the process connections instead of ground rings. These plastic disks serve only as spacers and have no potential equalization function. In addition, they provide a sealing function at the interface between the sensor and process connection. For this reason, with process connections without ground rings, these plastic disks/seals must not be removed, or must always be installed.
- Ground rings can be ordered separately from Endress+Hauser as accessories (see Page 85). When placing the order, make certain that the ground ring is compatible with the material used for the electrodes. Otherwise, there is a risk that the electrodes may be destroyed by electrochemical corrosion! Information about the materials can be found on Page 117.
- Ground rings, including the seals, are mounted within the process connections. Therefore, the fitting length is not affected.

1. Loosen the four hexagonal headed bolts (1) and remove the process connection from the sensor (5).
2. Remove the plastic disk (3), including the two O-ring seals (2, 4).
3. Place one seal (2) in the groove of the process connection.
4. Place the metal ground ring (3) on the process connection.
5. Now place the second seal (4) in the groove of the ground ring.
6. Finally, mount the process connection on the sensor again. With plastic process connections, note the max. torques for lubricated threads (7 Nm).




Fig. 23: Installing ground rings with a Promag H (DN 2...25)

- 1 = Hexagonal headed bolts (process connection)
 2 = O-ring seals
 3 = Ground ring or plastic disk (placeholder)
 4 = Sensor Promag H

Welding the sensor into the piping (weld nipples)



Caution!

Risk of destroying the measuring electronics. Make sure that the welding machine is *not* grounded via the sensor or the transmitter.

1. Tack-weld the Promag H sensor into the pipe. A suitable welding jig can be ordered separately from Endress+Hauser as an accessory (see Page 85).
2. Remove the threaded fasteners from the process-connection flange. Remove the sensor complete with seal from the pipe.
3. Weld the process connection to the pipe.
4. Reinstall the sensor in the pipe. Make sure that everything is clean and that the seal is correctly seated.



Note!

- If thin-walled foodstuffs pipes are not welded correctly, the heat could damage the installed seal. It is therefore advisable to remove the sensor and the seal prior to welding.
- The pipe has to be spread approximately 8 mm to permit disassembly.

Cleaning with pigs

If pigs are used for cleaning, it is essential to take the inside diameters of measuring tube and process connection into account.

All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation "Technical Information".

3.3.4 Turning the transmitter housing


Turning the aluminum field housing



Warning!

The turning mechanism in devices with EEx d/de or FM/CSA Cl. I Div. 1 classification is not the same as that described here. The procedure for turning these housings is described in the Ex-specific documentation.

1. Loosen the two securing screws.
2. Turn the bayonet catch as far as it will go.
3. Carefully lift the transmitter housing as far as it will go.
4. Turn the transmitter housing to the desired position (max. 2 x 90° in either direction).
5. Lower the housing into position and re-engage the bayonet catch.
6. Retighten the two securing screws.




F06-xxxxxxx-17-06-xx-xx-000

Fig. 24: Turning the transmitter housing (aluminum field housing)

Turning the stainless-steel field housing

1. Loosen the two securing screws.
2. Carefully lift the transmitter housing as far as it will go.
3. Turn the transmitter housing to the desired position (max. 2 x 90° in either direction).
4. Lower the housing into position.
5. Retighten the two securing screws.




F06-xxxxxxx-17-06-xx-xx-001

Fig. 25: Turning the transmitter housing (stainless-steel field housing)

3.3.5 Turning the local display

1. Remove the cover of the electronics compartment.
2. Press the side latches on the display module and remove it from the electronics compartment cover plate.
3. Rotate the display to the desired position (max. $4 \times 45^\circ$ in each direction), and place it back into the electronics compartment cover plate.
4. Screw the cover of the electronics compartment firmly onto the transmitter housing.



F06-xxxxxxx-07-xx-06-xx-000

Fig. 26: Turning the local display (field housing)

3.3.6 Installing the wall-mount transmitter housing

There are various ways of installing the wall-mount transmitter housing:

- Mounted directly on the wall
- Installation in control panel (with separate mounting kit, accessories → Page 85)
- Pipe mounting (with separate mounting kit, accessories → Page 85)




Caution!

- Make sure that ambient temperature does not exceed the permissible range (−20...+60 °C), (optional −40...+60 °C). Install the device at a shady location. Avoid direct sunlight.
- Always install the wall-mount housing in such a way that the cable entries are pointing down.

Direct wall mounting

1. Drill the holes as illustrated in Fig. 27.
2. Remove the cover of the connection compartment (a).
3. Push the two securing screws (b) through the appropriate bores (c) in the housing.
 - Securing screws (M6): max. Ø 6.5 mm
 - Screw head: max. Ø 10.5 mm
4. Secure the transmitter housing to the wall as indicated.
5. Screw the cover of the connection compartment (a) firmly onto the housing.



A0001130

Fig. 27: Mounted directly on the wall

Panel installation

1. Prepare the opening in the panel (Fig. 28).
2. Slide the housing into the opening in the panel from the front.
3. Screw the fasteners onto the wall-mount housing.
4. Place the threaded rods in the fasteners and screw them down until the housing is seated tightly against the panel. Afterwards, tighten the locking nuts. Additional support is not necessary.




Fig. 28: Panel Installation (wall-mount housing)

Pipe mounting

The assembly should be performed by following the instructions in Fig. 29.



Caution!

If the device is mounted to a warm pipe, make certain that the housing temperature does not exceed +60 °C, which is the maximum permissible temperature.




Fig. 29: Pipe mounting (wall-mount housing)

3.4 Installation check

Perform the following checks after installing the measuring device in the pipe:

Device condition and specifications	Notes
Is the device damaged (visual inspection)?	—
Does the device correspond to specifications at the measuring point, including process temperature and pressure, ambient temperature, minimum fluid conductivity, measuring range, etc.?	see Page 107 ff.
Installation	Notes
Does the arrow on the sensor nameplate match the direction of flow through the pipe?	—
Is the plane of the measuring-electrode axis correct?	Horizontal
Is the position of the Empty Pipe Detection (EPD) electrode correct?	see Page 17
Were all threaded fasteners tightened to the specified torques when the sensor was installed?	see Chap. 3.3
Were the correct seals installed (type, material, installation)?	Promag W → Page 26 Promag P → Page 33 Promag H → Page 39
Are the measuring-point number and labeling correct (visual inspection)?	—
Process environment / process conditions	Notes
Are the inlet and outlet runs respected?	Inlet run $\geq 5 \times \text{DN}$ Outlet run $\geq 2 \times \text{DN}$
Is the measuring device protected against moisture and direct sunlight?	—
Is the sensor adequately protected against vibration (attachment, support)?	Acceleration up to 2 g by analogy with IEC 600 68-2-6 (see Page 110)

4 Wiring



Warning!

- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to this Operating Manual. Please do not hesitate to contact your Endress+Hauser representative if you have any questions.
- If you use remote versions, connect each sensor *only* to the transmitter having the same serial number. Measuring errors can occur if the devices are not connected in this way.

4.1 Connecting the remote version

4.1.1 Connecting Promag W / P / H



Warning!

- Risk of electric shock. Switch off the power supply before opening the device. Do not install or wire the device while it is connected to the power supply. Failure to comply with this precaution can result in irreparable damage to the electronics.
- Risk of electric shock. Connect the protective conductor to the ground terminal on the housing before the power supply is applied.

Procedure (Fig. 30, Fig. 31):

1. Transmitter: Loosen the screws and remove cover (a) from the connection compartment.
2. Sensor: Remove cover (b) from the connection housing.
3. Feed signal cable (c) and coil cable (d) through the appropriate cable entries.



Caution!

- Make sure the connecting cables are secured (see Page 25).
- Risk of damaging the coil driver. Always switch off the power supply before connecting or disconnecting the coil cable.


4. Preterminate signal cable and coil current cable:
Promag W, P → Refer to the information on Page 49
Promag H → Refer to the information on Page 50
5. Establish the connections between sensor and transmitter in accordance with the wiring diagram:
→ Fig. 30, Fig. 31
→ wiring diagram inside the cover



Caution!

Insulate the shields of cables that are not connected to eliminate the risk of short-circuits with neighboring cable shields inside the sensor connection housing.


6. Transmitter: Secure cover (a) on the connection compartment.
7. Sensor: Secure cover (b) on the connection housing.



F06-5xPxxxx-04-xx-xx-en-000

Fig. 30: Connecting the remote version of Promag W/P

a = cover of the connection compartment, b = cover of the sensor connection housing, c = signal cable, d = coil current cable, n.c. = not connected, insulated cable shields



F06-5xHxxxx-04-xx-xx-de-000

Fig. 31: Connecting the remote version of Promag H

a = cover of the connection compartment, b = cover of the sensor connection housing, c = signal cable, d = coil current cable, n.c. = not connected, insulated cable shields

Cable termination for the remote version Promag W / Promag P

Terminate the signal and coil current cables as shown in the figure below (Detail A).
Fit the fine-wire cores with cable end sleeves (Detail B).




Caution!!

When fitting the connectors, pay attention to the following points:

- **Signal cable** → Make sure that the cable end sleeves do not touch the wire shield on the sensor side.
Minimum distance = 1 mm (exception "GND" = green cable).
- **Coil current cable** → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.


TRANSMITTER

Signal cable



A0002643


Coil current cable



A0002644


SENSOR

Signal cable



A0002645

Coil current cable



A0002645

① = Red cable sleeves \varnothing 1.0 mm

② = White cable sleeves \varnothing 0.5 mm

* = Stripping for armoured cables only

Cable termination for the remote version Promag H

Terminate the signal and coil current cables as shown in the figure below (Detail A).
Fit the fine-wire cores with cable end sleeves (Detail B).




Caution!!

When fitting the connectors, pay attention to the following points:

- **Signal cable** → Make sure that the cable end sleeves do not touch the wire shield on the sensor side.
Minimum distance = 1 mm (exception "GND" = green cable).
- **Coil current cable** → Insulate one core of the three-core wire at the level of the core reinforcement; you only require two cores for the connection.
- On the sensor side, reverse both cable shields approx. 15 mm over the outer jacket. The strain relief ensures an electrical connection with the connection housing.


TRANSMITTER

Signal cable



A0002686


Coil current cable



A0002684


SENSOR

Signal cable



A0002647

Coil current cable



A0002648

- ① = Red cable sleeves Ø 1.0 mm
② = White cable sleeves Ø 0.5 mm


4.1.2 Cable specifications

Coil cable:

- 2 x 0.75 mm² PVC cable with common, braided copper shield (Ø approx. 7 mm)
- Conductor resistance: ≤ 37 Ω/km
- Capacitance: core/core, shield grounded: ≤ 120 pF/m
- Permanent operating temperature: -20...+80 °
- Cable cross-section: max. 2.5 mm²

Signal cable:

- 3 x 0.38 mm² PVC cable with common, braided copper shield (Ø approx. 7 mm) and individually shielded cores
- With Empty Pipe Detection (EPD): 4 x 0.38 mm² PVC cable with common, braided copper shield (Ø approx. 7 mm) and individually shielded cores
- Conductor resistance: ≤ 50 Ω/km
- Capacitance: core/shield: ≤ 420 pF/m
- Permanent operating temperature: -20...+80 °C
- Cable cross-section: max. 2.5 mm²



F06-5xWxxxxx-04-11-08-xx-003

Fig. 32: Cable cross-section (a = Signal cable, b = Coil current cable)

1 = Core, 2 = Core insulation, 3 = Core shield, 4 = Core jacket, 5 = Core reinforcement, 6 = Cable shield, 7 = Outer jacket

As an option, Endress+Hauser can also deliver reinforced connecting cables with an additional, reinforcing metal braid. We recommend such cables for the following cases:

- Directly buried cable
- Cables endangered by rodents
- Device operation which should comply with the IP 68 standard of protection

Operation in zones of severe electrical interference:

The measuring device complies with the general safety requirements in accordance with EN 61010, the EMC requirements of EN 61326/A1, and NAMUR recommendation NE 21.



Caution!

Grounding is by means of the ground terminals provided for the purpose inside the connection housing. Keep the stripped and twisted lengths of cable shield to the terminals as short as possible.

4.2 Connecting the measuring unit


4.2.1 Transmitter



Warning!

- Risk of electric shock. Switch off the power supply before opening the device.
Do not install or wire the device while it is connected to the power supply. Failure to comply with this precaution can result in irreparable damage to the electronics.
- Risk of electric shock. Connect the protective conductor to the ground terminal on the housing before the power supply is applied (not necessary if the power supply is galvanically isolated).
- Compare the specifications on the nameplate with the local voltage supply and frequency. The national regulations governing the installation of electrical equipment also apply.


1. Remove the cover of the connection compartment (f) from the transmitter housing.
2. Feed the power supply cable (a) and signal cables (b) through the appropriate cable entries.
3. Connect the cables in accordance with the wiring diagram:
 - Wiring diagram (aluminium housing) → Fig. 33
 - Wiring diagram (stainless steel housing) → Fig. 34
 - Wiring diagram (wall-mount housing) → Fig. 35
 - Terminal assignment → Page 54
4. Screw the cover of the connection compartment (f) firmly onto the transmitter housing.



F06-xxxxxxx-04-06-xx-xx-005

Fig. 33: Connecting the transmitter (aluminium field housing). Cable cross-section: max. 2.5 mm²


- a Cable for power supply: 85...260 V AC, 20...55 V AC, 16...62 V DC
Terminal **No. 1**: L1 for AC, L+ for DC
Terminal **No. 2**: N for AC, L- for DC
- b Signal cable: Terminals **Nos. 20–27** → Page 54
- c Ground terminal for protective conductor
- d Ground terminal for signal cable shield
- e Service adapter for connecting service interface FXA 193 (Fieldcheck, ToF Tool – Fieldtool Package)
- f Cover of the connection compartment
- g Securing clamp



F06-xxxxxxx-04-06-xx-xx-006

Fig. 34: Connecting the transmitter (stainless-steel field housing). Cable cross-section: max. 2.5 mm²

- a Cable for power supply: 85...260 V AC, 20...55 V AC, 16...62 V DC
Terminal No. 1: L1 for AC, L+ for DC
Terminal No. 2: N for AC, L- for DC
- b Signal cable: Terminals Nos. 20–27 → Page 54
- c Ground terminal for protective conductor
- d Ground terminal for signal cable shield
- e Service adapter for connecting service interface FXA 193 (Fieldcheck, ToF Tool – Fieldtool Package)
- f Cover of the connection compartment



A6001135

Fig. 35: Connecting the transmitter (wall-mount housing). Cable cross-section: max. 2.5 mm²

- a Cable for power supply: 85...260 V AC, 20...55 V AC, 16...62 V DC
Terminal No. 1: L1 for AC, L+ for DC
Terminal No. 2: N for AC, L- for DC
- b Signal cable: Terminals Nos. 20–27 → Page 54
- c Ground terminal for protective conductor
- d Ground terminal for signal cable shield
- e Service adapter for connecting service interface FXA 193 (Fieldcheck, ToF Tool – Fieldtool Package)
- f Cover of the connection compartment

4.2.2 Terminal assignment

Order variant	Terminal No. (inputs / outputs)			
	20 (+) / 21 (-)	22 (+) / 23 (-)	24 (+) / 25 (-)	26 (+) / 27 (-)
50***_*****W	—	—	—	Current output HART
50***_*****A	—	—	Frequency output	Current output HART
50***_*****D	Status input	Status output	Frequency output	Current output HART
50***_*****S	—	—	Frequency output Ex i	Current output Ex i active, HART
50***_*****T	—	—	Frequency output Ex i	Current output Ex i passive, HART
<p><i>Status input (auxiliary input)</i> galvanically isolated, 3...30 V DC, $R_i = 5 \text{ k}\Omega$</p> <p><i>Status output</i> Open collector, max. 30 V DC / 250 mA, galvanically isolated, freely configurable</p> <p><i>Frequency output (passive)</i> Open collector, galvanically isolated, full scale frequency 2...1000 Hz ($f_{\max} = 1.25 \text{ kHz}$) 30 V DC, 250 mA</p> <p><i>Current output (active/passive)</i> galvanically isolated, active: 0/4...20 mA, $R_L < 700 \Omega$ (HART: $R_L \geq 250 \Omega$) passive: 4...20 mA, supply voltage V_s: 18...30 V DC, $R_i \geq 150 \Omega$</p> <p>Ground connection, power supply → Page 52 ff.</p>				

4.2.3 HART connection

Users have the following connection options at their disposal:


- Direct connection to transmitter by means of terminals 26(+) / 27(-)
- Connection by means of the 4...20 mA circuit



Note!

- The measuring loop's minimum load must be at least 250 Ω .
- After commissioning, make the following settings:
CURRENT SPAN function → "4–20 mA HART" or "4–20 mA (25 mA) HART"
- See also the documentation issued by the HART Communication Foundation, and in particular HCF LIT 20: "HART, a technical summary".

Connection of the HART handheld communicator




F06-xxxxxxx-04-xx-xx-xx-007

Fig. 36: Electrical connection of the HART handheld communicator:

1 = HART communicator, 2 = power supply, 3 = shield, 4 = other evaluation devices or PLC with passive input

Connection of a PC with an operating software

In order to connect a PC with an operating software (e.g. "ToF Tool - Fieldtool Package"), a HART modem (e.g. "Commubox FXA 191") is needed.



F06-xxxxxxx-04-xx-xx-xx-008

Fig. 37: Electrical connection of a PC with an operating software:

1 = PC with an operating software, 2 = power supply, 3 = shield, 4 = other evaluation devices or PLC with passive input, 5 = HART modem, e.g. Commubox FXA 191

4.3 Potential equalisation

4.3.1 Standard case

Perfect measurement is only ensured when the medium and the sensor have the same electrical potential. Most Promag sensors have a standard installed reference electrode which guarantees the required connection. This usually means that additional potential matching measures are unnecessary.

Promag W:

Reference electrode is standard

Promag P:

- Reference electrode is standard for electrode materials 1.4435, Alloy C-22 and tantalum.
- Reference electrode is optional for electrode material Pt/Rh.


Promag H:

- No reference electrode. The metallic process connection provides a permanent electrical connection to the fluid.
- If the process connections are made of a synthetic material, ground rings have to be used to ensure that potential is equalised (see Page 40). Ground rings can be ordered with the main product structure or as accessories → Page 85.



Note!

For installation in metal pipes, it is advisable to connect the ground terminal of the transmitter housing to the piping. Also, observe company-internal grounding guidelines.



F06-5XXXXXX-04-XX-XX-XX-002

Fig. 38: Potential equalisation by means of the transmitter's ground terminal



Caution!

For sensors without reference electrodes or without metal process terminals, carry out potential equalisation as per the instructions for special cases described below. These special measures are particularly important when standard grounding practice cannot be ensured or extremely strong matching currents are expected.

4.3.2 Special cases

Metal, ungrounded piping

In order to prevent outside influences on measurement, it is advisable to use ground cables to connect each sensor flange to its corresponding pipe flange and ground the flanges. Connect the transmitter or sensor connection housing, as applicable, to ground potential by means of the ground terminal provided for the purpose (Fig. 39).



Caution!


Also, observe company-internal grounding guidelines.



Note!

The ground cable for flange-to-flange connections can be ordered separately as an accessory from Endress+Hauser → Page 85.

- $DN \leq 300$: The ground cable is in direct connection with the conductive flange coating and is secured by the flange screws.
- $DN \geq 350$: The ground cable connects directly to the metal transport bracket.



F06-5xxxxxx-04-xx-xx-xx-003

Fig. 39: Potential equalisation with equalising currents in metallic, non-grounded piping systems

Plastic pipes and isolating lined pipes


Normally, potential is matched using the reference electrodes in the measuring tube. However, in exceptional cases it is possible that, due to the grounding plan of a system, large matching currents flow over the reference electrodes. This can lead to destruction of the sensor, e.g. through electrochemical decomposition of the electrodes. In such cases, e.g. for fibre-glass or PVC piping, it is recommended that you use additional ground disks for potential matching (Fig. 40).

Mounting of ground disks → Page 27, 34



Caution!

- Risk of damage by electrochemical corrosion. Note the electrochemical insulation rating, if the ground disks and measuring electrodes are made of different materials.
- Also, observe company-internal grounding guidelines.




F06-5xxxxxxx-04-xx-xx-xx-004

Fig. 40: Potential equalisation/ground disks with plastic pipes or lined pipes

Lined pipes (cathodic protection)

In such cases, install the measuring instrument without potential in the piping:

- When installing the measuring device, make sure that there is an electrical connection between the two piping runs (copper wire, 6 mm²).
- Make sure that the installation materials do not establish a conductive connection to the measuring device and that the installation materials withstand the tightening torques applied when the threaded fasteners are tightened.
- Also comply with the regulations applicable to potential-free installation.




F06-5xxxxxxx-04-xx-xx-xx-005

Fig. 41: Potential equalisation and cathode protection
1 = isolating transformer power supply, 2 = electrically insulated

4.4 Degree of protection

The devices fulfill all the requirements for IP 67. Compliance with the following points is mandatory following installation in the field or servicing, in order to ensure that IP 67 protection is maintained:

- The housing seals must be clean and undamaged when inserted into their grooves. The seals must be dried, cleaned or replaced if necessary.
- All threaded fasteners and screw covers must be firmly tightened.
- The cables used for connection must be of the specified outside diameter (see Page 108).
- Firmly tighten the cable entries (Fig. 42).
- The cables must loop down before they enter the cable entries ("water trap", Fig. 42). This arrangement prevents moisture penetrating the entry. Always install the measuring device in such a way that the cable entries do not point up.
- Remove all unused cable entries and insert plugs instead.
- Do not remove the grommet from the cable entry.



F06-xxxxxxx-04-xx-xx-xx-005

Fig. 42: Installation instructions, cable entries



Caution!

Do not loosen the threaded fasteners of the Promag sensor housing, as otherwise the degree of protection guaranteed by Endress+Hauser no longer applies.



Note!

The Promag W and Promag P sensors can be supplied with IP 68 rating (permanent immersion in water to a depth of 3 meters). In this case the transmitter must be installed remote from the sensor.

4.5 Electrical connection check

Perform the following checks after completing electrical installation of the measuring device:


Device condition and specifications	Notes
Are cables or the device damaged (visual inspection)?	—
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	85...260 V AC (45...65 Hz) 20...55 V AC (45...65 Hz) 16...62 V DC
Do the cables comply with the specifications?	see Page 51, 108
Do the cables have adequate strain relief?	—
Cables correctly segregated by type? Without loops and crossovers?	—
Are the power-supply and signal cables correctly connected?	See the wiring diagram inside the cover of the terminal compartment
Are all screw terminals firmly tightened?	—
Have the measures for grounding/potential equalisation been correctly implemented?	see Page 56 ff.
Are all cable entries installed, firmly tightened and correctly sealed? Cables looped as "water traps"?	see Page 59
Are all housing covers installed and firmly tightened?	—

5 Operation

5.1 Display and operating elements

The local display enables you to read all important parameters directly at the measuring point and configure the device.

The display area consists of two lines; this is where measured values are displayed, and/or status variables (direction of flow, partially filled pipe, bar graph, etc.). You can change the assignment of display lines to variables at will in order to customize the display to suit your needs and preferences (→ see the “Description of Device Functions” manual).



A0001141

Fig. 43: Display and operating elements

Liquid-crystal display (1)

The backlit, two-line liquid-crystal display shows measured values, dialog texts, error messages and information messages. The display as it appears when normal measuring is in progress is known as the HOME position (operating mode).

Upper display line: Shows primary measured values, e.g. volume flow in [ml/min] or in [%].

Lower display line: Shows supplementary measured variables and status variables, e.g. totalizer reading in [m³], bar graph, measuring point designation

Push buttons (2)

- Enter numerical values, select parameters
- Select different function groups within the function matrix

Press the +/- keys simultaneously to trigger the following functions:

- Exit the function matrix step by step → HOME position
- Press and hold down +/- keys for longer than 3 seconds → Return directly to HOME position
- Cancel data entry

Enter push button (3)

- HOME position → Entry into the function matrix
- Save the numerical values you input or settings you change

5.2 Brief operating instruction to the function matrix



Note!

- See the general notes on Page 63.
- Function descriptions → see the “Description of Device Functions” manual

1. HOME position → → Enter the function matrix
2. Select a function group (e.g. CURRENT OUTPUT 1)
3. Select a function (e.g. TIME CONSTANT)

Change parameter / enter numerical values:

- select or enter enable code, parameters, numerical values
- save your entries

4. Exit the function matrix:
 - Press and hold down Esc key () for longer than 3 seconds → HOME position
 - Repeatedly press Esc key () → return step by step to HOME position






Fig. 44: Selecting functions and configuring parameters (function matrix)

A0001142

5.2.1 General notes

The Quick Setup menu (see Page 80) is adequate for commissioning in most instances. Complex measuring operations on the other hand necessitate additional functions that you can configure as necessary and customize to suit your process parameters. The function matrix, therefore, comprises a multiplicity of additional functions which, for the sake of clarity, are arranged in a number of function groups.

Comply with the following instructions when configuring functions:

- You select functions as described on Page 62.
- You can switch off certain functions (OFF). If you do so, related functions in other function groups will no longer be displayed.
- Certain functions prompt you to confirm your data entries. Press  to select "SURE [YES]" and press  again to confirm. This saves your setting or starts a function, as applicable.
- Return to the HOME position is automatic if no key is pressed for 5 minutes.



Note!

- The transmitter continues to measure while data entry is in progress, i.e. the current measured values are output via the signal outputs in the normal way.
- If the power supply fails, all preset and parameterized values remain safely stored in the EEPROM.



Caution!

All functions are described in detail, including the function matrix itself, in the "Description of Device Functions" manual, which is a separate part of this Operating Instruction.


5.2.2 Enabling the programming mode

The function matrix can be disabled. Disabling the function matrix rules out the possibility of inadvertent changes to device functions, numerical values or factory settings.

A numerical code (factory setting = 50) has to be entered before settings can be changed.

If you use a code number of your choice, you exclude the possibility of unauthorized persons accessing data (→ see the "Description of Device Functions" manual).

Comply with the following instructions when entering codes:

- If programming is disabled and the  key is pressed in any function, a prompt for the code automatically appears on the display.
- If "0" is entered as the customer's code, programming is always enabled.
- The Endress+Hauser service organisation can be of assistance if you mislay your personal code.



Caution!

Changing certain parameters such as all sensor characteristics, for example, influences numerous functions of the entire measuring system, particularly measuring accuracy.

There is no need to change these parameters under normal circumstances and consequently, they are protected by a special code known only to the Endress+Hauser service organization. Please contact Endress+Hauser if you have any questions.

5.2.3 Disabling the programming mode

Programming is disabled if you do not press a key within 60 seconds following automatic return to the HOME position.

You can also disable programming in the "ACCESS CODE" function by entering any number (other than the customer's code).


5.3 Error messages

Type of error

Errors which occur during commissioning or measuring operation are displayed immediately. If two or more system or process errors occur, the error with the highest priority is the one shown on the display.

The measuring system distinguishes between two types of error:

- *System errors:* This group comprises all device errors, e.g. communication errors, hardware faults, etc. → see Page 90
- *Process errors:* This group comprises all application errors, e.g. empty pipe, etc. → see Page 93



A0000991

Fig. 45: Error messages on the display (example)

- 1 Error type: P = process error, S = system error
- 2 Error message type: ⚡ = fault message; ! = notice message
- 3 Error designation: e.g. EMPTY PIPE = measuring tube is only partly filled or completely empty
- 4 Error number: e.g. #401
- 5 Duration of most recent error occurrence in hours / minutes / seconds

Error message types

Users have the option of weighting certain errors differently, in other words having them classed as “**Fault messages**” or “**Notice messages**”. You can define messages in this way with the aid of the function matrix → see the “Description of Device Functions” manual.

Serious system errors, e.g. module defects, are always identified and classed as “fault messages” by the measuring device.

Notice message (!)

- Displayed as → Exclamation mark (!), error type (S: system error, P: process error).
- The error in question has no effect on the outputs of the measuring device.

Fault message (⚡)

- Displayed as → Lightning flash (⚡), error type (S: system error, P: process error).
- The error in question has a direct effect on the outputs.

The response of the outputs (failsafe mode) can be defined by means of functions in the function matrix (see Page 95).



Note!

For security reasons, error messages should be output via the status output.

5.4 Communication

In addition to local operation, the measuring device can be configured and measured values can be obtained by means of the HART protocol. Digital communication takes place using the 4–20 mA current output HART (see Page 55).

The HART protocol allows the transfer of measuring and device data between the HART master and the field devices for configuration and diagnostics purposes. The HART master, e.g. a handheld terminal or PC-based operating programs (such as ToF Tool – Fieldtool Package), require device description (DD) files which are used to access all the information in a HART device. Information is exclusively transferred using so-called “commands”. There are three different command groups:

Universal commands:

All HART device support and use universal commands. The following functionalities are linked to them:

- Identify HART devices
- Reading digital measured values (volume flow, totalizer, etc.)

Common practice commands:

Common practice commands offer functions which are supported and can be executed by most but not all field devices.

Device-specific commands:

These commands allow access to device-specific functions which are not HART standard. Such commands access individual field device information, amongst other things, such as empty/full pipe calibration values, low flow cutoff settings, etc.



Note!

Promag 50 has access to all three command classes. On Page 69, you will find a list with all the supported “Universal Commands” and “Common Practice Commands”.

5.4.1 Operating options

For the complete operation of the measuring device, including device-specific commands, there are DD files available to the user to provide the following operating aids and programs:



Note!

The HART protocol requires the “4...20 mA HART” setting (individual options see device function) in the CURRENT SPAN function (current output 1).

HART handheld terminal DXR 375

Selecting device functions with a HART Communicator is a process involving a number of menu levels and a special HART function matrix.

The HART manual in the carrying case of the HART Communicator contains more detailed information on the device.

Operating program “ToF Tool – Fieldtool Package”

Modular software package consisting of the service program “ToF Tool” for configuration and diagnosis of ToF level measuring devices (time-of-flight measurement) and evolution of pressure measuring instruments as well as the “Fieldtool” service program for the configuration and diagnosis of Proline flow measuring devices. The Proline flow measuring devices are accessed via a service interface or via the service interface FXA 193 or the HART protocol.

Contents of the “ToF Tool – Fieldtool Package”:

- Commissioning, maintenance analysis
- Configuring flowmeters
- Service functions
- Visualisation of process data
- Trouble-shooting
- Controlling the “Fieldcheck” tester/simulator

Fieldcare

FieldCare is Endress+Hauser's FDT-based plant Asset Management Tool and allows the configuration and diagnosis of intelligent field devices. By using status information, you also have a simple but effective tool for monitoring devices. The Proline flow measuring devices are accessed via a service interface or via the service interface FXA 193.

Operating program “SIMATIC PDM” (Siemens)

SIMATIC PDM is a standardised, manufacturer-independent tool for the operation, configuration, maintenance and diagnosis of intelligent field devices.

Operating program “AMS” (Emerson Process Management)

AMS (Asset Management Solutions): program for operating and configuring devices

5.4.2 Current device description files

The following table illustrates the suitable device description file for the operating tool in question and then indicates where these can be obtained.

HART protocol:

Valid for software:	2.00.XX	→Function "Device software"
Device data HART		
Manufacturer ID:	11 _{hex} (ENDRESS+HAUSER)	→ Function "Manufacturer ID"
Device ID:	41 _{hex}	→ Function "Device ID"
HART version data:	Device Revision 6/ DD Revision 1	
Software release:	03.2005	
Operating program:	Sources for obtaining device descriptions:	
Handheld terminal DXR 375	■ Use update function of handheld terminal	
ToF Tool - Fieldtool Package	■ www.tof-fieldtool.endress.com (→ Download → Software → Device driver) ■ CD-ROM (Endress+Hauser order number 50097200)	
Fieldcare / DTM	■ www.endress.com (→ Download → Software → Device driver) ■ CD-ROM (Endress+Hauser order number 50097200)	
AMS	■ www.endress.com (→ Download → Software → Device driver) ■ CD-ROM (Endress+Hauser order number 50097200)	
SIMATIC PDM	■ www.endress.com (→ Download → Software → Device driver) ■ CD-ROM (Endress+Hauser order number 50097200)	

Operation via the service protocol

Valid for device software:	2.00.XX	→Function "Device software"
Software release:	03.2005	
Operating program:	Sources for obtaining device descriptions:	
ToF Tool - Fieldtool Package	■ www.tof-fieldtool.endress.com (→ Download → Software → Device driver) ■ CD-ROM (Endress+Hauser order number 50097200)	

Tester/simulator:	Sources for obtaining device descriptions:
Fieldcheck	■ Update by means of ToF Tool - Fieldtool Package via Fieldflash module

5.4.3 Device and process variables

Device variables:

The following device variables are available using the HART protocol:

Code (decimal)	Device variable
0	OFF (not assigned)
1	Volume flow
250	Totalizer 1
251	Totalizer 2

Process variables:

At the factory, the process variables are assigned to the following device variables:

- Primary process variable (PV) → Volume flow
- Second process variable (SV) → Totalizer 1
- Third process variable (TV) → not assigned
- Fourth process variable (FV) → not assigned








Note!




You can set or change the assignment of device variables to process variables using Command 51 (see Page 73).






5.4.4 Universal / Common practice HART commands




The following table contains all the universal and common practice commands supported by Promag 50.

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
Universal Commands			
0	Read unique device identifier Access type = read	none	<p>Device identification delivers information on the device and the manufacturer. It cannot be changed.</p> <p>The response consists of a 12 byte device ID:</p> <ul style="list-style-type: none"> – Byte 0: fixed value 254 – Byte 1: Manufacturer ID, 17 = E+H – Byte 2: Device type ID, 65 = Promag 50 – Byte 3: Number of preambles – Byte 4: Universal commands rev. no. – Byte 5: Device-specific commands rev. no. – Byte 6: Software revision – Byte 7: Hardware revision – Byte 8: Additional device information – Bytes 9-11: Device identification
1	Read primary process variable Access type = read	none	<ul style="list-style-type: none"> – Byte 0: HART unit code of the primary process variable – Bytes 1-4: Primary process variable <p><i>Factory setting:</i> Primary process variable = Volume flow</p> <p> Note!</p> <ul style="list-style-type: none"> ■ You can set the assignment of device variables to process variables using Command 51. ■ Manufacturer-specific units are represented using the HART unit code "240".
2	Read the primary process variable as current in mA and percentage of the set measuring range Access type = read	none	<ul style="list-style-type: none"> – Bytes 0-3: actual current of the primary process variable in mA – Bytes 4-7: Percentage of the set measuring range <p><i>Factory setting:</i> Primary process variable = Volume flow</p> <p> Note!</p> <p>You can set the assignment of device variables to process variables using Command 51.</p>

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
3	Read the primary process variable as current in mA and four (preset using Command 51) dynamic process variables Access type = read	none	<p>24 bytes are sent as a response:</p> <ul style="list-style-type: none"> – Bytes 0-3: primary process variable current in mA – Byte 4: HART unit code of the primary process variable – Bytes 5-8: Primary process variable – Byte 9: HART unit code of the second process variable – Bytes 10-13: Second process variable – Byte 14: HART unit code of the third process variable – Bytes 15-18: Third process variable – Byte 19: HART unit code of the fourth process variable – Bytes 20-23: Fourth process variable <p><i>Factory setting:</i></p> <ul style="list-style-type: none"> ■ Primary process variable = Volume flow ■ Second process variable = Totalizer 1 ■ Third process variable = not assigned ■ Fourth process variable = not assigned <p> Note!</p> <ul style="list-style-type: none"> ■ You can set the assignment of device variables to process variables using Command 51. ■ Manufacturer-specific units are represented using the HART unit code "240".
6	Set HART shortform address Access type = write	<p>Byte 0: desired address (0...15)</p> <p><i>Factory setting:</i> 0</p> <p> Note! With an address >0 (multidrop mode), the current output of the primary process variable is set to 4 mA.</p>	Byte 0: active address
11	Read unique device identification using the TAG (measuring point designation) Access type = read	Bytes 0-5: TAG	<p>Device identification delivers information on the device and the manufacturer. It cannot be changed. The response consists of a 12 byte device ID if the given TAG agrees with the one saved in the device:</p> <ul style="list-style-type: none"> – Byte 0: fixed value 254 – Byte 1: Manufacturer ID, 17 = E+H – Byte 2: Device type ID, 65 = Promag 50 – Byte 3: Number of preambles – Byte 4: Universal commands rev. no. – Byte 5: Device-specific commands rev. no. – Byte 6: Software revision – Byte 7: Hardware revision – Byte 8: Additional device information – Bytes 9-11: Device identification
12	Read user message Access type = read	none	<p>Bytes 0-24: User message</p> <p> Note! You can write the user message using Command 17.</p>

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
13	Read TAG, descriptor and date Access type = read	none	<ul style="list-style-type: none"> – Bytes 0-5: TAG – Bytes 6-17: descriptor – Bytes 18-20: Date <p> Note! You can write the TAG, descriptor and date using Command 18.</p>
14	Read sensor information on primary process variable	none	<ul style="list-style-type: none"> – Bytes 0-2: Sensor serial number – Byte 3: HART unit code of sensor limits and measuring range of the primary process variable – Bytes 4-7: Upper sensor limit – Bytes 8-11: Lower sensor limit – Bytes 12-15: Minimum span <p> Note!</p> <ul style="list-style-type: none"> ■ The data relate to the primary process variable (= volume flow). ■ Manufacturer-specific units are represented using the HART unit code "240".
15	Read output information of primary process variable Access type = read	none	<ul style="list-style-type: none"> – Byte 0: Alarm selection ID – Byte 1: Transfer function ID – Byte 2: HART unit code for the set measuring range of the primary process variable – Bytes 3-6: upper range, value for 20 mA – Bytes 7-10: lower range, value for 4 mA – Bytes 11-14: Damping constant in [s] – Byte 15: Write protection ID – Byte 16: OEM dealer ID, 17 = E+H <p><i>Factory setting:</i> Primary process variable = Volume flow</p> <p> Note!</p> <ul style="list-style-type: none"> ■ You can set the assignment of device variables to process variables using Command 51. ■ Manufacturer-specific units are represented using the HART unit code "240".
16	Read the device production number Access type = read	none	Bytes 0-2: Production number
17	Write user message Access = write	<p>You can save any 32-character long text in the device under this parameter:</p> <p>Bytes 0-23: Desired user message</p>	<p>Displays the current user message in the device:</p> <p>Bytes 0-23: Current user message in the device</p>
18	Write TAG, descriptor and date Access = write	<p>With this parameter, you can store an 8 character TAG, a 16 character descriptor and a date:</p> <ul style="list-style-type: none"> – Bytes 0-5: TAG – Bytes 6-17: descriptor – Bytes 18-20: Date 	<p>Displays the current information in the device:</p> <ul style="list-style-type: none"> – Bytes 0-5: TAG – Bytes 6-17: descriptor – Bytes 18-20: Date

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
Common Practice Commands			
34	Write damping value for primary process variable Access = write	Bytes 0-3: Damping value of the primary process variable in seconds <i>Factory setting:</i> Primary process variable = Volume flow	Displays the current damping value in the device: Bytes 0-3: Damping value in seconds
35	Write measuring range of primary process variable Access = write	Write the desired measuring range: – Byte 0: HART unit code of the primary process variable – Bytes 1-4: upper range, value for 20 mA – Bytes 5-8: lower range, value for 4 mA <i>Factory setting:</i> Primary process variable = Volume flow  Note! ■ You can set the assignment of device variables to process variables using Command 51. ■ If the HART unit code is not the correct one for the process variable, the device will continue with the last valid unit.	The currently set measuring range is displayed as a response: – Byte 0: HART unit code for the set measuring range of the primary process variable – Bytes 1-4: upper range, value for 20 mA – Bytes 5-8: lower range, value for 4 mA  Note! Manufacturer-specific units are represented using the HART unit code "240".
38	Device status reset (Configuration changed) Access = write	none	none
40	Simulate output current of primary process variable Access = write	Simulation of the desired output current of the primary process variable. An entry value of 0 exits the simulation mode: Bytes 0-3: Output current in mA <i>Factory setting:</i> Primary process variable = Volume flow  Note! You can set the assignment of device variables to process variables using Command 51.	The momentary output current of the primary process variable is displayed as a response: Bytes 0-3: Output current in mA
42	Perform master reset Access = write	none	none
44	Write unit of primary process variable Access = write	Set unit of primary process variable. Only unit which are suitable for the process variable are transferred to the device: Byte 0: HART unit code <i>Factory setting:</i> Primary process variable = Volume flow  Note! ■ If the written HART unit code is not the correct one for the process variable, the device will continue with the last valid unit. ■ If you change the unit of the primary process variable, this has no impact on the system units.	The current unit code of the primary process variable is displayed as a response: Byte 0: HART unit code  Note! Manufacturer-specific units are represented using the HART unit code "240".
48	Read additional device status Access = read	none	The device status is displayed in extended form as the response: Coding: see table on Page 74

Command No. HART command / Access type		Command data (numeric data in decimal form)	Response data (numeric data in decimal form)
50	Read assignment of the device variables to the four process variables Access = read	none	<p>Display of the current variable assignment of the process variables:</p> <ul style="list-style-type: none"> – Byte 0: Device variable code to the primary process variable – Byte 1: Device variable code to the second process variable – Byte 2: Device variable code to the third process variable – Byte 3: Device variable code to the fourth process variable <p><i>Factory setting:</i></p> <ul style="list-style-type: none"> ■ Primary process variable: Code 1 for volume flow ■ Second process variable: Code 250 for totalizer 1 ■ Third process variable: Code 0 for OFF (not assigned) ■ Fourth process variable: Code 0 for OFF (not assigned) <p> Note! You can set or change the assignment of device variables to process variables using Command 51.</p>
51	Write assignments of the device variables to the four process variables Access = write	<p>Setting of the device variables to the four process variables:</p> <ul style="list-style-type: none"> – Byte 0: Device variable code to the primary process variable – Byte 1: Device variable code to the second process variable – Byte 2: Device variable code to the third process variable – Byte 3: Device variable code to the fourth process variable <p><i>Code of the supported device variables:</i> See data on Page 68</p> <p><i>Factory setting:</i></p> <ul style="list-style-type: none"> ■ Primary process variable = Volume flow ■ Second process variable = Totalizer 1 ■ Third process variable = OFF (not assigned) ■ Fourth process variable = OFF (not assigned) 	<p>The variable assignment of the process variables is displayed as a response:</p> <ul style="list-style-type: none"> – Byte 0: Device variable code to the primary process variable – Byte 1: Device variable code to the second process variable – Byte 2: Device variable code to the third process variable – Byte 3: Device variable code to the fourth process variable
53	Write device variable unit Access = write	<p>This command set the unit of the given device variables. Only those units which suit the device variable are transferred:</p> <ul style="list-style-type: none"> – Byte 0: Device variable code – Byte 1: HART unit code <p><i>Code of the supported device variables:</i> See data on Page 68</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If the written unit is not the correct one for the device variable, the device will continue with the last valid unit. ■ If you change the unit of the device variable, this has no impact on the system units. 	<p>The current unit of the device variables is displayed in the device as a response:</p> <ul style="list-style-type: none"> – Byte 0: Device variable code – Byte 1: HART unit code <p> Note! Manufacturer-specific units are represented using the HART unit code "240".</p>
59	Write number of preambles in response message Access = write	<p>This parameter sets the number of preambles which are inserted in the response messages:</p> <p>Byte 0: Number of preambles (2...20)</p>	<p>As a response, the current number of the preambles is displayed in the response message:</p> <p>Byte 0: Number of preambles</p>

5.4.5 Device status / Error messages

You can read the extended device status, in this case, current error messages, via Command "48". The command delivers information which are partly coded in bits (see table below).



Note!

You can find a detailed explanation of the device status and error messages and their elimination on Page 90 ff.

Byte Bit	Error No.	Short error description (→ Page 90 ff.)
0-0	001	Serious device error
0-1	011	Measuring amplifier has faulty EEPROM
0-2	012	Error when accessing data of the measuring amplifier EEPROM
0-3	not assigned	—
0-4	not assigned	—
0-5	not assigned	—
0-6	not assigned	—
0-7	not assigned	—
1-0	not assigned	—
1-1	031	S-DAT: defective or missing
1-2	032	S-DAT: Error accessing saved values
1-3	not assigned	—
1-4	not assigned	—
1-5	051	I/O board and the amplifier board are not compatible.
1-6	not assigned	—
1-7	not assigned	—
2-0	not assigned	—
2-1	not assigned	—
2-2	not assigned	—
2-3	not assigned	—
2-4	not assigned	—
2-5	not assigned	—
2-6	not assigned	—
2-7	not assigned	—
3-0	not assigned	—
3-1	not assigned	—
3-2	not assigned	—
3-3	111	Totalizer checksum error
3-4	121	I/O board and the amplifier board are not compatible.
3-5	not assigned	—
3-6	not assigned	—
3-7	not assigned	—
4-0	not assigned	—
4-1	not assigned	—
4-2	not assigned	—
4-3	251	Internal communication fault on the amplifier board.
4-4	261	No data reception between amplifier and I/O board

Byte Bit	Error No.	Short error description (→ Page 90 ff.)
4-5	not assigned	—
4-6	not assigned	—
4-7	not assigned	—
5-0	321	Coil current of the sensor is outside the tolerance.
5-1	not assigned	—
5-2	not assigned	—
5-3	not assigned	—
5-4	not assigned	—
5-5	not assigned	—
5-6	not assigned	—
5-7	339	Flow buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
6-0	340	
6-1	341	
6-2	342	
6-3	343	Frequency buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
6-4	344	
6-5	345	
6-6	346	
6-7	347	Pulse buffer: The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.
7-0	348	
7-1	349	
7-2	350	
7-3	351	Current output: flow is out of range.
7-4	352	
7-5	353	
7-6	354	
7-7	355	Frequency output: flow is out of range.
8-0	356	
8-1	357	
8-2	358	
8-3	359	Pulse output: the pulse output frequency is out of range.
8-4	360	
8-5	361	
8-6	362	
8-7	not assigned	—
9-0	not assigned	—
9-1	not assigned	—
9-2	not assigned	—
9-3	not assigned	—
9-4	not assigned	—
9-5	not assigned	—
9-6	not assigned	—
9-7	not assigned	—

Byte Bit	Error No.	Short error description (→ Page 90 ff.)
10-0	not assigned	--
10-1	not assigned	--
10-2	not assigned	--
10-3	not assigned	--
10-4	not assigned	--
10-5	not assigned	--
10-6	not assigned	--
10-7	401	Measuring tube partially filled or empty
11-0	not assigned	--
11-1	not assigned	--
11-2	461	EPD calibration not possible because the fluid's conductivity is either too low or too high.
11-3	not assigned	--
11-4	463	The EPD calibration values for empty pipe and full pipe are identical, therefore incorrect.
11-5	not assigned	--
11-6	not assigned	--
11-7	not assigned	--
12-0	not assigned	--
12-1	474	Maximum flow value entered is overshoot.
12-2	not assigned	--
12-3	not assigned	--
12-4	not assigned	--
12-5	not assigned	--
12-6	not assigned	--
12-7	501	New amplifier software version is loaded. Currently no other commands are possible.
13-0	502	Upload and download of device files. Currently no other commands are possible.
13-1	not assigned	--
13-2	not assigned	--
13-3	not assigned	--
13-4	not assigned	--
13-5	not assigned	--
13-6	not assigned	--
13-7	not assigned	--
14-0	not assigned	--
14-1	not assigned	--
14-2	not assigned	--
14-3	601	Positive zero return active
14-4	not assigned	--
14-5	not assigned	--
14-6	not assigned	--

Byte Bit	Error No.	Short error description (→ Page 90 ff.)
14-7	611	Simulation current output active
15-0	612	
15-1	613	
15-2	614	
15-3	621	Simulation frequency output active
15-4	622	
15-5	623	
15-6	624	
15-7	631	Simulation pulse output active
16-0	632	
16-1	633	
16-2	634	
16-3	641	Simulation status output active
16-4	642	
16-5	643	
16-6	644	
16-7	not assigned	—
17-0	not assigned	—
17-1	not assigned	—
17-2	not assigned	—
17-3	not assigned	—
17-4	not assigned	—
17-5	not assigned	—
17-6	not assigned	—
17-7	671	Simulation status input active
18-0	672	Simulation status input active
18-1	673	Simulation status input active
18-2	674	Simulation status input active
18-3	691	Simulation of response to error (outputs) active
18-4	692	Simulation of volume flow active
18-5	not assigned	—
18-6	not assigned	—
18-7	not assigned	—

6 Commissioning

6.1 Function check


Make sure that all final checks have been completed before you start up your measuring point:

- Checklist for "Installation check" → Page 46
- Checklist for "Electrical connection check" → Page 60

6.1.1 Switching on the measuring device

Once the connection checks (see Page 60) have been successfully completed, it is time to switch on the power supply. The device is now operational.

The measuring device performs a number of post switch-on self-tests. As this procedure progresses the following sequence of messages appears on the local display:



Normal measuring mode commences as soon as start-up completes. Various measured-value and/or status variables (HOME position) appear on the display.



Note!

If start-up fails, an error message indicating the cause is displayed.

6.2 Application-specific commissioning

In the case of measuring devices without a local display, the individual parameters and functions must be configured via the configuration program, e.g. ToF Tool - Fieldtool Package. If the measuring device is equipped with a local display, all the important device parameters for standard operation can be configured quickly and easily by means of the "Commissioning" Quick Setup menu.

■ Quick Setup "Commissioning", → Page 3 ff.

6.2.1 "Commissioning" Quick Setup menu

This Quick Setup menu guides you systematically through the setup procedure for all the major device functions that have to be configured for standard measuring operation.

Note!

In the case of measuring devices **without** a local display, the individual parameters and functions must be configured by means of a configuration program, such as ToF Tool - Fieldtool Package from Endress+Hauser.




Fig. 46: Quick Setup for commissioning

F06-50XXXXXX-19-xx-xx-en-000

6.2.2 Empty-pipe/full-pipe adjustment

Flow cannot be measured correctly unless the measuring tube is completely full. This status can be permanently monitored using the Empty Pipe Detection:

- EPD = Empty Pipe Detection (with the help of an EPD electrode)
- OED = Open Electrode Detection (Empty Pipe Detection with the help of the measuring electrodes, if the sensor is not equipped with an EPD electrode or the orientation is not suitable for using EPD).



Caution!

A detailed description and other helpful hints for the empty-pipe/full-pipe adjustment procedure can be found in the separate "Description of Device Functions" Manual:

- EPD/OED ADJUSTMENT → Carrying out the adjustment.
- EPD → Switching on and off EPD/OED.
- EPD RESPONSE TIME → Input of the response time for EPD/OED.



Note!

- The EPD function is not available unless the sensor is fitted with an EPD electrode.
- The devices are already calibrated at the factory with water (approx. 500 $\mu\text{S}/\text{cm}$).
If the fluid conductivity differs from this reference, empty-pipe/full-pipe adjustment has to be performed again on site.
- The default setting for EPD/OED when the devices are delivered is OFF; the function has to be activated if required.
- The EPD/OED process error can be output by means of the configurable status output.

Performing empty-pipe and full-pipe adjustment (EPD/OED)

1. Select the appropriate function in the function matrix:
HOME → → → PROCESS PARAMETER → → → EPD/OED ADJUSTMENT
2. Empty the piping. In case of an EPD adjustment, the wall of the measuring tube should be wetted with fluid for the adjustment procedure but this is not the case with an OED adjustment.
3. Start empty-pipe adjustment: Select "EMPTY PIPE ADJUST" or "OED EMPTY ADJUST" and press to confirm.
4. After empty-pipe adjustment, fill the piping with fluid.
5. Start full-pipe adjustment: Select "FULL PIPE ADJUST" or "OED FULL ADJUST" and press to confirm.
6. Having completed the adjustment, select the setting "OFF" and exit the function by pressing .
7. Now select the "EPD" function. Switch on Empty Pipe Detection by selecting the following settings:
 - EPD → Select ON STANDARD or ON SPECIAL and press to confirm.
 - OED → Select OED and confirm with .



Caution!

The adjustment coefficients must be valid before you can activate the EPD/OED function. If adjustment is incorrect the following messages might appear on the display:

- FULL = EMPTY

The adjustment values for empty pipe and full pipe are identical. In cases of this nature you **must** repeat empty-pipe or full-pipe adjustment!

- ADJUSTMENT NOT OK

Adjustment is not possible because the fluid's conductivity is out of range.

6.2.3 Current output: active/passive

The current output is configured as “active” or “passive” by means of various jumpers on the I/O board.



Warning!

- Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Wait at least 10 minutes for heat to dissipate before opening an Ex-rated device.


1. Switch off power supply.
2. Remove the I/O board → Page 98, 100
3. Position the jumper according to Fig. 47.



Caution!

Risk of destroying the measuring device. Set the jumpers exactly as shown in Fig. 47. Incorrectly set jumpers can cause overcurrents that would destroy either the measuring device or external devices connected to it.

4. Installation of the I/O board is the reverse of the removal procedure.



A0001044

Fig. 47: Configuring the current output (I/O board)

- 1 Active current output (Factory setting)
- 2 Passive current output

6.3 Data storage device (HistoROM)

At Endress+Hauser, the term HistoROM refers to various types of data storage modules on which process and measuring device data are stored.

6.3.1 HistoROM/S-DAT (sensor-DAT)

The S-DAT is an exchangeable data storage device in which all sensor relevant parameters are stored, i.e., diameter, serial number, calibration factor, zero point.

7 Maintenance

The Promag 50 flow measuring system requires no special maintenance.

7.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing and the seals.

7.2 Seals

The seals of the Promag H sensor must be replaced periodically, particularly in the case of gasket seals (aseptic version). The period between changes depends on the frequency of cleaning cycles, the cleaning temperature and the fluid temperature.

Replacement seals (accessories) → Page 85.

8 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor. The Endress+Hauser service organisation can provide detailed information on the order codes of your choice.

8.1 Device-specific accessories

Accessory	Description	Order code
Transmitter Promag 50	Transmitter for replacement or for stock. Use the order code to define the following specifications: <ul style="list-style-type: none"> – Approvals – Degree of protection / version – Cable type for the remote version – Cable entries – Display / power supply / operation – Software – Outputs / inputs 	50XXX – XXXXX * * * * *

8.2 Measuring principle-specific accessories

Accessory	Description	Order code
Mounting kit for transmitter Promag 50/53	Mounting kit for wall-mounted housing (remote version). Suitable for: <ul style="list-style-type: none"> – Wall mounting – Post mounting – Installation in control panel Mounting set for aluminium housings. Suitable for pipe mounting (3/4" ... 32")	DK5WM – *
Cable for remote version	Coil and signal cables, various lengths. Reinforced cable on request.	DK5CA – **
Ground cable for Promag W, P	A set consists of two ground cables.	DK5GC – ***
Ground disk for Promag W, P	Ground disk for potential equalisation	DK5GD – ***
Mounting kit for Promag H	Mounting kit for Promag H, comprising: <ul style="list-style-type: none"> – 2 process connections – Threaded fasteners – Seals 	DKH ** – ***
Adapter connection for Promag A, H	Adapter connections for installing Promag 50 H instead of Promag 30/33 A or Promag 30/33 H DN 25.	DK5HA – *****
Ground rings for Promag H	If the process connections are made of PVC or PVDF, ground rings are necessary to ensure that potential is matched. Set of ground rings, comprising: <ul style="list-style-type: none"> – 2 ground rings 	DK5HR – ***
Set of seals for Promag H	For regular replacement of the seals of the Promag H sensor.	DK5HS – ***
Wall-mounting kit for Promag H	Wall-mounting kit for the Promag H sensor	DK5HM – **
Welding jig for Promag H	Weld nipple as process connection: welding jig for installation in pipe.	DK5HW – ***

8.3 Communication-specific accessories

Accessory	Description	Order code
HART Communicator DXR 375 hand-held terminal	Hand-held terminal for remote parameterisation and for fetching measured values via the current output HART (4...20 mA). Contact your Endress+Hauser representative for more information.	DXR375 – * * * *


8.4 Communication-specific accessories

Accessory	Description	Order code
Applicator	Software for selecting and configuring flowmeters. Applicator can be downloaded from the Internet or ordered on CD-ROM for installation on a local PC. Contact your Endress+Hauser representative for more information.	DKA80 – *
ToF Tool – Fieldtool Package	Modular software package consisting of the service program "ToF Tool" for configuration and diagnosis of ToF level measuring devices (time-of-flight measurement) and the "Fieldtool" service program for the configuration and diagnosis of Proline flow measuring devices. The Proline flow measuring devices are accessed via a service interface or via the service interface FXA 193. Contents of the "ToF Tool – Fieldtool Package": – Commissioning, maintenance analysis – Configuring flowmeters – Service functions – Visualisation of process data – Trouble-shooting – Controlling the "Fieldcheck" tester/simulator Contact your Endress+Hauser representative for more information.	DXS10 – * * * *
Fieldcheck	Tester/simulator for testing flowmeters in the field. When used in conjunction with the "ToF Tool – Fieldtool Package" software package, test results can be imported into a database, printed and used for official certification. Contact your Endress+Hauser representative for more information.	DXC10 – * *




9 Trouble-shooting

9.1 Trouble-shooting instructions

Always start trouble-shooting with the checklist below, if faults occur after start-up or during operation. The routine takes you directly to the cause of the problem and the appropriate remedial measures.

Check the display	
No display visible and no output signals present.	<ol style="list-style-type: none"> 1. Check the power supply → terminals 1, 2 2. Check the power line fuse → Page 102 85...260 V AC: 0.8 A slow-blow / 250 V 20...55 V AC and 16...62 V DC: 2 A slow-blow / 250 V 3. Measuring electronics defective → order spare parts → Page 97
No display visible, but output signals are present.	<ol style="list-style-type: none"> 1. Check whether the ribbon-cable connector of the display module is correctly plugged into the amplifier board → Page 99, 101 2. Display module defective → order spare parts → Page 97 3. Measuring electronics defective → order spare parts → Page 97
Display texts are in a foreign language.	Switch off power supply. Press and hold down both the  buttons and switch on the measuring device. The display text will appear in English (default) and is displayed at maximum contrast.
Measured value indicated, but no signal at the current or pulse output	Measuring electronics defective → order spare parts → Page 97



Error messages on display	
<p>Errors which occur during commissioning or measuring operation are displayed immediately. Error messages consist of a variety of icons: the meanings of these icons are as follows (example):</p> <ul style="list-style-type: none"> – Error type: S = system error, P = process error – Error message type:  = fault message,  = notice message – EMPTY PIPE = Type of error, e.g. measuring tube is only partly filled or completely empty – 03:00:05 = duration of error occurrence (in hours, minutes and seconds) – # 401 = error number <p> Caution!!</p> <ul style="list-style-type: none"> ■ See the information on Page 64! ■ The measuring system interprets simulations and positive zero return as system errors, but displays them as notice message only. 	
Error number: No. 001 – 399 No. 501 – 699	System error (device error) has occurred → Page 90
Error number: No. 401 – 499	Process error (application error) has occurred → Page 93



Other error (without error message)	
Some other error has occurred.	Diagnosis and rectification → Page 94

9.2 System error messages

Serious system errors are **always** recognised by the instrument as "Fault message", and are shown as a lightning flash (⚡) on the display. Fault messages immediately affect the inputs and outputs. Simulations and positive zero return, on the other hand, are classed and displayed as notice messages.




Caution!


In the event of a serious fault, a flowmeter might have to be returned to the manufacturer for repair. The procedures on Page 8 must be carried out before you return a flowmeter to Endress+Hauser. Always enclose a duly completed "Declaration of contamination" form. You will find a preprinted blank of this form at the back of this manual.




Note!

The listed error message types below correspond to the factory setting. Also observe the information on Page 64 and 95.

No.	Error message / Type	Cause	Remedy / spare part
S = System error ⚡ = Fault message (<i>with</i> an effect on the outputs) ! = Notice message (<i>without</i> an effect on the outputs)			
No. # 0xx → Hardware error			
001	S: CRITICAL FAILURE ⚡: # 001	Serious device error	Replace the amplifier board. Spare parts → Page 97
011	S: AMP HW EEPROM ⚡: # 011	Amplifier: Defective EEPROM	Replace the amplifier board. Spare parts → Page 97
012	S: AMP SW EEPROM ⚡: # 012	Amplifier: Error accessing EEPROM data	The EEPROM data blocks in which an error has occurred are displayed in the "TROUBLESHOOTING" function. Press Enter to acknowledge the errors in question; default values are automatically inserted instead of the errored parameter values.  Note! The measuring device has to be restarted if an error has occurred in a totalizer block (see error No. 111 / CHECKSUM TOTAL).
031	S: SENSOR HW DAT ⚡: # 031	Sensor DAT: 1. S-DAT is defective. 2. S-DAT is not plugged into the amplifier board or is missing.	1. Replace the S-DAT. Spare parts → Page 97 Check the spare part set number to ensure that the new, replacement DAT is compatible with the measuring electronics. 2. Plug the S-DAT into the amplifier board → Page 99, 101
032	S: SENSOR SW DAT ⚡: # 032	Sensor: Error accessing the calibration values stored in the S-DAT.	1. Check whether the S-DAT is correctly plugged into the amplifier board → Page 99, 101 2. Replace the S-DAT if it is defective. Spare parts → Page 97. Before replacing the DAT, check that the new, replacement DAT is compatible with the measuring electronics. Check the: – Spare part set number – Hardware revision code 3. Replace measuring electronics boards if necessary. Spare parts → Page 97

No.	Error message / Type	Cause	Remedy / spare part
No. # 1xx → Software error			
101	S: GAIN ERROR AMP f: # 101	Gain deviation compared to reference gain is greater than 2%.	Replace amplifier board. Spare parts → Page 97
111	S: CHECKSUM TOTAL f: # 111	Totalizer checksum error	1. Restart the measuring device 2. Replace the amplifier board if necessary. Spare parts → Page 97
121	S: A / C COMPATIB. l: # 121	Due to different software versions, I/O board and amplifier board are only partially compatible (possibly restricted functionality).  Note! – The indication on the display as notice message appears only for 30 seconds (with listing in “Previous system condition” function). – This condition can occur if only one electronics board has been exchanged; the extended software functionality is not available. The previously existing software functionality is still working and the measurement possible.	Module with lower software version has either to be actualized by FieldTool with the required software version or the module has to be replaced. Spare parts → Page 97
No. # 2xx → Error in DAT / no communication			
251	S: COMMUNICATION I/O f: # 251	Internal communication error on the amplifier board.	Remove the amplifier board. Spare parts → Page 97
261	S: COMMUNICATION I/O f: # 261	No data reception between amplifier and I/O board or faulty internal data transfer.	Check the BUS contacts
No. # 3xx → System limits exceeded			
321	S: TOL. COIL CURR. f: # 321	Sensor: Coil current is out of tolerance.	1. Remote version: Switch off the power supply before connecting or disconnecting the cable of the coil (terminals 41/42). 2. Remote version: Switch off power supply and check wiring of terminals 41/42 → Page 47 ff. 3. Switch off the power supply and check the connectors of the coil cable → Page 99, 101 4. Replace measuring electronics boards if necessary. Spare parts → Page 97
339 ... 342	S: STACK CUR OUT n l: # 339...342	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.	1. Change the upper or lower limit setting, as applicable. 2. Increase or reduce flow, as applicable. Recommendations in the event of fault category = FAULT MESSAGE (f): – Configure the fault response of the output to “ACTUAL VALUE” (see Page 95), so that the temporary buffer can be cleared. – Clear the temporary buffer by the measures described under Item 1.
343 ... 346	S: STACK FREQ. OUT n l: # 343...346		
347 ... 350	S: STACK PULSE OUT n l: # 347...350	The temporarily buffered flow portions (measuring mode for pulsating flow) could not be cleared or output within 60 seconds.	1. Increase the setting for pulse weighting 2. Increase the max. pulse frequency, if the totalizer can handle a higher number of pulses. 3. Reduce flow Recommendations in the event of fault category = FAULT MESSAGE (f): – Configure the fault response of the output to “ACTUAL VALUE” (see Page 95), so that the temporary buffer can be cleared. – Clear the temporary buffer by the measures described under Item 1.

No.	Error message / Type	Cause	Remedy / spare part
351 ... 354	S: CURRENT RANGE n ! : # 351...354	Current output: Flow is out of range.	1. Change the upper or lower limit setting, as applicable. 2. Increase or reduce flow, as applicable.
355 ... 358	S: FREQ. RANGE n ! : # 355...358	Frequency output: Flow is out of range.	1. Change the upper or lower limit setting, as applicable. 2. Increase or reduce flow, as applicable.
359 ... 362	S: PULSE RANGE n ! : # 359...362	Pulse output: Pulse output frequency is out of range.	1. Increase the setting for pulse weighting 2. When selecting the pulse width, choose a value that can still be processed by a connected counter (e.g. mechanical counter, PLC etc.). <i>Determine the pulse width:</i> – Variant 1: Enter the minimum duration that a pulse must be present at the connected counter to ensure its registration. – Variant 2: Enter the maximum (pulse) frequency as the half "reciprocal value" that a pulse must be present at the connected counter to ensure its registration. Example: The maximum input frequency of the connected counter is 10 Hz. The pulse width to be entered is: $\frac{1}{2 \cdot 10 \text{ Hz}} = 50 \text{ ms}$ 3. Reduce flow.
No. # 5xx → Application error			
501	S: SW-UPDATE ACT. ! : # 501	New amplifier or communication (I/O module) software version is loaded. Currently no other functions are possible.	Wait until the procedure is finished. The device will restart automatically.
502	S: UP-/DOWNLOAD ACT ! : # 502	Up- or downloading the device data via configuration program. Currently no other functions are possible.	Wait until the procedure is finished.
No. # 6xx → Simulation mode active			
601	S: POS. ZERO-RETURN ! : # 601	Positive zero return active  Caution!! This message has the highest display priority!	Switch off positive zero return
611 ... 614	S: SIM. CURR. OUT. n ! : # 611...614	Simulation current output active	Switch off simulation
621 ... 624	S: SIM. FREQ. OUT. n ! : # 621...624	Simulation frequency output active	Switch off simulation
631 ... 634	S: SIM. PULSE n ! : # 631...634	Simulation pulse output active	Switch off simulation
641 ... 644	S: SIM. STAT. OUT n ! : # 641...644	Simulation status output active	Switch off simulation
671 ... 674	S: SIM. STATUS IN ! : # 671...674	Simulation status input active	Switch off simulation

No.	Error message / Type	Cause	Remedy / spare part
691	S: SIM. FAILSAFE !: # 691	Simulation of response to error (outputs) active	Switch off simulation
692	S: SIM. VOL. FLOW !: # 692	Simulation of volume flow active	Switch off simulation
698	S: DEV. TEST ACT. !: # 698	The measuring device is being checked on site via the test and simulation device.	—

9.3 Process error messages

Process errors can be defined as either “Fault” or “Notice” messages and can thereby be weighted differently. Determination of this is done via the function matrix (see the “Description of Device Functions” Manual).



Note!

The error types listed in the following correspond to the factory settings.
Also observe the information on Page 64 ff. and 95.

No.	Error message / Type	Cause	Remedy
P = Process error ⚡ = Fault message (<i>with</i> an effect on the outputs) ! = Notice message (<i>without</i> an effect on the outputs)			
401	EMPTY PIPE ⚡: # 401	Measuring tube partially filled or empty	1. Check the process conditions of the plant 2. Fill the measuring tube
461	ADJ. NOT OK !: # 461	EPD/OED calibration not possible because the fluid's conductivity is either too low or too high.	The EPD/OED function cannot be used with fluids of this nature.
463	FULL = EMPTY ⚡: # 463	The EPD/OED calibration values for empty pipe and full pipe are identical, therefore incorrect.	Repeat calibration, making sure procedure is correct → Page 81

9.4 Process errors without messages

Symptoms	Rectification
<p>Remark: You may have to change or correct certain settings in functions in the function matrix in order to rectify the fault. The functions outlined below, such as DISPLAY DAMPING, for example, are described in detail in the "Description of Device Functions" manual.</p>	
Flow values are negative, even though the fluid is flowing forwards through the pipe.	<ol style="list-style-type: none"> Remote version: <ul style="list-style-type: none"> Switch off the power supply and check the wiring → Page 47 ff. If necessary, reverse the connections at terminals 41 and 42 Change the setting in the "INSTALLATION DIRECTION SENSOR" function accordingly
Measured-value reading fluctuates even though flow is steady.	<ol style="list-style-type: none"> Check grounding and potential equalization → Page 56 ff. Check the fluid for presence of gas bubbles. In the "TIME CONSTANT" function (current output) → increase the value In the "DISPLAY DAMPING" function → increase the value
Measured-value reading shown on display, even though the fluid is at a standstill and the measuring tube is full.	<ol style="list-style-type: none"> Check grounding and potential equalization → Page 56 ff. Check the fluid for presence of gas bubbles. Activate the "LOW FLOW CUTOFF" function, i.e. enter or increase the value for the switching point.
Measured-value reading on display, even though measuring tube is empty.	<ol style="list-style-type: none"> Perform empty-pipe/full-pipe adjustment and then switch on Empty Pipe detection → Page 81 Remote version: Check the terminals of the EPD cable → Page 47 ff. Fill the measuring tube.
The current output signal is always 4 mA, irrespective of the flow signal at any given time.	<ol style="list-style-type: none"> Select the "BUS ADDRESS" function and change the setting to "0". Value for creepage too high. Reduce corresponding value in the "Low flow cutoff" functions (ON-/OFF-VALUE).
<p>The fault cannot be rectified or some other fault not described above has arisen.</p> <p>In these instances, please contact your Endress+Hauser service organization.</p>	<p>The following options are available for tackling problems of this nature:</p> <p>Request the services of an Endress+Hauser service technician If you contact our service organization to have a service technician sent out, please be ready to quote the following information:</p> <ul style="list-style-type: none"> Brief description of the fault Nameplate specifications (Page 9 ff.): order code, serial number <p>Returning devices to Endress+Hauser The procedures on Page 8 must be carried out before you return a flowmeter requiring repair or calibration to Endress+Hauser. Always enclose a duly completed "Declaration of Conformity" form with the flowmeter. You will find a preprinted form at the back of this manual.</p> <p>Replace transmitter electronics Components in the measuring electronics defective → order spare parts → Page 97</p>

9.5 Response of outputs to errors




Note!

The failsafe mode of totalizers, current, pulse and frequency outputs can be customized by means of various functions in the function matrix. You will find detailed information on these procedures in the "Description of Device Functions" manual.

Positive zero return and failsafe mode:

You can use positive zero return to set the signals of the current, pulse and frequency outputs to their fallback value, for example when measuring has to be interrupted while a pipe is being cleaned.

This function takes priority over all other device functions: simulations, for example, are suppressed.

Failsafe mode of outputs and totalizers		
	Process/system error is current	Positive zero return is activated
 Caution!! System or process errors defined as "Notice messages" have no effect whatsoever on the inputs and outputs. See the information on Page 64 ff.		
Current output	<p>MINIMUM CURRENT The current output will be set to the lower value of the signal on alarm level depending on the setting selected in the CURRENT SPAN (see the "Description of Device Functions" manual).</p> <p>MAXIMUM CURRENT The current output will be set to the higher value of the signal on alarm level depending on the setting selected in the CURRENT SPAN (see the "Description of Device Functions" manual).</p> <p>HOLD VALUE Measured value display on the basis of the last saved value preceding occurrence of the fault.</p> <p>ACTUAL VALUE Measured value display on the basis of the current flow measurement. The fault is ignored.</p>	Output signal corresponds to "zero flow"
Pulse output	<p>FALLBACK VALUE Signal output → no pulses</p> <p>ACTUAL VALUE Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.</p>	Output signal corresponds to "zero flow"

Failsafe mode of outputs and totalizers		
	Process/system error is current	Positive zero return is activated
Frequency output	<p><i>FALLBACK VALUE</i> Signal output → 0 Hz</p> <p><i>FAILSAFE LEVEL</i> Output of the frequency specified in the FAILSAFE VALUE function.</p> <p><i>HOLD VALUE</i> Last valid value (preceding occurrence of the fault) is output.</p> <p><i>ACTUAL VALUE</i> Fault is ignored, i.e. normal measured-value output on the basis of ongoing flow measurement.</p>	Output signal corresponds to "zero flow"
Totalizer	<p><i>STOP</i> The totalizers are paused until the error is rectified.</p> <p><i>ACTUAL VALUE</i> The fault is ignored. The totalizers continue to count in accordance with the current flow value.</p> <p><i>HOLD VALUE</i> The totalizers continue to count the flow in accordance with the last valid flow value (before the error occurred).</p>	Totalizer stops
Status output	In the event of a fault or power supply failure: Status output → non-conductive	No effect on status output

9.6 Spare parts

Chap. 9.1 contains a detailed trouble-shooting guide. The measuring device, moreover, provides additional support in the form of continuous self-diagnosis and error messages. Fault rectification can entail replacing defective components with tested spare parts. The illustration below shows the available scope of spare parts.




Note!

You can order spare parts directly from your Endress+Hauser service organisation by providing the serial number printed on the transmitter's nameplate (Page 9 ff.).

Spare parts are shipped as sets comprising the following parts:

- Spare part
- Additional parts, small items (threaded fasteners, etc.)
- Mounting instructions
- Packaging



F06-50xxxxxx-03-06-06-xx-000

Fig. 48: Spare parts for Promag 50 transmitter (field and wall-mounted housings)

- 1 Power supply board (85...260 V AC, 20...55 V AC, 16...62 V DC)
- 2 Amplifier board
- 3 I/O board
- 4 S-DAT (sensor data memory)
- 5 Display module

9.7 Removing and installing printed circuit boards

Field housing: removing and installing printed circuit boards (Fig. 49)



Warning!


- Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface purpose-built for electrostatically sensitive devices!
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.
- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.

1. Unscrew cover of the electronics compartment from the transmitter housing.
2. Remove the local display (1) as follows:
 - Press in the latches (1.1) at the side and remove the display module.
 - Disconnect the ribbon cable (1.2) of the display module from the amplifier board.
3. Remove the screws and remove the cover (2) from the electronics compartment.
4. Remove power supply board and I/O board (4, 6):
Insert a suitable tool into the holes (3) provided for the purpose and pull the board clear of its holder.
5. Remove amplifier board (5):
 - Disconnect the plug of the electrode signal cable (5.1) including S-DAT (5.3) from the board.
 - Loosen the plug locking of the coil current cable (5.2) and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Insert a thin pin into the hole (3) provided for the purpose and pull the board clear of its holder.
6. Installation is the reverse of the removal procedure.



Caution!

Use only original Endress+Hauser parts.



A0002657

Fig. 49: Field housing: removing and installing printed circuit boards

- 1 Local display
- 1.1 Latch
- 1.2 Ribbon cable (display module)
- 2 Screws of electronics compartment cover
- 3 Aperture for tool, removal/installation
- 4 Power supply board
- 5 Amplifier board
- 5.1 Electrode signal cable (sensor)
- 5.2 Coil current cable (sensor)
- 5.3 S-DAT (sensor data memory)
- 6 I/O board


Wall-mounted housing: removing and installing printed circuit boards (Fig. 50)**Warning!**

- Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.
- Risk of damaging electronic components (ESD protection). Static electricity can damage electronic components or impair their operability. Use a workplace with a grounded working surface, purpose-built for electrostatically sensitive devices.
- If you cannot guarantee that the dielectric strength of the device is maintained in the following steps, then an appropriate inspection must be carried out in accordance with the manufacturer's specifications.
- When connecting Ex-certified devices, see the notes and diagrams in the Ex-specific supplement to these Operating Instructions.

1. Remove the screws and open the hinged cover (1) of the housing.
2. Remove screws of the electronics module (2). Then push up electronics module and pull it as far as possible out of the wall-mounted housing.
3. Disconnect the following cable plugs from amplifier board (7):
 - Electrode signal cable plug (7.1) including S-DAT (7.3)
 - Plug of coil current cable (7.2). To do so, loosen the plug locking of the coil current cable and gently disconnect the plug from the board, i.e. without moving it to and fro.
 - Ribbon cable plug (3) of the display module
4. Remove the screws and remove the cover (4) from the electronics compartment.
5. Remove the boards (6, 7, 8):
Insert a suitable tool into the hole (5) provided for the purpose and pull the board clear of its holder.
6. Installation is the reverse of the removal procedure.

**Caution!**

Use only original Endress+Hauser parts.



F06-50xxxxxx-03-03-06-xx-000

Fig. 50: Wall-mounted housing: removing and installing printed circuit boards

- 1 Housing cover
- 2 Electronics module
- 3 Ribbon cable (display module)
- 4 Cover of electronics compartment (3 screws)
- 5 Aperture for tool, removal/installation
- 6 Power supply board
- 7 Amplifier board
- 7.1 Electrode signal cable (sensor)
- 7.2 Coil current cable (sensor)
- 7.3 S-DAT (sensor data memory)
- 8 I/O board

9.8 Replacing the device fuse



Warning!

Risk of electric shock. Exposed components carry dangerous voltages. Make sure that the power supply is switched off before you remove the cover of the electronics compartment.

The main fuse is on the power supply board (Fig. 51).


The procedure for replacing the fuse is as follows:

1. Switch off power supply.
2. Remove the power supply board → Page 98, 100
3. Remove cap (1) and replace the device fuse (2).
Use only fuses of the following type:
 - Power supply 20...55 V AC / 16...62 V DC → 2.0 A slow-blow / 250 V; 5.2 x 20 mm
 - Power supply 85...260 V AC → 0.8 A slow-blow / 250 V; 5.2 x 20 mm
 - Ex-rated devices → see the Ex documentation.
4. Assembly is the reverse of the disassembly procedure.



Caution!

Use only original Endress+Hauser parts.



A0001148

Fig. 51: Replacing the device fuse on the power supply board

- 1 Protective cap
- 2 Device fuse

9.9 Replacing exchangeable measuring electrodes

The Promag W sensor (DN 350...2000) is available with exchangeable measuring electrodes as an option. This design permits the measuring electrodes to be replaced or cleaned under process conditions (see Page 104).









Fig. 52: Apparatus for replacing exchangeable measuring electrodes (Replacing → Page 104)

- a Allen screw
- b Handle
- c Electrode cable
- d Knurled nut (locknut)
- e Measuring electrode
- f Stop cock
- g Retaining cylinder
- h Locking pin (for handle)
- i Ball-valve housing
- j Seal (retaining cylinder)
- k Coil spring

Removing the electrode	Installing the electrode
1 Loosen Allen screw (a) and remove the cover.	1 Insert new electrode (e) into retaining cylinder (g) from below. Make sure that the seals at the tip of the electrode are clean.
2 Remove electrode cable (c) secured to handle (b).	2 Mount handle (b) on the electrode and insert locking pin (h) to secure it in position.  Caution!! Make sure that coil spring (k) is inserted. This is essential to ensure correct electrical contact and correct measuring signals.
2 Loosen knurled nut (d) by hand. This knurled nut acts as a locknut.	2 Pull the electrode back until the tip of the electrode no longer protrudes from retaining cylinder (g).
3 Remove electrode (e) by turning handle (b). The electrode can now be pulled out of retaining cylinder (g) as far as a defined stop.  Warnung! Risk of injury. Under process conditions (pressure in the piping system) the electrode can recoil suddenly against its stop. Apply counter-pressure while releasing the electrode.	3 Screw the retaining cylinder (g) onto ball-valve housing (i) and tighten it by hand. Seal (j) on the cylinder must be correctly seated and clean.  Note! Make sure that the rubber hoses on retaining cylinder (g) and stop cock (f) are of the same color (red or blue).
4 Close stop cock (f) after pulling out the electrode as far as it will go.  Warnung! Do not subsequently open the stop cock, in order to prevent fluid escaping.	4 Open stop cock (f) and turn handle (b) to screw the electrode all the way into the retaining cylinder.
5 Remove the electrode complete with retaining cylinder (g).	5 Screw knurled nut (d) onto the retaining cylinder. This firmly locates the electrode in position.
6 Remove handle (b) from electrode (e) by pressing out locking pin (h). Take care not to lose coil spring (k).	6 Use the Allen screw to secure electrode cable (c) to handle (b).  Caution!! Make sure that the machine screw securing the electrode cable is firmly tightened. This is essential to ensure correct electrical contact and correct measuring signals.
7 Remove the old electrode and insert the new electrode. Replacement electrodes can be ordered separately from Endress+Hauser.	7 Reinstall the cover and tighten (a) Allen screw.

9.10 Software history

Date	Software version	Changes to software	Operating Instructions
03.2005	2.00.XX	Software expansion: – New / revised functionalities New functionalities: – DEVICE SOFTWARE → Device software displayed (NAMUR-recommendation 53) – Unit US Kgal	50097090/03.05
11.2004	Amplifier: 1.06.01 Communication module: 1.04.00	Software update relevant only for production	50097090/10.03
10.2003	Amplifier: 1.06.00 Communication module: 1.03.00	Software expansion: – Language groups – Flow direction pulse output selectable New functionalities: – Second Totalizer – Adjustable backlight (display) – Operation hours counter – Simulation function for pulse output – Access code for counter – Reset function (fault history) – Up-/download with FieldTool	50097090/10.03
08.2003	Communication module: 1.02.01	Software expansion: – New / revised functionalities Special documentation: – Current span NAMUR NE 43 – Failsafe mode function – Trouble-shooting function – System and process error messages – Response of status output	50097090/08.03
08.2002	Amplifier: 1.04.00	Software expansion: – New / revised functionalities Special documentation: – Current span NAMUR NE 43 – EPD (new mode) – Failsafe mode function – Acknowledge fault function – Trouble-shooting function – System and process error messages – Response of status output	50097090/08.02
03.2002	Amplifier: 1.03.00	Software expansion: – Suitability for custody transfer measurement Promag 50/51	none
06.2001	Amplifier: 1.02.00 Communication module: 1.02.00	Software expansion: – New functionalities: New functionalities: – General instrument functions – “OED” software function – “Pulse width” software function	50097090/06.01

Date	Software version	Changes to software	Operating Instructions
09.2000	Amplifier: 1.01.01 Communication module: 1.01.00	Software expansion: – Functional adaptations	none
08.2000	Amplifier: 1.01.00	Software expansion: – Functional adaptations	none
04.2000	Amplifier: 1.00.00 Communication module: 1.00.00	Original software Compatible with: – FieldTool – Commuwin II (version 2.05.03 and higher) – HART Communicator DXR 275 (from OS 4.6) with Rev. 1, DD 1.	50097090/04.00

**Note!**

Usually, an upload or download between the different software versions is only possible with a special service software.

10 Technical data

10.1 Technical data at a glance

10.1.1 Application

Application

- Measuring the flow rate of fluids in closed piping systems.
- A minimum conductivity of $\geq 5 \mu\text{S}/\text{cm}$ is required for measuring; the minimum conductivity required in the case of demineralised water is $\geq 20 \mu\text{S}/\text{cm}$.
- Applications in measuring, control and regulation technology

Liner specific applications:

- Promag W (DN 25...2000):
 - Polyurethane lining for applications with cold water and for slightly abrasive fluids.
 - Hard rubber lining for all applications with water (especially for drinking water)
- Promag P (DN 15...600):
 - PTFE lining for standard applications in chemical and process industries.
 - PFA lining for all applications in chemical and process industries; especially for high process temperatures and applications with temperature shocks.
- Promag H (DN 2...100):
 - PFA lining for all applications in chemical, process and food industries; especially for high process temperatures, for applications with temperature shocks and for applications with CIP or SIP cleaning processes.

10.1.2 Function and system design

Measuring principle

Electromagnetic flow measurement on the basis of Faraday's Law.

Measuring system

The measuring system consists of a transmitter and a sensor.

Two versions are available:

- Compact version: transmitter and sensor form a single mechanical unit.
- Remote version: transmitter and sensor are installed separately.

Transmitter:

- Promag 50

Sensor:

- Promag W (DN 25...2000)
- Promag P (DN 15...600)
- Promag H (DN 2...100)

10.1.3 Input

Measured variable

Flow rate (proportional to induced voltage)

Measuring range

Typically $v = 0.01 \dots 10 \text{ m/s}$ with the specified measuring accuracy

Operable flow range

Over 1000 : 1

Input signals

Status input (auxiliary input):

$U = 3 \dots 30 \text{ V DC}$, $R_i = 5 \text{ k}\Omega$, galvanically isolated

Configurable for: totalizer reset, positive zero return

10.1.4 Output

Output signal	<p>Current output: active/passive selectable, galvanically isolated, time constant selectable (0.01...100 s), full scale value selectable, temperature coefficient: typically 0.005% o.f.s./ °C; resolution: 0.5 µA</p> <ul style="list-style-type: none"> ■ active: 0/4...20 mA, $R_L < 700 \Omega$ (for HART: $R_L \geq 250 \Omega$) ■ passive: 4...20 mA, supply voltage V_s: 18...30 V DC, $R_i \geq 150 \Omega$ <p>Pulse / frequency output: passive, open collector, 30 V DC, 250 mA, galvanically isolated</p> <ul style="list-style-type: none"> ■ Frequency output: full scale frequency 2...1000 Hz ($f_{max} = 1250$ Hz), on/off ratio 1:1, pulse width max. 10 s ■ Pulse output: pulse value and pulse polarity selectable, pulse width configurable (0.5...2000 ms)
Signal on alarm	<ul style="list-style-type: none"> ■ Current output → failsafe mode selectable (e.g. to NAMUR recommendation NE 43) ■ Pulse/frequency output → failsafe mode selectable ■ Status output → "non-conductive" by fault or power supply failure <p>Details → Page 95</p>
Load	see "output signal"
Switching output	<p>Status output: Open collector, max. 30 V DC / 250 mA, galvanically isolated Configurable for: error messages, Empty Pipe Detection (EPD/OED), flow direction, limit values</p>
Low flow cutoff	Switch points for low flow cutoff are selectable
Galvanic isolation	All circuits for inputs, outputs, and power supply are galvanically isolated from each other.

10.1.5 Power supply

Electrical connections	see Page 47 ff.
Cable entry	<p>Power-supply and signal cables (inputs/outputs):</p> <ul style="list-style-type: none"> ■ Cable entry M20 x 1.5 (8...12 mm) ■ Sensor cable entry for armoured cables M20 x 1.5 (9.5...16 mm) ■ Threads for cable entries 1/2" NPT, G 1/2" <p>Connecting cable for remote version:</p> <ul style="list-style-type: none"> ■ Cable entry M20 x 1.5 (8...12 mm) ■ Sensor cable entry for armoured cables M20 x 1.5 (9.5...16 mm) ■ Threads for cable entries 1/2" NPT, G 1/2"
Cable specifications	see Page 51
Supply voltage	<p>85...260 V AC, 45...65 Hz 20...55 V AC, 45...65 Hz 16...62 V DC</p>

Power consumption	AC: <15 VA (including sensor)
	DC: <15 W (including sensor)
	Switch-on current:
	■ max. 13.5 A (< 50 ms) at 24 V DC
	■ max. 3 A (< 5 ms) at 260 V AC
Power supply failure	Lasting min. 1 power cycle
	■ EEPROM saves measuring system data if power supply fails
	■ S-DAT: exchangeable data storage chip which stores the data of the sensor (nominal diameter, serial number, calibration factor, zero point, etc.)
Potential equalisation	see Page 56 ff.

10.1.6 Performance characteristics

Reference operating conditions	To DIN EN 29104 and VDI/VDE 2641:
	<ul style="list-style-type: none"> ■ Fluid temperature: $+28\text{ °C} \pm 2\text{ K}$ ■ Ambient temperature: $+22\text{ °C} \pm 2\text{ K}$ ■ Warm-up time: 30 minutes
	Installation:
	<ul style="list-style-type: none"> ■ Inlet run >10 x DN ■ Outlet run > 5 x DN ■ Sensor and transmitter grounded. ■ Sensor centered relative to the pipe.
Maximum measured error	Pulse output:
	<ul style="list-style-type: none"> ■ $\pm 0.5\%$ o.r. $\pm 1\text{ mm/s}$ (o.r. = of reading) ■ Option: $\pm 0.2\%$ o.r. $\pm 2\text{ mm/s}$ (o.r. = of reading)
	Current output: plus typically $\pm 5\text{ }\mu\text{A}$
	Supply-voltage fluctuations have no effect within the specified range.




Fig. 53: Max. measured error in % of reading

F06-5XXXXXX-05-xx-xx-xx-000



Repeatability	max. $\pm 0.1\%$ o.r. $\pm 0.5\text{ mm/s}$ (o.r. = of reading)
---------------	---

10.1.7 Operating conditions

Installation

Installation instructions	Any orientation (vertical, horizontal) Restrictions and additional installation instructions → see Page 15 ff.
Inlet and outlet runs	Inlet run: typically $\geq 5 \times \text{DN}$ Outlet run: typically $\geq 2 \times \text{DN}$
Length of connecting cable	For the remote version the permissible cable length L_{max} depends on the conductivity of the medium → Page 25. A minimum conductivity of $20 \mu\text{S}/\text{cm}$ is required for measuring demineralized water.

Environment

Ambient temperature	<p>Transmitter:</p> <ul style="list-style-type: none"> ■ Standard: $-20 \dots +60 \text{ }^{\circ}\text{C}$ ■ Optional: $-40 \dots +60 \text{ }^{\circ}\text{C}$ <p> Note! At ambient temperatures below $-20 \text{ }^{\circ}\text{C}$ the readability of the display may be impaired.</p> <p>Sensor:</p> <ul style="list-style-type: none"> ■ Flange material carbon steel: $-10 \dots +60 \text{ }^{\circ}\text{C}$ ■ Flange material stainless steel: $-40 \dots +60 \text{ }^{\circ}\text{C}$ <p> Caution! It is not allowed to use the device beyond the min. and max. lining specified temperature values (→ "Medium temperature range").</p> <p>Note the following points:</p> <ul style="list-style-type: none"> ■ Install the device at a shady location. Avoid direct sunlight, particularly in warm climatic regions. ■ If both fluid and ambient temperatures are high, install the transmitter at a remote location from the sensor (→ "Medium temperature range").
Storage temperature	The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.
Degree of protection	<ul style="list-style-type: none"> ■ Standard: IP 67 (NEMA 4X) for transmitter and sensor ■ Optional: IP 68 (NEMA 6P) for remote version of Promag W and P sensor
Shock and vibration resistance	Acceleration up to 2 g by analogy with IEC 60068-2-6 (high-temperature version: no data available)
CIP cleaning	Promag W: not possible Promag P: possible (note max. temperature) Promag H: possible (note max. temperature)
SIP cleaning	Promag W: not possible Promag P: possible with PFA (note max. temperature) Promag H: possible (note max. temperature)
Electromagnetic compatibility (EMC)	To EN 61326/A1 and NAMUR recommendation NE 21.

Process

Medium temperature range

The permissible fluid temperature depends on the lining of the measuring tube:

Promag W


0...+80 °C for hard rubber (DN 65...2000)

–20...+50 °C for polyurethane (DN 25...2000)

Promag P

–40...+130 °C for PTFE (DN 15...600), for restrictions → refer to diagrams

–20...+180 °C for PFA (DN 25...200), for restrictions → refer to diagrams




A0002660

Fig. 54: Compact version Promag P (with PFA or PTFE lining)

T_A = ambient temperature, T_F = fluid temperature, HT = high-temperature version, with insulation

① = Temperature range from –10 °C to –40 °C is valid for stainless steel flanges only



A0002671

Fig. 55: Remote version Promag P (with PFA or PTFE lining)

T_A = ambient temperature, T_F = fluid temperature, HT = high-temperature version, with insulation

① = Temperature range from –10 °C to –40 °C is valid for stainless steel flanges only

Promag H

Sensor:

- DN 2...25: -20...+150 °C
- DN 40...100: -20...+150 °C

Seal:

- EPDM: -20...+130 °C
- Silicone: -20...+150 °C
- Viton: -20...+150 °C
- Kalrez: -20...+150 °C

Conductivity

Minimum conductivity:

- $\geq 5 \mu\text{S/cm}$ for fluids generally
- $\geq 20 \mu\text{S/cm}$ for demineralised water

Note that in the case of the remote version, the requisite conductivity is also influenced by the length of the connecting cable → Page 25.

Limiting medium pressure range (nominal pressure)**Promag W**

- EN 1092-1 (DIN 2501): PN 6 (DN 1200...2000), PN 10 (DN 200...2000), PN 16 (DN 65...2000), PN 25 (DN 200...1000), PN 40 (DN 25...150)
- ANSI B16.5: Class 150 (1...24"), Class 300 (1...6")
- AWWA: Class D (28...78")
- JIS B2238: 10K (DN 50...300), 20K (DN 25...300)

Promag P

- EN 1092-1 (DIN 2501): PN 10 (DN 200...600), PN 16 (DN 65...600), PN 25 (DN 200...600), PN 40 (DN 15...150)
- ANSI B16.5: Class 150 (1/2...24"), Class 300 (1/2...6")
- JIS B2238: 10K (DN 50...300), 20K (DN 15...300)

Promag H:

The permissible nominal pressure depends on the process connection and seal:

- 40 bar: flange, weld nipple (with O-ring seal)
- 16 bar: all other process connections

Pressure tightness
(liner)

Promag W Nominal diameter		Measuring tube lining	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] at various fluid temperatures						
[mm]	[inch]		25 °C	50 °C	80 °C	100 °C	130 °C	150 °C	180 °C
25...1000	1...40"	Polyurethane	0	0	–	–	–	–	–
65...2000	3...78"	Hard rubber	0	0	0	–	–	–	–

Promag P Nominal diameter		Measuring tube lining	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] at various fluid temperatures					
[mm]	[inch]		25 °C	80 °C	100 °C	130 °C	150 °C	180 °C
15	1/2"	PTFE	0	0	0	100	–	–
25	1"	PTFE / PFA	0 / 0	0 / 0	0 / 0	100 / 0	– / 0	– / 0
32	–	PTFE / PFA	0 / 0	0 / 0	0 / 0	100 / 0	– / 0	– / 0
40	1 1/2"	PTFE / PFA	0 / 0	0 / 0	0 / 0	100 / 0	– / 0	– / 0
50	2"	PTFE / PFA	0 / 0	0 / 0	0 / 0	100 / 0	– / 0	– / 0
65	–	PTFE / PFA	0 / 0	*	40 / 0	130 / 0	– / 0	– / 0
80	3"	PTFE / PFA	0 / 0	*	40 / 0	130 / 0	– / 0	– / 0
100	4"	PTFE / PFA	0 / 0	*	135 / 0	170 / 0	– / 0	– / 0
125	–	PTFE / PFA	135 / 0	*	240 / 0	385 / 0	– / 0	– / 0
150	6"	PTFE / PFA	135 / 0	*	240 / 0	385 / 0	– / 0	– / 0
200	8"	PTFE / PFA	200 / 0	*	290 / 0	410 / 0	– / 0	– / 0
250	10"	PTFE	330	*	400	530	–	–
300	12"	PTFE	400	*	500	630	–	–
350	14"	PTFE	470	*	600	730	–	–
400	16"	PTFE	540	*	670	800	–	–
450	18"	PTFE	Partial vacuum is impermissible					
500	20"	PTFE						
600	24"	PTFE						
* No value can be quoted.								

Promag H Nominal diameter		Measuring tube lining	Resistance of measuring tube lining to partial vacuum Limit values for abs. pressure [mbar] at various fluid temperatures						
[mm]	[inch]		25 °C	80 °C	100 °C	130 °C	150 °C	180 °C	
2...100	1/12...4"	PFA	0	0	0	0	0	0	

Limiting flow

see Page 20

Pressure loss

- No pressure loss if the sensor is installed in a pipe of the same nominal diameter (Promag H: only DN 8 and larger).
- Pressure losses for configurations incorporating adapters according to DIN EN 545 → Page 20

10.1.8 Mechanical construction

Design / dimensions

All the dimensions and lengths of the sensor and transmitter are provided in the separate documentation "Technical Information".

Weight

Weight data of Promag W in kg										
Nominal diameter		Compact version			Remote versin (without cable)					
		EN (DIN) / AS*	JIS	ANSI/AWWA	EN (DIN) / AS*	Sensor	JIS	ANSI/AWWA	Wall housing	
[mm]	[inch]								g	
25	1"	PN 40	7.3	7.3	PN 40	5.3	5.3	5.3	6.0	
32	1 1/4"		8.0	—		6.0	5.3	—	6.0	
40	1 1/2"		9.4	9.4		7.4	6.3	7.4	6.0	
50	2"		10.6	10.6		8.6	7.3	8.6	6.0	
65	2 1/2"	PN 16	12.0	—	PN 16	10.0	9.1	—	6.0	
80	3"		14.0	14.0		12.0	10.5	12.0	6.0	
100	4"		16.0	16.0		14.0	12.7	14.0	6.0	
125	5"		21.5	—		19.5	19.0	—	6.0	
150	6"	PN 10	25.5	25.5	PN 10	23.5	22.5	23.5	6.0	
200	8"		45	45		43	39.9	43	6.0	
250	10"		65	75		63	67.4	73	6.0	
300	12"		70	110		68	70.3	108	6.0	
350	14"	PN 10	115	175	PN 10	113	—	173	6.0	
400	16"		135	205		133	—	203	6.0	
450	18"		175	255		173	—	253	6.0	
500	20"		175	285		173	—	283	6.0	
600	24"	PN 6	235	405	PN 6	233	—	403	6.0	
700	28"		355	400		353	—	398	6.0	
—	30"		—	460		—	—	458	6.0	
800	32"		435	550		433	—	548	6.0	
900	36"	PN 6	575	800	PN 6	573	—	798	6.0	
1000	40"		700	900		698	—	898	6.0	
—	42"		—	1100		—	—	1098	6.0	
1200	48"		850	1400		848	—	1398	6.0	
—	54"	PN 6	—	2200	PN 6	—	—	2198	6.0	
1400	—		1300	—		1298	—	—	6.0	
—	60"		—	2700		—	—	2698	6.0	
1600	—		1700	—		1698	—	—	6.0	
—	66"	PN 6	—	3700	PN 6	—	—	3698	6.0	
1800	72"		2200	4100		2198	—	4098	6.0	
—	78"		—	4600		—	—	4598	6.0	
2000	—		2800	—		2798	—	—	6.0	

Transmitter Promag (compact version): 3.4 kg
 (Weight data valid for standard pressure ratings and without packaging material)
 * Flanges according AS are only available for DN 80, 100, 150...400, 500 and 600

Weight data of Promag P in kg

Nominal diameter		Compact version			Remote version (without cable)			
		EN (DIN) /AS*	JIS	ANSI	EN (DIN) /AS*	Sensor	ANSI	Wall housing
[mm]	[inch]					JIS		
15	1/2"	6.5	6.5	6.5	4.5	4.5	4.5	6.0
25	1"	7.3	7.3	7.3	5.3	5.3	5.3	6.0
32	1 1/4"	8.0	7.3	—	6.0	5.3	—	6.0
40	1 1/2"	9.4	8.3	9.4	7.4	6.3	7.4	6.0
50	2"	10.6	9.3	10.6	8.6	7.3	8.6	6.0
65	2 1/2"	12.0	11.1	—	10.0	9.1	—	6.0
80	3"	14.0	12.5	14.0	12.0	10.5	12.0	6.0
100	4"	16.0	14.7	16.0	14.0	12.7	14.0	6.0
125	5"	21.5	21.0	—	19.5	19.0	—	6.0
150	6"	25.5	24.5	25.5	23.5	22.5	23.5	6.0
200	8"	45	41.9	45	43	39.9	43	6.0
250	10"	65	69.4	75	63	67.4	73	6.0
300	12"	70	72.3	110	68	70.3	108	6.0
350	14"	115		175	113		173	6.0
400	16"	135		205	133		203	6.0
450	18"	175		255	173		253	6.0
500	20"	175		285	173		283	6.0
600	24"	235		405	233		403	6.0

Transmitter Promag (compact version): 3.4 kg

High-temperature version: +1.5 kg

(Weight data valid for standard pressure ratings and without packaging material)

* Flanges according AS are only available for DN 25 and 50

Weight data of Promag H in kg

Nominal diameter		Compact version	Remote version (without cable)	
		DIN	Sensor	Wall housing
[mm]	[inch]			
2	1/12"	5.2	2.5	6.0
4	5/32"	5.2	2.5	6.0
8	5/16"	5.3	2.5	6.0
15	1/2"	5.4	2.6	6.0
25	1"	5.5	2.8	6.0
40	1 1/2"	6.5	4.5	6.0
50	2"	9.0	7.0	6.0
65	2 1/2"	9.5	7.5	6.0
80	3"	19.0	17.0	6.0
100	4"	18.5	16.5	6.0

Transmitter Promag (compact version): 3.4 kg

(Weight data valid for standard pressure ratings and without packaging material)

Materials

Promag W

Transmitter housing:

- Compact housing: powder coated die-cast aluminium
- Wall-mounted housing: powder coated die-cast aluminium

Sensor housing:

- DN 25...300: powder-coated die-cast aluminium
- DN 350...2000: painted steel (Amerlock 400)

Measuring tube:

- DN < 350: stainless steel 1.4301 or 1.4306/304L; non-stainless flange material with Al/Zn protective coating
- DN > 300: stainless steel 1.4301/304; non-stainless flange material with Amerlock 400 paint

Flange:

- EN 1092-1 (DIN 2501): 316L / 1.4571; RSt37-2 (S235JRG2) / C22 / FE 410W B (DN < 350: with Al/Zn protective coating; DN > 300 with Amerlock 400 paint)
- ANSI: A105, F316L (DN < 350 with Al/Zn protective coating, DN > 300 with Amerlock 400 paint)
- AWWA: 1.0425
- JIS: RSt37-2 (S235JRG2) / H II / 1.0425 / 316L (DN < 350 with Al/Zn protective coating, DN > 300 with Amerlock 400 paint)
- AS 2129: (DN 150, 200, 250, 300, 600) A105 or RSt37-2 (S235JRG2) (DN 80, 100, 350, 400, 500) A105 or St44-2 (S275JR)
- AS 4087: A105 or St44-2 (S275JR)

Ground disks: : 1.4435/316L or Alloy C-22

Electrodes: 1.4435 or Alloy C-22, tantalum

Seals: Seals to DIN EN 1514-1

Promag P

Transmitter housing:

- Compact housing: powder coated die-cast aluminium or stainless steel field housing
- Wall-mounted housing: powder coated die-cast aluminium

Sensor housing:

- DN 15...300: powder-coated die-cast aluminium
- DN 350...600: painted steel (Amerlock 400)

Measuring tube:

- DN < 350: stainless steel 1.4301 or 1.4306/304L; non-stainless flange material with Al/Zn protective coating
- DN > 300: stainless steel 1.4301/304; non-stainless flange material with Amerlock 400 paint

Flange:

- EN 1092-1 (DIN 2501): 316L / 1.4571; RSt37-2 (S235JRG2) / C22 / FE 410W B (DN < 350: with Al/Zn protective coating, DN > 300 with Amerlock 400 paint)
- ANSI: A105, F316L (DN < 350 with Al/Zn protective coating, DN > 300 with Amerlock 400 paint)
- JIS: RSt37-2 (S235JRG2) / H II / 1.0425 / 316L (DN < 350 with Al/Zn protective coating, DN > 300 with Amerlock 400 paint)
- AS 2129: (DN 25) A105 or RSt37-2 (S235JRG2) (DN 50) A105 oder St44-2 (S275JR)
- AS 4087: A105 or St44-2 (S275JR)

Ground disks: 1.4435/316L or Alloy C-22
 Electrodes: 1.4435, platinum/rhodium 80/20 or Alloy C-22, tantalum
 Seals: Seals to DIN EN 1514-1

Promag H

Transmitter housing:

- Compact housing: powder coated die-cast aluminium or stainless-steel field housing 1.4301/316L
- Wall-mounted housing: powder coated die-cast aluminium

Sensor housing: 1.4301

Wall mounting (holder panel): 1.4301

Measuring tube: stainless steel 1.4301 or 1.4306/304L

Flange:

- All connections stainless-steel 1.4404/316L
- Flanges (EN (DIN), ANSI, JIS) made of PVDF
- Adhesive fitting made of PVC

Ground rings: 1.4435/316L, Option: tantalum, Alloy C-22

Electrodes:

- Standard: 1.4435
- Option: Alloy C-22, tantalum, platinum/rhodium 80/20 (up to DN 25 only)

Seals:

- DN 2...25: O-ring (EPDM, Viton, Kalrez) or gasket seal (EPDM, silicone, Viton)
- DN 40...100: gasket seal (EPDM, silicone)

Material load diagram

The material load diagrams (pressure-temperature graphs) for the process connections are to be found in the following documents:

- Technical Information "Promag 50/53W" (TI 046D/06/en)
- Technical Information "Promag 50/53P" (TI 047D/06/en)
- Technical Information "Promag 50/53H" (TI 048D/06/en)

Fitted electrodes

Promag W:

Measuring, reference and EPD electrodes

- Standard available with 1.4435, Alloy C-22, tantalum
- Optional: exchangeable measuring electrodes made of 1.4435 (DN 350...2000)

Promag P:

Measuring, reference and EPD electrodes

- Standard available with 1.4435, Alloy C-22, tantalum, platinum/rhodium 80/20
- Optional: measuring electrodes made of platinum/rhodium 80/20

Promag H:

Measuring electrodes and EPD electrodes

- Standard available with 1.4435, Alloy C-22, tantalum, platinum/rhodium 80/20
- DN 2...4: without EPD electrode

Process connections	Promag W: Flange connection: EN 1092-1 (DIN 2501); DN 65 PN 16 and DN 600 PN 16 exclusively to EN 1092-1, ANSI, AWWA, JIS, AS
	Promag P: Flange connection: EN 1092-1 (DIN 2501); DN 65 PN 16 and DN 600 PN 16 exclusively to EN 1092-1, ANSI, JIS, AS
	Promag H: <ul style="list-style-type: none"> ■ With O-ring: weld nipples (DIN EN ISO 1127, ODT / SMS), flanges (EN (DIN), ANSI, JIS), PVDF flanges (EN (DIN), ANSI, JIS), external pipe thread, internal pipe thread, hose connection, PVC adhesive fittings ■ With gasket seal: weld nipples (DIN 11850, ODT / SMS), clamps (ISO 2852, DIN 32676, L14 AM7), threaded fasteners (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145), flanges (DIN 11864-2)

Surface roughness	<ul style="list-style-type: none"> ■ PFA liner: $\leq 0.4 \mu\text{m}$ ■ Electrodes: <ul style="list-style-type: none"> – 1.4435, Alloy C-22: $0.3\ldots 0.5 \mu\text{m}$ – Tantalum, platinum/rhodium: $0.3\ldots 0.5 \mu\text{m}$ ■ Process connection Promag H: $\leq 0.8 \mu\text{m}$
	(all data relate to parts in contact with medium)

10.1.9 Human interface

Display elements	<ul style="list-style-type: none"> ■ Liquid-crystal display: illuminated, two lines with 16 characters per line ■ Custom configurations for presenting different measured values and status variables ■ 2 totalizers ■ At ambient temperatures below -20°C the readability of the display may be impaired
------------------	--

Operating elements	<ul style="list-style-type: none"> ■ Local operation with three push buttons (–, +, E) ■ “Quick Setup” menus for straightforward commissioning
--------------------	--

Language group	<p>Language groups available for operation in different countries:</p> <ul style="list-style-type: none"> ■ Western Europe and America (WEA): English, German, Spanish, Italian, French, Dutch and Portuguese ■ Eastern Europe and Scandinavia (EES): English, Russian, Polish, Norwegian, Finnish, Swedish and Czech ■ South and east Asia (SEA): English, Japanese, Indonesian <p>You can change the language group via the operating program “ToF Tool – Fieldtool Package.”</p>
----------------	--

Remote operation	Operation via HART protocol
------------------	-----------------------------

10.1.10 Certificates and approvals

Ex Approvals	Information about currently available Ex versions (ATEX, FM, CSA) can be supplied by your Endress+Hauser Sales Center on request. All explosion protection data are given in a separate documentation which is available upon request.
--------------	--

Sanitary compatibility	<p>Promag W: No applicable approvals or certification</p> <p>Promag P: No applicable approvals or certification</p> <p>Promag H: <ul style="list-style-type: none"> ■ 3A authorization and EHEDG-tested ■ Seals in conformity with FDA (except Kalrez seals) </p>
Pressure Equipment Directive	<p>Measuring devices with a nominal diameter smaller than or equal to DN 25 correspond to Article 3(3) of the EC Directive 97/23/EC (Pressure Equipment Directive) and have been designed and manufactured according to good engineering practice. Where necessary (depending on the medium and process pressure), there are additional optional approvals to Category II/III for larger nominal diameters.</p>
CE mark	<p>The measuring system is in conformity with the statutory requirements of the EC Directives. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
Other standards and guidelines	<p>EN 60529 Degrees of protection by housing (IP code)</p> <p>EN 61010 Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures</p> <p>EN 61326/A1 (IEC 6326) Electromagnetic compatibility (EMC requirements)</p> <p>NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment.</p> <p>NAMUR NE 43 Standardisation of the signal level for the breakdown information of digital transmitters with analogue output signal.</p> <p>NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics.</p>

10.1.11 Ordering information

The Endress+Hauser service organisation can provide detailed ordering information and information on specific order codes on request.

10.1.12 Accessories

Various accessories, which can be ordered separately from Endress+Hauser, are available for the transmitter and the sensor (see Page 85). The Endress+Hauser service organisation can provide detailed information on request.

10.1.13 Supplementary documentation

- System Information Promag (SI 028D/06/en)
- Technical Information Promag 50/53W (TI 046D/06/en)
- Technical Information Promag 50/53P (TI 047D/06/en)
- Technical Information Promag 50/53H (TI 048D/06/en)
- Description of Device Functions Promag 50 (BA 049D/06/en)
- Supplementary documentation on Ex-ratings: ATEX, FM, CSA, etc.

11 Index

A

- Accessories 85
- Adapters (installation of sensors) 20
- Ambient temperature 110
- Application 107
- Applicator (selection and configuration software) 87
- Auxiliary input
 - see Status input

B

- Boards 97, 99, 101

C

- Cable entries
 - degree of protection 59
 - technical data 108
- Cable specifications (remote version)
 - cable length, conductivity 25
 - Cable termination of Promag H 50
 - Cable termination Promag W, P 49
 - technical data 51
- Calibration factor (default) 10
- Cathode protection 58
- CE mark (declaration of conformity) 11
- CIP cleaning 110
- Cleaning
 - CIP /SIP cleaning 110
 - exterior cleaning 83
- Code entry (function matrix) 63
- Commissioning 79
 - Commissioning Quick Setup menu 80
 - configure current output (active/passive) 82
 - empty pipe and full pipe calibration (EPD/OED) 81
- Commubox FXA 191, electrical connection 55
- Communication (HART) 65
- Conditions for operation 110
- Conductivity of fluid, minimum 112
- Connection
 - see Electrical connection
- Current output
 - configuration (active/passive) 82
 - electrical connection 54
 - technical data 108

D

- Data storage (S-DAT) 82, 97
- Declaration of conformity (CE mark) 11
- Declaration of contamination 8
- Degree of protection 59, 110
- Designated use 7
- Device description files 67
- Device designation 9
- Device functions
 - see "Description of Device Functions" manual
- Device fuse, replacing 102
- Display
 - display and operating elements 61
 - turning the display 43

- Documentation for hazardous areas (Ex) 7
- Down pipes 16

E

- Electrical connection
 - cable specifications (remote version) 51
 - Commubox FXA 191 55
 - degree of protection 59
 - HART handheld communicator 55
 - length of connecting cable 25
 - post-connection check (checklist) 60
 - potential equalisation 56
 - remote version (connecting cable) 47
 - terminal assignment, transmitter 54
 - transmitter 52
- Electrode Cleaning Circuitry
 - see "Description of Device Functions" manual
- Electrodes
 - EPD electrode 17, 81
 - exchanging replaceable electrodes 103
 - fitted electrodes 117
 - measuring electrode plane 17
 - reference electrode (potential equalisation) 56
- Electromagnetic compatibility (EMC) 51, 110
- Electronics board 97, 99, 101
- Empty Pipe Detection (EPD/OED)
 - empty-pipe/full-pipe adjustment 81
 - EPD electrode 17
 - general information 81
- Error limits
 - see Measuring accuracy
- Error messages
 - display mode 64
 - error message types 94
 - process errors (application errors) 64
 - system errors (device errors) 90
- Error response of outputs / totalizers 95
- Error types (system and process errors) 64
- Ex certification 118
- Ex documentation 7
- Exchange
 - device fuse 102
 - measuring electrodes 103
 - printed circuit boards 98

F

- Failsafe mode (failure response) 95
- Fieldcare 66
- FieldCheck (tester and simulator) 87
- Flow rate / nominal diameter 20
- Fluid conductivity, minimum 25
- Fluid pressure range 112
- Fluid temperature ranges 111
- Foundations (for sensors with DN > 300) 19

- Frequency output
 electrical connection 54
 technical data 108
- Function descriptions
 see "Description of Device Functions" manual
- Function matrix 62
- Functions, function groups 62
- Fuse, replacing 102
- G**
- Galvanic isolation 108
- Ground cable 57
- Ground disks 58
 mounting (Promag P) 34
 mounting (Promag W) 27
 potential equalisation 58
- Ground rings (Promag H)
 mounting, application area 40
 potential equalisation 56
- H**
- HART
 command groups 65
 electrical connection 55
 Handheld terminal 66
- Hazardous substances 8
- High-temperature version (Promag P)
 installation 35
 temperature ranges 111
- HOME position (operating mode) 61
- I**
- Incoming acceptance 13
- Inlet runs 18
- Input signals 107
- Input variables 107
- Installation 15
 Installation dimensions 15, 27, 41
- Installation check (checklist) 46
- Installation conditions
 adapters 20
 down pipes 16
 foundations (DN > 300) 19
 inlet and outlet runs 18
 installation of pumps 15
 location 15
 orientation (vertical, horizontal) 17
 partially filled pipes, drains 16
 vibrations 18
- Installing sensor
 adapters 20
 foundations (DN > 300) 19
 ground disks (Promag P) 34
 ground disks (Promag W) 27
 ground rings (Promag H) 40
 Promag H 39
 Promag H with weld nipples 41
 Promag P 33
 Promag P, high-temperature version 35
 Promag W 26
- Installing the wall-mount housing 44
- Insulation of pipes (Promag P) 35
- L**
- Limiting flow
 see Measuring range 113
- Local display
 see Display
- Low flow cutoff 108
- M**
- Maintenance 83
- Material load curves 117
- Materials 116
- Measured variable 107
- Measuring accuracy
 deviation 109
 reference conditions 109
 repeatability 109
- Measuring electrodes
 see electrodes
- Measuring principle 107
- Measuring range 107
- Measuring system 107
- Measuring tube
 lining, resistance to partial vacuum 113
 lining, temperature range 111
- Medium
 see Fluid ...
- N**
- Nameplate
 Connections 11
 sensor 10
 transmitter 9
- Nominal diameter / flow rate 20
- Nominal pressure
 see Fluid pressure range
- O**
- OED (Open Electrode Detection)
 see Empty Pipe Detection 81
- Operable flow range 107
- Operating conditions 110
- Operation
 device description files 67
 display and operating elements 61
 Fieldcare 66
 function matrix 62
 HART commands 69
 HART handheld terminal 66
 ToF Tool - Fieldtool Package (configuration and service software) 66
- Order code
 Sensor 11
- Ordering code
 accessories 85
 sensor 10
 transmitter 9
- Ordering information 119

- Outlet runs 18
- Output signal 108
- Output variables 108
- Outputs, response to errors 95
- P**
- Partial vacuum, lining 113
- Performance characteristics
 - see Measuring accuracy
- Positive zero return 95
- Potential equalisation 56
- Power consumption 109
- Power supply 108
- Power supply failure 109
- Pressure loss
 - adapters (reducers, expanders) 20
 - general information 113
 - resistance to partial vacuum, lining 113
- Printed circuit boards, removing and installing 98
- Process connections 118
- Process error 64
 - error messages 93
 - process errors without message 94
- Programming mode
 - disable 63
 - enable 63
- Pumps, location 15
- Q**
- Quick Setup menu for "Commissioning" 80
- R**
- Registered trademarks 12
- Registrierte Warenzeichen 12
- Repair 8
- Repeatability (measuring accuracy) 109
- Returning devices 8
- S**
- Safety icons 8
- Safety instructions 7
- Safety of operation 7
- Safety regulation form (e.g. for repairs)
 - see Declaration of contamination
- Sanitary compatibility 119
- Screw tightening torques
 - for Promag H (with plastic process connections) 39
 - for Promag P 36
 - for Promag W 28
- S-DAT 97
- S-DAT (HistoROM) 82
- Seals
 - Promag H 39
 - Promag P 33
 - Promag W 26
 - temperature ranges (Promag H) 112
- Sensor installation
 - see Installing sensor
- Serial number 9, 10, 11
- Shock resistance 110
- Signal on alarm 108
- SIP cleaning 110
- Software
 - amplifier display 79
 - versions (history) 105
- Spare parts 97
- Status input
 - electrical connection 54
 - technical data 107
- Status output
 - electrical connection 54
 - technical data 108
- Storage 14
- Switching output 108
- System error 64
 - definition 64
 - error messages 90
- T**
- Technical data 107
- Temperature ranges
 - ambient temperature 110
 - fluid temperature 111
 - storage temperature 110
- ToF Tool – Fieldtool Package 66, 87
- Transmitter
 - electrical connection 52
 - installing the wall-mount housing 44
 - length of connecting cable (remote version) 25
 - turning the field housing (aluminum) 42
 - turning the field housing (stainless steel) 42
- Transporting the sensor 13
- Trouble-shooting 89
- V**
- Vibrations
 - measures to prevent vibrations 18
 - shock resistance 110
- W**
- Wall-mount housing, installing 44
- Weights 114
- Welding work
 - grounding welding equipment 41
 - Promag H with weld nipples 41
- Wiring
 - see Electrical connection

Declaration of Contamination

Erklärung zur Kontamination

Endress+Hauser 

People for Process Automation

Because of legal regulations and for the safety of our employees and operating equipment, we need the "declaration of contamination", with your signature, before your order can be handled. Please make absolutely sure to include it with the shipping documents, or - even better - attach it to the outside of the packaging.

Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination", bevor Ihr Auftrag bearbeitet werden kann. Legen Sie diese unbedingt den Versandpapieren bei oder bringen Sie sie idealerweise außen an der Verpackung an.

Type of instrument / sensor

Geräte-/Sensortyp _____

Serial number

Seriennummer _____

Process data / Prozessdaten

Temperature / Temperatur _____ [°C] Pressure / Druck _____ [Pa]

Conductivity / Leitfähigkeit _____ [S] Viscosity / Viskosität _____ [mm²/s]

Medium and warnings

Warnhinweise zum Medium



	Medium / concentration Medium / Konzentration	Identification CAS No.	flammable entzündlich	toxic giftig	corrosive ätzend	harmful/ irritant gesundheitsschädlich/ reizend	other * sonstiges*	harmless unbedenklich
Process medium Medium im Prozess								
Medium for process cleaning Medium zur Prozessreinigung								
Returned part cleaned with Medium zur Endreinigung								

* explosive; oxidising; dangerous for the environment; biological risk; radioactive

* explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv

Please tick should one of the above be applicable, include security sheet and, if necessary, special handling instructions.

Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.

Reason for return / Grund zur Rücksendung _____

Company data / Angaben zum Absender

Company / Firma _____	Contact person / Ansprechpartner _____
Address / Adresse _____	Department / Abteilung _____
_____	Phone number / Telefon _____
_____	Fax / E-Mail _____
_____	Your order No. / Ihre Auftragsnr. _____

We hereby certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free from any residues in dangerous quantities.

Hiermit bestätigen wir, dass die zurückgesandten Teile sorgfältig gereinigt wurden, und nach unserem Wissen frei von Rückständen in gefährbringender Menge sind.

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation