



TRANE®

User Guide

Tracer CH.530™
Chiller Control System
RTHD only



RLC-SVU03A-E4



General Information

Foreword

These instructions are given as a guide to good practice in the operation of Tracer CH.530 chiller control. They do not contain the full service procedures necessary for the continued successful operation of this equipment. The services of a qualified service technician should be employed, through the medium of a maintenance contract with a reputable service company.

Warranty

Warranty is based on the general terms and conditions of the constructor. The warranty is void if the equipment is modified or repaired without the written approval of the constructor, if the operating limits are exceeded, or if the control system or the electrical wiring is modified. Damage due to misuse, lack of maintenance, or failure to comply with the manufacturer's instructions, is not covered by the warranty obligation. If the user does not conform to the instructions in this manual, it may entail cancellation of warranty and liabilities by the constructor.

Reception

On arrival, inspect the unit before signing the delivery note. Specify any damage on the delivery note, and send a registered letter of protest to the last carrier of the goods within 72 hours of delivery. Notify the local sales office at the same time. The unit should be totally inspected within 7 days of delivery. If any concealed damage is discovered, send a registered letter of protest to the carrier within 7 days of delivery and notify the local sales office.

About this manual

Cautions appear at appropriate places in this instruction manual. Your personal safety and the proper operation of this machine require that you follow them carefully. The constructor assumes no liability for installations or servicing performed by unqualified personnel.

Contents

General Information	2
Overview	4
DynaView Interface	
Key Functions	5
Display Screens	5
TechView Interface	
Software Download	19
Diagnostics	21
Maintenance Contract	40
Training	40

Overview

Components

The Trane CH.530 control system that runs the chiller consists of several elements:

- The **main processor** collects data, status, and diagnostic information and communicates commands to the starter module and the **LLID (Low Level Intelligent Device)** bus. The main processor has an integral display (DynaView).
- Higher level **modules** (e.g. starter) exist only as necessary to support system level control and communications. The starter module provides control of the starter when starting, running, and stopping the chiller motor. It also processes its own diagnostics and provides motor and compressor protection.
- **LLID bus.** The main processor communicates to each input and output device (e.g. temperature and pressure sensors, low voltage binary inputs, analog input/output) all connected to a four-wire bus, rather than the conventional control architecture of signal wires for each device.
- The **communication interface** to a building automation system (BAS).
- A **service tool** to provide all service/maintenance capabilities. Main processor and service tool (TechView) software is downloadable from www.Trane.com. The process is discussed later in this section under Tech-View Interface. DynaView provides bus management. It has the task of restarting the link, or filling in for what it sees as "missing" devices when normal communications has been degraded. Use of TechView may be required. The CH.530 uses the IPC3 protocol based on RS485 signal technology and communicating at 19.2 Kbaud to allow 3 rounds of data per second on a 64-device network. Most diagnostics are

handled by the DynaView. If a temperature or pressure is reported out of range by a LLID, the DynaView processes this information and calls out the diagnostic. The individual LLIDs are not responsible for any diagnostic functions. The only exception to this is the Starter module.

NOTE: It is imperative that the CH.530 Service Tool (TechView) be used to facilitate the replacement of any LLID or reconfigure any chiller component.

Controls Interfaces

DynaView (picture on cover)

Each chiller is equipped with the DynaView interface. DynaView has the capability to display additional information to the advanced operator including the ability to adjust settings. Multiple screens are available and text is presented in multiple languages as factory-ordered or can be easily downloaded online.

The display on DynaView is a 1/4 VGA display with a resistive touch screen and an LED backlight. The display area is approximately 102mm x 60mm.

TechView

TechView can be connected to the DynaView module and provides further data, adjustment capabilities, diagnostics information and downloadable software and languages.

DynaView Interface

Key Functions

In this touch screen application, key functions are determined completely by software and change depending upon the subject matter currently being displayed. The basic touch screen functions are outlined below.

CAUTION Equipment Damage!
Putting excessive pressure on the touch screen could cause damage. It takes less than 7 kg of force to break the screen.

Radio Buttons

Radio buttons show 1 menu choice among 2 or more alternatives, all visible. The possible selections are each associated with a button. The selected button is darkened, presented in reverse video to indicate it is the selected choice. The full range of possible choices as well as the current choice is always in view.

Spin Value Buttons

Spin values are used to allow a variable setpoint to be changed, such as leaving water setpoint. The value increases or decreases by touching the (+) or (-) arrows.

Action Buttons

Action buttons appear temporarily and provide the user with a choice such as **Enter** or **Cancel**.

File Folder Tabs

File folder tabs are used to select a screen of data. The tabs are in 1 row across the top of the display. The user selects a screen of information by touching the appropriate tab.

Display Screens

Basic Screen Format (Figure 1)

The main body of the screen is used for description text, data, setpoints, or keys (touch sensitive areas). The Chiller Mode is displayed here. A double arrow pointing to the right indicates more information is available about the specific item on that same line. Pressing it will bring you to a sub-screen that will present the information or allow changes to

settings. The bottom of the screen (7) is present in all screens. The contrast (8,9) may require re-adjustment at ambient temperatures significantly different from those present at last adjustment.


The other functions are critical to machine operation. The **AUTO** and **STOP** keys are used to enable or disable the chiller. The key selected is in black. The chiller will stop when the **STOP** key is touched and after completing the Run Unload mode. Touching the **AUTO** key will enable the chiller for active cooling if no diagnostic is present. (A separate action must be taken to clear active diagnostics.)

The **AUTO** and **STOP** keys take precedence over the **Enter** and **Cancel** keys. (While a setting is being changed, **AUTO** and **STOP** keys are recognized even if **Enter** or **Cancel** has not been pressed.)

The **ALARMS** button appears only when an alarm is present, and blinks (by alternating between normal and reverse video) to draw attention to a diagnostic condition. Pressing the **ALARMS** button takes you to the corresponding tab for additional information.

DynaView Interface

Figure 1 - Basic Screen Format



- 1 = File folder tabs - to select the various display screens
- 2 = Reports Tab
- 3 = Settings Tab
- 4 = Page scroll up
- 5 = Line scroll up/down
- 6 = Page scroll down
- 7 = Fixed display
- 8 = Contrast control (lighter)
- 9 = Contrast control (darker)

Display and Touch Screen Lock Feature

This screen (Figure 2) is used if the display and touch screen lock feature is enabled. 30 minutes after the last keystroke, this screen is displayed and the Display and Touch Screen are locked out until the sequence "159 <ENTER>" is pressed.

Until the proper password is entered, there will be no access to the DynaView screens including all reports, setpoints, and Auto/Stop/Alarms/Interlocks. The password "159" can not be changed from either DynaView or TechView.

Figure 2 - Locked Screen

DISPLAY AND TOUCH SCREEN ARE LOCKED
ENTER PASSWORD TO UNLOCK

1	2	3
3	5	6
7	8	9
Enter	0	Cancel

○
Auto
Stop
Alarms
●

Main Screen

The main screen (default screen, see Figure 3) is a summary of the chiller's activity. After an idle time of 30 minutes the CH.530 will display the Main screen with the first data fields. The remaining items (listed in the Table 1) are viewed by selecting the up/down arrow icons.

Figure 3 - Main Screen

Main
Reports
Settings

▲
▲
▼
▼

Chiller Mode:	Stopped
Evap Ent/Lvg Water Temp:	54.0 / 44.0
Cond Ent/Lvg Water Temp:	85.0 / 95.0
Active Chilled Water Setpoint:	44.0
Average Line Current:	87.4% R.H.
Active Current Limit Setpoint:	100% R.H.

○
Auto
Stop
Alarms
●

DynaView Interface

Table 1 - Main screen Items

Message	Description	Units
Chiller Mode (>> submodes)	See Table 2	Text
Evap Ent/Lvg WaterTemp	Indicates the temperature of the water entering and leaving the evaporator	F / C
Cond Ent/Lvg WaterTemp	Indicates the temperature of the water entering and leaving the condenser	F / C
Active Chilled Water Setpoint (>>source)	Indicates the active setpoint currently used by the unit (pressing ">>" will indicate the origin of the setpoint (e.g. external, local, BAS...))	F / C
Average Line Current	Indicates the average current of the 3 lines	% RLA
Active Current Limit Setpoint (>>source)	Indicates the active setpoint currently used by the unit (pressing ">>" will indicate the origin of the setpoint (e.g. external, local, BAS...))	% RLA
Active Base Loading Setpoint (>>source)	Indicates the active setpoint currently used by the unit (pressing ">>" will indicate the origin of the setpoint (e.g. local, BAS...))	%
Active Ice Termination Setpoint (>>source)	Indicates the active setpoint currently used by the unit (pressing ">>" will indicate the origin of the setpoint (e.g. external, local, BAS...))	F / C
Outdoor Air Temperature	Indicates the current outdoor air temperature	F / C
Software Type	RTH	Text
Software Version	Version of MP application	Text

DynaView Interface

Chiller Operating Modes

The machine-operating mode indicates the operational status of the chiller. A sub-screen with additional mode summary information is provided by selection of an additional information icon (>>). The operating mode line will remain stationary while the remaining status items scroll with the up/down arrow keys. Table 2 is a list of all Top Level (1) and Sub Level (2) Modes.

Table 2 - Chiller Operating Modes

Chiller Modes	Description
MP Resetting (1)	
Stopped (1)	The chiller is not running and cannot run without intervention. Further information is provided by the sub-mode:
Local Stop (2)	Chiller is stopped by DynaView. Stop button command - cannot be remotely overridden.
Panic Stop (2)	Chiller is stopped by the DynaView. Panic Stop (pressing "Stop" twice) - previous shutdown was manually commanded to shutdown immediately without a run-unload or pumpdown cycle - cannot be remotely overridden.
Diagnostic Shutdown - Manual Reset (2)	The chiller is stopped by a diagnostic that requires manual intervention to reset.

DynaView Interface

Other sub-modes are possible in conjunction with at least one of the above modes - See items below for their descriptions:

Diagnostic Shutdown - Auto Reset (2)	
Start Inhibited by External Source (2)	
Start Inhibited by BAS (2)	
Waiting for BAS Communications (2)	
Ice Building to Normal Transition (2)	
Ice Building is Complete (2)	
Waiting for Oil Level (2)	
Run Inhibit (1)	The chiller is currently being inhibited from starting (and running), but may be allowed to start if the inhibiting or diagnostic condition is cleared. Further information is provided by the sub-mode:
Diagnostic Shutdown - Auto Reset (2)	The entire chiller is stopped by a diagnostic that may automatically clear.
Start Inhibited by External Source (2)	The chiller is inhibited from starting (and running) by the "external stop" hardwired input.
Start Inhibited by BAS (2)	The chiller is inhibited from starting (and running) by command from a BAS via the digital communication link (com 4 or com 5).
Waiting for BAS Communications (2)	This is a transient mode - 15 min. max, and is only possible if the chiller is in the Auto - Remote command mode. After a power up reset, it is necessary to wait for valid communication from a BAS (Tracer) to know whether to run or stay inhibited. Either valid communication will be received from the BAS (Tracer), or a communication diagnostic ultimately will result. In the latter case the chiller will revert to Local control.
Power Up Delay Inhibit (2) min:sec	The compressor is currently being inhibited from starting as part of the power up start delay (or staggered start) feature. This feature is intended to prevent multiple chillers from all starting simultaneously if power is restored to all chillers simultaneously.
Ice Building to Normal Transition (2)	The chiller is inhibited from running for a brief period of time if it is commanded from active ice building mode into normal cooling mode via the ice building hardwired input or Tracer. This allows time for the external system load to "switchover" from an ice bank to the chilled water loop, and provides for a controlled pull down of the loop's warmer temperature. This mode is not seen if the ice making is automatically terminated on return brine temperature per the mode below.
Ice Building is Complete (2)	The chiller is inhibited from running as the Ice Building process has been normally terminated on the return brine temperature. The chiller will not start unless the ice building command (hardwired input or BAS command) is removed or cycled (contact opened).

DynaView Interface

Low Diff Rfqt Pres Cool-DownTime (2) mn:sec	See oil flow protection specification.
Auto (1)	The chiller is not currently running but can be expected to start at any moment given that the proper conditions and interlocks are satisfied. Further information is provided by the sub-mode:
Waiting For Evap Water Flow (2)	The chiller will wait up to 4 minutes in this mode for evaporator water flow to be established per the flow switch hardwired input.
Waiting for Need to Cool (2)	The chiller will wait indefinitely in this mode, for an evaporator leaving water temperature higher than the Chilled Water Setpoint plus the Differential to Start.
Waiting to Start (1)	The chiller is not currently running and there is a call for cooling but start is delayed by certain interlocks or proofs. Further information is provided by the sub-mode:
Waiting For Cond Water Flow (2)	The chiller will wait up to 4 minutes in this mode for condenser water flow to be established per the flow switch hardwired input.
Waiting for Oil Level (2)	The chiller will wait up to 2 minutes in this mode for oil level to appear in the oil tank.
Cond Water Pump PreRunTime (2) min:sec	The chiller will wait up to 30 minutes (user adjustable) in this mode to allow the condenser water loop to equalize in temperature
Compressor Restart InhibitTime (2) min:sec	The compressor is currently unable to start due to its restart inhibit timer. A given compressor is not allowed to start until 5 minutes (user adjustable) has expired since its last start.
Waiting For EXV Preposition (2)	The chiller will wait for the time it takes the EXV to get to its commanded pre-position prior to starting the compressor. This is typically a relatively short delay and no countdown timer is necessary (less than 15 seconds).
Running (1)	The chiller, circuit, and compressor are currently running. Further information is provided by the sub-mode:
Unit is Building Ice (2)	The chiller is running in the Ice Building Mode, and either at or moving towards full capacity available. Ice mode is terminated either with the removal of the ice mode command or with the return brine temperature falling below the IceTermination Setpoint.
Establishing Min Capacity - High Disch Temp (2)	The compressor is running and is being forced loaded, without regard to the leaving water temperature control, to prevent tripping on high compressor discharge temperature.
Base Loaded (2)	Chiller is running in "Base Load" operation where the capacity of the chiller is controlled to maintain a given current per an adjustable setpoint. The chiller is forced to run without regard to the chilled water temperatures and the differential to start and stop.

DynaView Interface

Capacity Control Softloading (2)	The chiller is running, but loading is influenced by a gradual "pulldown" filter on the chilled water temperature setpoint. The settling time of this filter is user adjustable as part of the softload control feature.
Current Control Softloading (2)	The chiller is running, but loading is influenced by a gradual filter on the current limit setpoint. The starting current and the settling time of this filter is user adjustable as part of the softload control feature.
EXV Controlling Differential Pressure (2)	Liquid level control of the Electronic Expansion Valve has temporarily been suspended. The EXV is being modulated to control for a minimum differential pressure. This control implies low liquid levels and higher approach temperatures, but is necessary to provide minimum oil flow for the compressor until the condenser water loop can warm up to approx. 10°C.
Running - Limited (1)	The chiller, circuit, and compressor are currently running, but the operation of the chiller/compressor is being actively limited by the controls. Further information is provided by the sub-mode.
Capacity Limited by High Cond Press (2)	The circuit is experiencing condenser pressures at or near the condenser limit setting. The compressor will be unloaded to prevent exceeding the limits.
Capacity Limited by Low Evap Rfgt Temp (2)	The circuit is experiencing saturated evaporator temperatures at or near the Low Refrigerant Temperature Cutout setting. The compressors will be unloaded to prevent tripping.
Capacity Limited by Low Liquid Level (2)	The circuit is experiencing low refrigerant liquid levels and the EXV is at or near full open. The compressor will be unloaded to prevent tripping.
Capacity Limited by High Current (2)	The compressor is running and its capacity is being limited by high currents. The current limit setting is 120% RLA (to avoid overcurrent trips).
Capacity Limited by Phase Unbalance (2)	The compressor is running and its capacity is being limited by excessive phase current unbalance.
Note: Other normal running modes (see above) may also appear under this top level mode.	
Shutting Down (1)	The chiller is still running but shutdown is imminent. The chiller is going through a compressor run-unload sequence. Shutdown is necessary due to one (or more) of the following sub-modes:
Local Stop (2)	Chiller is in the process of being stopped by DynaView Stop button command.
Panic Stop (2)	Chiller is in the process of being stopped by DynaView Panic Stop command.



DynaView Interface

Diagnostic Shutdown - Manual Reset (2)	Chiller is in the process of being stopped by a Latching Diagnostic shutdown - Manual Reset is required to clear.
Diagnostic Shutdown - Auto Reset (2)	Chiller is in the process of being stopped by a Diagnostic shutdown- Automatic clearing of the diagnostic is possible if condition clears.
Compressor Unloading (2) min:sec	The compressor is in its "run - unload" state in which it is being continuously unloaded for 40 sec prior to shutdown.
Start Inhibited by External Source (2)	Chiller is in the process of being stopped by the External Stop hardwired input.
Start Inhibited by BAS (2)	Chiller is in the process of shutdown due to a command from the BAS (Tracer).
Ice Building to Normal Transition (2)	Chiller is in the process of being stopped by the transition from ice to normal cooling mode with the removal of the ice making command via the hardwired input or BAS (Tracer).
Ice Building is Complete (2)	Chiller is in the process of being stopped as the Ice Building process is being normally terminated on the return brine temperature.
Evap Pump Off Delay (2) min:sec	Chiller is stopped. Evaporator pump is still operating and will stop after the minimum delay set.
Service Override (1)	The Chiller is in a Service Override mode
Service Pumpdown (2)	The chiller, circuit, and compressor is running via a manual command to perform a Service Pumpdown. Both evaporator and condenser water pumps are commanded to run. The EXV is held wide open, but the manual liquid line service valve should be closed.


(1) Top Level Mode
(2) Sub Level Mode

DynaView Interface

Reports Screen

This screen allows a user to select from a list of report headings. Each report will generate a list of status items as defined in Table 3.

Figure 4 - Reports Screen



Message	Description	Units
Evaporator		
Evap Entering Water Temp	Indicates the water temperature entering the evaporator	F / C
Evap Leaving Water Temp	Indicates the water temperature leaving the evaporator	F / C
Evap Sat Rfgt Temp	Indicates the evaporator saturated refrigerant temperature	F / C
Evap Rfgt Pressure	Indicates the evaporator refrigerant pressure	psi / kPa
Evap Approach	Indicates the difference between the evaporator leaving water temperature and evaporator saturated refrigerant temperature	F / C
Evap Water Flow Switch Status		Text (Flow, No Flow)
Expansion Valve Position	Indicates the opening of the expansion valve	%
Expansion Valve Position Steps	Indicates the opening of the expansion valve	Steps
Evaporator Liquid Level	Indicates the level of refrigerant in the evaporator	in / mm
Condenser		
Cond Entering Water Temp	Indicates the water temperature entering the condenser	F / C
Cond Leaving Water Temp	Indicates the water temperature leaving the condenser	F / C
Cond Sat Rfgt Temp	Indicates the condenser saturated refrigerant temperature	F / C

DynaView Interface

Cond Rfgt Pressure	Indicates the condenser refrigerant pressure	psi / kPa
Cond Approach Temp	Indicates the difference between the condenser leaving water temperature and condenser saturated refrigerant temperature	F / C
Cond Water Flow Switch Status		Text (Flow, No Flow)
Cond Head Pressure Ctrl Command	Percentage of water condenser flow commanded	%
Outdoor Air Temperature	Indicates the current outdoor air temperature	F / C
Compressor		
Compressor Starts	Indicates the total number of compressor starts	Integer
Compressor RunningTime	Indicates the total time the compressor has run	hr:min
System Rfgt Diff Pressure	Indicates the system's refrigerant differential pressure	psi / kPa
Oil Pressure		psi / kPa
Compressor Rfgt DischargeTemp	Indicates the temperature at which the refrigerant is leaving the compressor	F / C
Discharge Superheat	Indicates the difference between the discharge temperature and condensing saturated temperature	F / C
% RLA L1 L2 L3	For each of the 3 lines	% RLA
Amps L1 L2 L3	For each of the 3 lines	A
Volts AB BC CA	Between each line	V
Chiller Log		
Current Time/Date	mmm dd, yyyy	Date /Time
Operating Mode:	See Table 2	Text
Amps L1 L2 L3	For each of the 3 lines	A
Volts AB BC CA	Between each line	V
Active Chilled Water Setpoint	Indicates the active setpoint currently used by the unit	F / C
Active Current Limit Setpoint	Indicates the active setpoint currently used by the unit	F / C
Refrigerant Monitor	Indicates the concentration of refrigerant detected by the refrigerant monitor	Ppm

DynaView Interface


Compressor Starts	Indicates the total number of compressor starts	Hours:Minute
Compressor RunningTime	Indicates the total time the compressor has run	F / C
Compressor Rfgt DischargeTemp	Indicates the temperature at which the refrigerant is leaving the compressor	F / C
Evap Entering WaterTemp	Indicates the water temperature entering the evaporator	F / C
Evap Leaving WaterTemp	Indicates the water temperature leaving the evaporator	F / C
Evap Sat RefrigerantTemp	Indicates the evaporator saturated refrigerant temperature	psi / kPa
Evap Rfgt Pressure	Indicates the evaporator refrigerant pressure	F / C
Evap Approach Temp	Indicates the difference between the evaporator leaving water temperature and evaporator saturated refrigerant temperature	Text
Evap Water Flow Switch Status		F / C
Cond Entering WaterTemp	Indicates the water temperature entering the condenser	F / C
Cond Leaving WaterTemp	Indicates the water temperature leaving the condenser	F / C
Cond Sat RfgtTemp	Indicates the condenser refrigerant pressure	psi / kPa
Cond Rfgt Pressure	Indicates the condenser refrigerant pressure	F / C
Cond ApproachTemp	Indicates the difference between the condenser leaving water temperature and condenser saturated refrigerant temperature	
Cond Water Flow Switch Status		Text

DynaView Interface

Settings Screen

This screen enables the user to adjust settings. The layout provides a list of sub-menus, organized by typical subsystem.

Figure 5 - Settings Screen



Message	Description / Default	Units
Chiller		
Front Panel Chilled Water Setpt	Local setpoint	F / C
Front Panel Current Limit Setpt	Local setpoint	% RLA
Front Panel Base Load Cmd	Local command	Text (On/Auto)
Front Panel Base Load Setpt	Local setpoint	%
Front Panel Ice Build Cmd	Local command	Text (On/Auto)
Front Panel Ice Termn Setpt	Local setpoint	F / C
Ice to Normal CoolTimer Setpt	Time between the end of ice making and return to normal operation, 5 min	TMinutes (0-10)
Differential to Start	Difference between the active chilled water setpoint and the leaving temperature at which the unit will start	F / C
Differential to Stop	Difference between the active chilled water setpoint and the leaving temperature at which the unit will stop	F / C
Setpoint Source	BAS/External/Front Panel (local)	Text (BAS/Ext/FP, Ext/ Front Panel, Front Panel)
Features		
Chilled Water Reset	The chilled water setpoint is reset based on a constant value, or on return water temperature or outdoor air temperature. Disable	Text (Constant, Outdoor, Return, Disable)
Return Reset Ratio	User-adjustable gain based on the return water temperature	%

DynaView Interface

Return Start Reset	The return water temperature at which the reset will start	F / C
Return Maximum Reset	User-adjustable limit providing the maximum amount of reset	F / C
Outdoor Reset Ratio	User-adjustable gain based on the outdoor air temperature	%
Outdoor Start Reset	The outdoor air temperature at which the reset will start	F / C
Outdoor Maximum Reset	User-adjustable limit providing the maximum amount of reset	F / C
Ext Chilled Water Setpoint	Disable	Text (Enable, Disable)
Ext Current Limit Setpoint	Disable	Text (Enable, Disable)
Ice Building	Disable	Text (Enable, Disable)
Ext Base Loading Setpoint	Disable	Text (Enable, Disable)
Mode Overrides		
Evap Water Pump	Auto	Text (Auto, On)
Cond Water Pump	Auto	Text (Auto, On)
Expansion Valve Control	Auto	Text (Auto, Manual)
Slide Valve Control	Auto	Text (Auto, Manual)
Service Pumpdown	Status: (Avail, Not Avail, Pumpdown)	Text
Display Settings		
Date Format	mmm dd, yyy	Text (mmm dd, yyy, dd-mmm-yyyy)
Date		Text
Time Format	12-hour	Text (12-hour, 24-hour)
Time of Day		Text
Keypad/Display Lockout	Disable	Text (Enable, Disable)
Display Units	English	Text (SI, English)
Pressure Units	Absolute	Text (Absolute, Gauge)
Language Selection	Downloaded from TechView	Text

DynaView Interface

Diagnostic Screen

The diagnostic screen (Figure 6) is accessible by depressing the Alarms enunciator. A verbal description will be provided. A scrollable list of the last (up to 10) active diagnostics is presented. Performing a "Reset Diags" will reset all active diagnostics regardless of type, machine or circuit. The scrollable list will be sorted by time of occurrence. If an informational warning is present, the "Alarms" key will be present but not flashing. If a diagnostic shutdown (normal or immediate) has occurred, the "Alarm" key will be flashing. If no diagnostics exist, the "Alarm" key will not be present. The "Operating Mode At Last Diagnostic" text above the most recent diagnostic will display a sub-screen listing the operating mode and submodes at the time of the last diagnostic.

Figure 6 - Diagnostics Screen

Main		Reports		Settings	
		▽		Reset Diags	
Chiller Mode>>		Stopped			
[01] 8:32 AM Nov 16, 2001					
Comm Loss: Emergency Stop					
[02] 8:29 AM Nov 16, 2001					
MP: Reset Has Occurred					
○	Auto	Stop	Alarms	●	



TechView Interface

TechView is the laptop-based tool used for servicing Tracer CH.530. Technicians that make any chiller control modification or service any diagnostic with Tracer CH.530 must use a laptop running the software application "TechView." TechView is a Trane application developed to minimize chiller downtime and aid the technicians' understanding of chiller operation and service requirements.

NOTE: Important: Performing any Tracer CH.530 service functions should be done only by a properly trained service technician. Please contact your local Trane service agency for assistance with any service requirements. TechView software is available via Trane.com. (<http://www.trane.com/commercial/software/tracerch530/>) This download site provides the TechView installation software and CH.530 main processor software that must be loaded onto your PC in order to service a CH.530 main processor. The TechView service tool is used to load software into the Tracer CH.530 main processor.

Minimum PC requirements to install and operate TechView are:

Pentium or higher processor
b

0 resolution of display

C -

5 modem

-pin - 3 serial connection

operating system - Windows 000

Microsoft Office (Word
Access Excel)

Parallel Port (5-pin) or Port

NOTE: TechView was designed for the preceding listed laptop configuration. Any variation will have unknown results. Therefore, support for TechView is limited to only those operating systems that meet the specific configuration listed here. Only computers with a Pentium II class processor or better are supported; Intel Celeron, AMD, or Cyrix processors are not supported.

TechView is also used to perform any CH.530 service or maintenance function. Servicing a CH.530 main processor includes:

Updating main processor software

Monitoring chiller operation

Viewing and resetting chiller diagnostics

Low level intelligent device () replacement and binding

Main processor replacement and configuration modifications

Setpoint modifications

Service overrides

Software Download

Instructions for First Time TechView Users

This information can also be found at <http://www.trane.com/commercial/software/tracerch530/>.

1. Create a folder called "CH.530" on your C:\ drive. You will select and use this folder in subsequent steps so that downloaded files are easy to locate.
2. Download the Java Runtime installation utility file onto your PC in the CH.530 folder. Please note that this does not install Java Runtime. It only downloads the installation utility.
 - a. Click on the latest version of Java Runtime shown in the TechView Download table.
 - b. Select "Save this program to disk" while downloading the files. Do not select "Run this program from its current location".
3. Download the TechView installation utility file onto your PC in the CH.530 folder. Please note that this does not install TechView. It only downloads the installation utility.
 - a. Click on the latest version of TechView shown in the TechView Download table.
 - b. Select "Save this program to disk" while downloading the files. Do not select "Run this program from its current location".

TechView Interface

4. Remember where you downloaded the files (the "CH.530 " folder). You will need to locate them to finish the installation process.
5. Proceed to the "Main Processor Software Download " page. Read the instructions to download the latest version of main processor installation files. You will first select the chiller type to obtain the available file versions.
6. Select the product family. A table with the download link will appear for that product family.
7. Download the main processor software onto your PC in the CH.530 folder. Please note that this does not install the main processor. It only downloads the installation utility.
 - a. Click on the latest version of the main processor.
 - b. Select "Save this program to disk" while downloading the files. Do not select "Run this program from its current location".
8. Remember where you downloaded the files (the "CH.530" folder). You will need to locate them to finish the installation process.
9. To complete the installation process, locate the installation utilities you downloaded into the CH.530 folder. If necessary, use your PC's file manager to locate the downloaded files.
10. Install the applications in the following order by double-clicking on the install program and following the installation prompts:
 - a. Java Runtime Environment (JRE_VXXX.exe) Note: During the Java Runtime Environment installation, you may be prompted to "select the default Java Runtime for the system browsers". Do not select any system browsers at this step. There should be no default browsers selected for proper operation.
 - b. TechView (6200-0347-VXXX.exe)
 - c. The main processor (6200-XXXX-XX-XX.exe).
 - d. The main processor program will self extract to the proper folder within the TechView program directory, provided the TechView program is properly installed on the C:\ drive.
11. Connect your PC to the CH.530 main processor using a standard 9-pin male/9-pin female RS-232 cable.
12. Run the TechView software by selecting the TechView icon placed on your desktop during the installation process. The "Help...About "menu can be viewed to confirm proper installation of latest versions.

Diagnostics

Table 5 contains all the diagnostics possible. Not all data is available unless TechView is installed.

Hex Code: 3-digit hexadecimal code used on all past products to uniquely identify diagnostics. Refer to the database \\SRV-et-data\ucp3\service-tool\databases\servicetool.mdb

Diagnostic Name and Source: Note that this is the exact text used in the User Interface and/or Service Tool displays.

Severity: Defines the severity of the above effect. **Immediate** means immediate shutdown of the effected portion, **Normal** means normal or friendly shutdown of the effected portion, **Special Mode** means a special mode of operation (limp along) is invoked, but without shutdown, and **Info** means an Informational Note or Warning is generated.

Persistence: Defines whether or not the diagnostic and its effects are to be manually reset (Latched), or can be either manually or automatically reset (Nonlatched) and, if nonlatching, the criteria for auto reset. If more explanation is necessary a hot link to the Functional Specification is used which can clear the diagnostic. The manual diagnostic reset levels in order of can only be reset by a local diagnostic reset command, but not by the lower priority remote Reset command whereas a diagnostic listed as Remote reset can be reset by either.

Criteria: Quantitatively defines the criteria used in generating the diagnostic

Reset Level: Defines the lowest level of manual diagnostic reset command priority are: **Local** and **Remote**. A diagnostic that has a reset level of Local, can only be reset by a local diagnostic reset command, but not by the lower priority remote Reset command whereas a diagnostic listed as Remote reset can be reset by either.

Diagnostics

Table 5 - Possible Diagnostics

Hex Code	Diagnostic Name and Source	Severity	Persistence	Criteria	Reset Level
398	BAS Communication Lost	Special		The BAS was setup as "installed" at the MP and the Comm 3 LLID lost communications with the BAS for 15 contiguous minutes after it had been established.	Remote
390	BAS Failed to Establish Communication	Special		The BAS was setup as "installed" and the BAS did not communicate with the MP within 15 minutes after power-up.	Remote
2E6	Check Clock	Info	Latch	The real time clock had detected loss of its oscillator at some time in the past. Check / replace battery? This diagnostic can be effectively cleared only by writing a new value to the chiller's time clock using the TechView or DynaView's "set chiller time" functions.	Remote
8A	Chilled Water Flow (Entering WaterTemp)	Info	NonLatch	The entering evaporator water temp fell below the leaving evaporator water temperature by more than an integrated value. For diagnostic cannot reliably indicate loss of flow, but can warn of improper flow direction through the evaporator, misbound temperature sensors, or other system problems.	Remote
5F8	Comm Loss: Chilled Water Pump Starter	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5EF	Comm Loss: Chilled Water Flow Switch	Immediate	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Compressor % RLA Output	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote

Diagnostics

6B6	Comm Loss: Compressor Discharge Temperature	Immediate	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Cond Head Press Cntrl Output	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Condenser Entering Water Temperature	Info and Special Action	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. If chiller running, and condenser water regulating valve option installed, force valve to 100% flow.	Remote
6B6	Comm Loss: Condenser Leaving Water Temperature	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5F2	Comm Loss Condenser Rfgt: Pressure	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Condenser Rfgt Pressure Output	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5F9	Comm Loss: Condenser Water Pump Starter	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
694	Comm Loss: Electronic Expansion Valve, Actuator 1	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote



Diagnostics

695	Comm Loss: Electronic Expansion Valve, Actuator 2	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5DE	Comm Loss: Emergency Stop	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5E4	Comm Loss: Evaporator Entering Water Temperature	Info and Special Action	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Chiller shall remove any Return or Constant Return Chilled Water Reset, if it was in effect. Apply slew rates per Chilled Water Reset spec.	Remote
5E3	Comm Loss: Evaporator Leaving Water Temperature	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
688	Comm Loss: Evaporator Rfgt Liquid Level	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5F0	Comm Loss: Evaporator Rfgt Pressure	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5E1	Comm Loss: Ext Ice Building Control Input	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Chiller shall revert to normal (non-ice building) mode regardless of last state.	Remote
5DD	Comm Loss: External Auto/ Stop	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote

Diagnostics

6B6	Comm Loss: External Base Load Enable	Info and Special Action	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. The external base load input is removed from the arbitration to enable Base Loading.	Remote
6B6	Comm Loss: External Base Load Setpoint Input	Info and Special Action	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. The external base load setpoint input is removed from the arbitration to establish the Base Loading Setpoint.	Remote
5E9	Comm Loss: External Base Load Setpoint Input	Info and Special Action	NonLatch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Chiller shall discontinue use of the External Chilled Water Setpoint source and revert to the next higher priority for setpoint arbitration.	Remote
5EA	Comm Loss: External Current Limit Setpoint	Info and Special Action	NonLatch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Chiller shall discontinue use of the External Current limit setpoint and revert to the next higher priority for Current Limit setpoint arbitration.	Remote
5EB	Comm Loss: High Pressure Cutout Switch	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5FA	Comm Loss: Ice-Making Status	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Chiller shall revert to normal (non-ice building) mode regardless of last state.	Remote



Diagnostics

69D	Comm Loss: Local BAS Interface	Info and Special Action	NonLatch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Use the last values sent from BAS.	Remote
6B6	Comm Loss: Master Oil Line Solenoid Valve	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Oil Loss Level Input	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5F4	Comm Loss: Oil Pressure	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Oil Return Gas Pump Drain	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Oil Return Gas Pump Fill	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6A0	Comm Loss: Op Status Programmable Relays	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5E2	Comm Loss: Outdoor Air Temperature	Info and Special Action	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period. Note that if this diagnostic occurs, Chiller shall remove any OA Chilled Water Reset, if it was in effect and if Tracer OA was unavailable. Apply slew rates per Chilled Water Reset specification.	Remote

Diagnostics

6B6	Comm Loss: Refrigerant Monitor Input	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5D2	Comm Loss: Slide Valve Load	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
5D1	Comm Loss: Slide Valve Unload	Normal	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
6B6	Comm Loss: Solid State Starter Fault Input	Info	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
690	Comm Loss: Starter	Immediate	Latch	Continual loss of communication between the MP and the Functional ID has occurred for a 30 second period.	Remote
1F5	Compressor Did Not Accelerate Fully	Immediate	Latch	Starter module did not receive an "Up to Speed" or "End of Ramp" signal from the SSS within 2.5 seconds after commanding a bypass, or after the maximum acceleration time had expired, whichever is longer. This diagnostic only applies to SSS.	Remote
EE	Compressor Did Not Accelerate: Shutdown	Immediate	Latch	The compressor did not come up to speed (get to <85%RLA) in the allotted time defined by the Maximum Acceleration Timer and the start was aborted per the starter configuration selected.	Remote

Diagnostics

1FA	Compressor Did Not Accelerate: Transition	Info	Latch	The compressor did not come up to speed (get to <85%RLA) in the allotted time defined by the Maximum Acceleration Timer and a transition was forced (motor put across the line) at that time.	Remote
284	Compressor Discharge Temperature Sensor	Immediate	Latch	Bad Sensor or LLID	Remote
9A	Condenser Entering Water Temperature Sensor	Info and Special Action	Latch	Bad Sensor or LLID. If chiller running, and condenser water regulating valve option installed, force valve to 100% flow.	Remote
5B8	Condenser Refrigerant Pressure Transducer	Normal	Latch	Bad Sensor or LLID	Remote
F7	Condenser Water Flow Lost	Immediate	NonLatch	The condenser water flow proof input was open for more than 6 contiguous seconds after flow had been proven. This diagnostic is automatically cleared once the compressor is stopped by a fixed time out of 7 sec. The Cond Pump shall be commanded off but the Evap pump command will not be effected.	Remote
DC	Condenser Water Flow Overdue	Normal	NonLatch	Condenser water flow was not proven within 20 minutes of the condenser pump relay being energized. The Cond Pump shall be commanded off. Diagnostic is reset with return of flow (although only possible with external control of pump).	Remote
EC or EC	Current Overload Trip Motor Current Overload	Immediate	Latch	Compressor current exceeded overload time vs. trip characteristic.	Local

Diagnostics

FD	Emergency Stop	Immediate	Latch	EMERGENCY STOP input is open. An external interlock has tripped. Time to trip from input opening to unit stop shall be 0.1 to 1.0 seconds.	Local
8E	Evaporator Entering Water Temperature Sensor	Info	Latch	Bad Sensor or LLID Normal operation unless Chilled Water Reset is enabled. If Chilled Water Reset is enabled and either Return or Constant Return Chilled Water Reset is selected, its effect will be removed but slew rates on the change will be limited per the Chilled Water Reset specification.	Remote
AB	Evaporator Leaving Water Temperature Sensor	Normal	Latch	Bad Sensor or LLID	Remote
27D	Evaporator Liquid Level Sensor	Normal	Latch	Bad Sensor or LLID	Remote
5BA	Evaporator Refrigerant Pressure Transducer	Normal	Latch	Bad Sensor or LLID	Remote
ED	Evaporator Water Flow Lost	Normal	NonLatch	The chilled water flow proof input was open for more than 6-10 contiguous seconds after flow had been proven. The pump command status will not be effected. 6-10 seconds of contiguous flow shall clear this diagnostic. Even though the pump may be commanded to run in the STOP modes (pump off delay time), this diagnostic shall not be called out in the STOP modes.	Remote

Diagnostics

384	Evaporator Water Flow Overdue	Normal	Latch	Evaporator water flow was not proven within 20 minutes of the chilled water pump relay being energized. The evaporator pump command status will not be effected.	Remote
5C4	Excessive Loss of Comm	Immediate	Latch	Loss of comm with 20% or more of the LLIDs configured for the system has been detected. This diagnostic will suppress the callout of all subsequent comm loss diagnostics. Check power supply(s) and power disconnects - troubleshoot LLIDS buss using TechView.	Remote
4C4	External Base Loading Setpoint	Info and Special Action	NonLatch	a. Not "Enabled": no diagnostics. b. "Enabled ": Out- Of-Range Low or Hi or bad LLID, set diagnostic, default Base Loading Setpoint to next level of priority (e.g. Front Panel SetPoint). This information diagnostic will automatically reset if the input returns to the normal range.	Remote
87	External Chilled Water Setpoint	Info	NonLatch	a. Function Not "Enabled": no diagnostics. b. "Enabled ": Out-Of-Range Low or Hi or bad LLID, set diagnostic, default Chilled Water Setpoint to next level of priority (e.g. Front Panel SetPoint). This information diagnostic will automatically reset if the input returns to the normal range.	Remote
89	External Current Limit Setpoint	Info	NonLatch	a. Not "Enabled": no diagnostics. b. "Enabled ": Out-Of-Range Low or High or bad LLID, set diagnostic, default Current Limit Setpoint to next level of priority (e.g. Front Panel SetPoint). This information diagnostic will automatically reset if the input returns to the normal range.	Remote

Diagnostics

1C2	High Compressor Discharge Temperature	Immediate	Latch	The compressor discharge temperature exceeded 88°C. This during the compressor run-unload period or after the compressor has stopped, but a run unload will be terminated early as a result.	Remote
1C6	High Differential Refrigerant Pressure	Normal	Latch	a. The system differential pressure was above 11 bar - trip immediately (normal shutdown) b. The differential pressure was above 10.5 bar - trip in 1 hour.	Remote
584	High Evaporator Liquid Level	Normal	Latch	The liquid level sensor is seen to be at or near its high end of range for 80 contiguous minutes while the compressor is running. (The diagnostic timer will hold, but not clear when the circuit is off).	Remote
6B8	High Evaporator Refrigerant Pressure	Info and Special Action	NonLatch	The evaporator refrigerant pressure has risen above 13 bar. The evaporator water pump relay will be de-energized to stop the pump regardless of why the pump is running. The diagnostic will auto reset and the pump will return to normal control when the evaporator pressures falls below 12.7 bar . This diagnostic must shutdown the chiller if it is running.	Local
F5	High Pressure Cutout	Immediate	NonLatch	A high pressure cutout was detected.	Local
1C6	High Refrigerant Pressure Ratio	Immediate	Latch	The system pressure ratio exceeded maximum value for 1 contiguous minute. This pressure ratio is a fundamental limitation of the compressor. The pressure ratio is defined as $P_{cond} (abs) / P_{evap} (abs)$.	Remote

Diagnostics

59C	Loss of Oil at Compressor (Running)	Immediate	Latch	In running modes, Oil Loss Level Sensor detects lack of oil in the oil tank feeding the compressor (distinguishing a liquid flow from a vapor flow).	Local
59D	Loss of Oil at Compressor (Stopped)	Immediate and Special Action	Latch	Oil Loss Level Sensor detects a lack of oil in the oil tank feeding the compressor for 90 seconds after EXV preposition is completed. Note: Compressor start is delayed while waiting for oil to be detected.	Local
C5	Low Chilled Water Temp: Unit Off	Info and Special Action	NonLatch	The leaving chilled water temp. fell below the leaving water temp cutout setting (integrated value) while the chiller is in the Stop mode, or in Auto mode with no compressors running. Energize evaporator water pump relay until diagnostic auto resets, then return to normal evaporator pump control. Automatic reset occurs when the temp rises the cutout setting for 30 minutes.	Remote
C6	Low Chilled Water Temp: Unit On	Immediate and Special Action	NonLatch	The chilled water temp. fell below the cutout setpoint (integrated value) while the compressor was running. Automatic reset occurs when the temperature rises 2 cutout setting for 2 minutes. This diagnostic shall not de-energize the Evaporator Water Pump Output.	Remote
1AE	Low Differential Refrigerant Pressure	Immediate	Latch	The system differential pressure was either below 1.6 bar (integrated value).	Remote
18E	Low Discharge Superheat	Normal	Latch	While Running Normally, the Discharge Superheat was less than 7°C (integrated value). At startup the Unit Control Module shall ignore the Discharge Superheat for 5 min.	Remote

Diagnostics

583	Low Evaporator Liquid Level	Info	NonLatch	The liquid level sensor is seen to be at or near its low end of range (lower than 21.2mm) for 80 continuous minutes while the compressor is running.	Remote
B5	Low Evaporator Refrigerant Pressure	Immediate	Latch	The Evaporator Refrigerant Pressure dropped below 0.7bar abs. just prior to compressor start. The pressure fell below 0.7bar abs while running but before the 1 minute ignore time had expired or fell below 1.1 bar abs. after the 1 minute ignore time had expired.	Local
FB	Low Evaporator Refrigerant Temperature	Immediate	Latch	<p>a. The inferred Saturated Evaporator Refrigerant Temperature (calculated from suction pressure transducer(s)) dropped below the Low Refrigerant Temperature Cutout Setpoint while the circuit was running after the ignore period had expired.(1 minute).</p> <p>b. During the timeout of the trip integral, the unload solenoid(s) of the running compressors on the circuit, shall be energized continuously and the load solenoid shall be off. Normal load/unload operation will be resumed if the trip integral is reset by return to temps above the cutout setpoint.</p>	Remote
6B3	Low EvaporatorTemp: Unit Off	Info and Special Action	NonLatch	The evaporator saturated temperature fell below the water temperature cutout setting (integrated value) while the respective evaporator liquid level was greater than -21.2mm while chiller is in the Stop mode, or in Auto mode with no compressors running. Energize evaporator water pump relay until diagnostic auto resets, then return to normal evaporator pump control. Automatic reset occurs when either the evaporator temperature rises the cutout setting or the liquid level falls below -21.2mm for 30 minutes.	Remote

Diagnostics

198	Low Oil Flow	Immediate	Latch	The oil pressure was out of the acceptable pressure range for 15 seconds.	Local
E2	Momentary Power Loss	Immediate	NonLatch	Momentary Power Loss option disabled: No effect. Momentary Power Loss option enabled: A loss of power on 3 line cycles or more was detected. Diagnostic is reset in 30 seconds. See Momentary Power Loss Protection specification for additional information.	Remote
1AD	MP Application Memory CRC Error	Immediate	Latch	Application software inside the MP failed its own checksum test. Possible causes: application software in the MP is not complete - software download to the MP was not completed successfully - or MP hardware problem. Note: User should attempt to reprogram the MP if this diagnostic occurs.	Remote
6A1	MP: Could not Store Starts and Hours	Info	Latch	MP has determined there was an error with the previous power down store. Starts and Hours may have been lost for the last 24 hours.	Remote
5FF	MP: Invalid Configuration	Immediate	Latch	MP has an invalid configuration based on the current software installed.	Remote
6A2	MP: Non-Volatile Block Test Error	Info	Latch	MP has determined there was an error with a block in the Non-Volatile memory. Check settings. MP has determined there was an error in a sector of the Non-Volatile memory and it was reformatted. Check settings.	Remote

Diagnostics

69C	MP: Non-Volatile Memory Reformat	Info	Latch	MP has determined there was an error in a sector of the Non-Volatile memory and it was reformatted. Check settings.	Remote
D9	MP: Reset Has Occurred	Info	NonLatch	The main processor has successfully come out of a reset and built its application. A reset may have been due to a power up, installing new software or configuration. This diagnostic is immediately and automatically cleared and thus can only be seen in the Historic Diagnostic List in TechView.	Remote
297	No Differential Refrigerant Pressure	Immediate	Latch	The system differential pressure was below 0.5bar. The occurrence of this diagnostic will saturate the above "Low Diff Rfgt Press" Integral and invoke the same "Compressor Cool Down" operating mode.	Remote
1E1	Oil Flow Protection Fault	Immediate	Latch	The Oil Pressure Transducer for this Chiller is reading a pressure either above its Condenser Pressure by 1 bar or more, or below its Evaporator Pressure 0.7 bar or more for 30 seconds continuously.	Local
5BE	Oil Pressure Transducer	Normal	Latch	Bad Sensor or LLID	Remote
A1	Outdoor Air Temperature Sensor	Info and Special Action	Latch	Bad Sensor or LLID. This diagnostic will only occur if OA sensor is configured. OA Chilled water reset will be suspended if selected and Tracer OA unavailable.	Remote
D7	Over Voltage	Immediate	Latch	Average of all monitored Line voltages above +10% of nominal.	Remote

Diagnostics

E4	Phase Loss	Immediate	Latch	<p>a. No current was sensed on 1 or 2 of the current transformer inputs while running or starting (See Nonlatching Power Loss Diagnostic for all three phases lost while running).</p> <p>b. If phase reversal protection is enabled and current is not sensed on 1 or more current transformer inputs. Logic will detect and trip in a maximum of 0.3 second from compressor start.</p>	Local
E5 or E5	Phase Reversal	Immediate	Latch	A phase reversal was detected on the incoming current. On a compressor startup the phase reversal logic must detect and trip in a maximum of 0.3 second from compressor start.	Local
E3	Phase Unbalance Severe Current Imbalance	Normal	Latch	A 30% Phase c Current Unbalance imbalance has been detected on 1 phase relative to the average of all 3 phases for 90 continuous seconds.	Remote
1A0	Power Loss	Immediate	NonLatch	<p>The compressor had previously established currents while running and then all 3 phases of current were lost. Note: This diagnostic prevents nuisance latching diagnostics due to a momentary power loss - It does not protect motor/compressor from uncontrolled power reapplication. See Momentary Power Loss Diagnostic for this protection. This diagnostic will auto reset in 10 seconds from its occurrence, and is not active during the start mode before the transition complete input is proven. This prevents the chiller from cycling due to some internal starter problem, as the starter would latch out on either a "Starter Fault Type 3" or a "Starter Did Not Transition" latching diagnostic. However true power loss occurring during a start would result in a misdiagnosis and the chiller would not automatically recover.</p>	Remote

Diagnosics

2F2	Refrigerant Monitor Sensor	Info	NonLatch	Open or Shorted input and the Rfgr Monitor is setup as installed.	Remote
28C	Restart Inhibit Warning	Info	NonLatch	The Restart Inhibit was invoked on a compressor. This indicates excessive chiller cycling which should be corrected.	Remote
189	Solid State Starter Fault	Immediate	Latch	The Solid State Starter Fault Relay is open.	Local
188	Starter Dry Run Test	Immediate	Latch	While in the Starter Dry Run Mode either 50 % Line Voltage was sensed at the Potential Transformers or 10 % RLA Current was sensed at the Current Transformers.	Local
5CD	Starter Comm Loss with MP	Immediate	Latch	Starter has had a loss of communication with the MP for a 15 second period.	Local
CA	Starter Contactor Interrupt Failure	Immediate and Special Mode Action	Latch	Detected compressor currents greater than 10% RLA on any or all phases when the compressor was commanded off. Detection time shall be 5 seconds minimum and 10 seconds maximum. On detection and until the controller is manually reset: generate diagnostic, energize the appropriate alarm relay, continue to energize the Evaporator and Condenser Pump Outputs, continue to command the affected compressor off, fully unload the effected compressor. For as long as current continues, perform liquid level and oil return gas pump control.	Local

Diagnostics

F0	Starter Did Not Transition	Immediate	Latch	The starter module did not receive a transition complete signal in the designated time from its command to transition.	Local
6A3	Starter Failed to Arm/Start	Info	Latch	Starter failed to arm or start within the allotted time (15 seconds).	Remote
1E9	Starter FaultType I	Immediate	Latch	This is a specific starter test where 1M(1K1) is closed first and a check is made to ensure that there are no currents detected by the CT's. If currents are detected when only 1M is closed first at start, then one of the other contactors is shorted.	Local
1ED	Starter FaultType II	Immediate	Latch	This is a specific starter test where the Shorting Contactor (1K3) is individually energized and a check is made to ensure that there are no currents detected by the CT's. If current is detected when only S is energized at Start, then 1M is shorted.	Local
1F1	Starter FaultType III	Immediate	Latch	As part of the normal start sequence to apply power to the compressor, the Shorting Contactor (1K3) and then the Main Contactor (1K1) were energized. 1.6 seconds later there were no currents detected by the CT's for the last 1.2 seconds on all 3 phases.	Local
5C5	Starter Module Memory ErrorType 1	Info	Latch	Checksum on RAM copy of the Starter LLID configuration failed. Configuration recalled from EEPROM.	Local

Diagnostics

5C9	Starter Module Memory Error Type 2	Immediate	Latch	Checksum on EEPROM copy of the Starter LLID configuration failed. Factor default values used.	Local
3D7	Transition Complete Input Opened	Immediate	Latch	The Transition Complete input is open with the compressor motor running after a successful completion of transition. This is active only for all electromechanical starters.	Local
3D5	Transition Complete Input Shorted	Immediate	Latch	The Transition Complete input is shorted before the compressor was started. This is active for all electromechanical starters.	Local
D8	Under Voltage	Normal	Non-Latch	Average of all monitored Line voltages below -10% of nominal.	Remote

Maintenance Contract

It is strongly recommended that you sign a maintenance contract with your local Service Agency. This contract provides regular maintenance of your installation by a specialist in our equipment. Regular maintenance helps ensure that any malfunction is detected and corrected quickly and minimizes the possibility that serious damage will occur. Finally, regular maintenance helps ensure the maximum operating life of your equipment. We would remind you that failure to respect these installation and maintenance instructions may result in immediate cancellation of the warranty.

Training

The equipment described in this manual is the result of many years of research and continuous development. To assist you in obtaining the best use of it, and maintaining it in perfect operating condition over a long period of time, the constructor has at your disposal a refrigeration and air conditioning service school. The principal aim of this is to give operators and maintenance technicians a better knowledge of the equipment they are using, or that is under their charge. Emphasis is particularly given to the importance of periodic checks on the unit operating parameters as well as on preventive maintenance, which reduces the cost of owning the unit by avoiding serious and costly breakdowns.

Notes



Notes

Notes





Trane
A business of American Standard Companies
www.trane.com


For more information contact your local
district office or e-mail us at comfort@trane.com

Literature Order Number	RLC-SVU03A-E4
Date	0903
Supersedes	New
Stocking Location	Europe


Trane has a policy of continuous product and product data improvement and reserves the right to change design and specifications without notice. Only qualified technicians should perform the installation and servicing of equipment referred to in this publication.

Société Trane – Société Anonyme au capital de 61 005 000 Euros – Siège Social: 1 rue des Amériques –
88190 Golbey – France – Siret 306 050 188-00011 – RSC Epinal B 306 050 188
Numéro d'identification taxe intracommunautaire: FR 83 3060501888

	RTHD	C	5712-2328	1 / 1
		Date : 15-12-2003 Rev : /		
		 Std		



CHAÎNE DE SECURITE
SICHERHEITSKETTE
SAFETY CHAIN
CAVO DI SICUREZZA
VEILIGHEIDSKABEL
CADENA DE SEGURIDAD



RTHD	POIDS MAXI MAXI GEWICHT MAXI WEIGHT PESO MASSIMO MAXMAALGEWICHT PESO MAXIMO (Kg)	DIMENSIONS DIMENSIONEN DIMENSIONS DIMENSIONI AFMETINGEN DIMENSIONES (mm)						CENTRE DE GRAVITE SCHWERPUNKT CENTER OF GRAVITY CENTRO DI GRAVITA MIDDELPUNT VAN DE ZWAARTEKRACHT CENTRO DE GRAVEDAD (mm)		
		A	B	C	(D)	E (2x)	F (2x)	X	Y	Z
B1 B1 B1	4215	2100	103	1153	600	1900	1650	581	1476	902
B1 C1 D1	4462	2100	99	925	600	1950	1700	568	1480	853
B2 B1 B1	4215	2100	103	1153	600	1900	1650	581	1476	902
B2 C1 D1	4462	2100	99	925	600	1950	1700	568	1480	853
C1 D6 E5	5797	2100	226	1198	600	1900	1650	662	1521	1022
C1 D5 E4	5884	2100	226	1198	600	1900	1650	662	1521	1022
C1 D3 E3	6351	2100	226	1198	600	1900	1650	662	1521	1022
C2 D6 E5	5797	2100	226	1198	600	1900	1650	662	1521	1022
C2 D5 E4	5884	2100	226	1198	600	1900	1650	662	1521	1022
C2 E1 F1	6639	1900	136	957	600	1950	1750	670	1612	1040
D1 D4 E4	5883	2100	226	1198	600	1900	1650	662	1521	1022
D1 D3 E3	6351	2100	226	1198	600	1900	1650	662	1521	1022
D2 D1 E1	6551	2100	226	1198	600	1900	1650	662	1521	1022
D3 D1 E1	6551	2100	226	1198	600	1900	1650	662	1521	1022
D2 F1 F2	7353	1900	41	956	600	1950	1750	703	1611	970
D3 F1 F2	7353	1900	41	956	600	1950	1750	703	1611	970
D1 G1 G1	8129	3500	38	1760	600	1950	1650	783	1615	954
D2 G2 G1	8516	3500	38	1760	600	1950	1650	783	1615	954
D3 G2 G2	8666	3500	38	1760	600	1950	1650	783	1615	954
E3 D2 E2	6676	2100	226	1198	600	1900	1650	662	1521	1022
E3 F2 F3	7690	1900	41	956	600	1950	1750	703	1611	970
E3 G3 G3	8913	3500	38	1760	600	1950	1650	783	1615	954

INSTRUCTIONS DE LEVAGE ET DE MANUTENTION

IL EST RECOMMANDE D'UTILISER LES ORGANES DE LEVAGE ET DE MANUTENTION MONTRES PAR LE SCHEMA A GAUCHE ET DE SUIVRE LES INSTRUCTIONS SUIVANTES :

- 1 - UTILISER LES 4 POINTS D'ANCRAGE PREVUS SUR L'UNITE.
- 2 - ATTACHER LA CHAÎNE (CABLE) DE SECURITE COMME INDIQUE, SANS TENSION, AFIN D'EVITER QUE L'UNITE NE SE RENVERSE.
- 3 - LES ELINGUES ET LE PALONNIER DOIVENT ETRE PREVUS PAR L'INSTALLATEUR.
- 4 - LA CHARGE MINIMUM ADMISSIBLE PAR ELINGUE ET PAR LE PALONNIER UTILISES NE DOIT PAS ETRE INFERIEURE AU POIDS DE L'UNITE.
- 5 - ATTENTION : CETTE UNITE DOIT ETRE LEVEE ET MANUTENTIONNEE AVEC PRECAUTIONS. EVITER LES A-COUPS LORS DU LEVAGE ET DE LA MANUTENTION.

ANWEISUNGEN FUER DEN TRANSPORT MIT HEBEZEUG

ES WIRD EMPFOHLEN, DIE MASCHINE ENTSPRECHEND DER ZEICHNUNG MIT EINEM KRAN ANZUHEBEN UND DIE FOLGENDEN ANWEISUNGEN ZU BEACHTEN :

- 1 - JEDE MASCHINE WIRD MIT 4 IM WERK MONTIERTEN KRANOESEN GELIEFERT.
- 2 - SICHERHEITSKETTE (KABEL) OHNE SPANNUNG ANBRINGEN. DIENT NICHT ZUM ANHEBEN SONDERN UM UMFALLEN DER MASCHINE ZU VERMEIDEN.
- 3 - DAS HEBEZEUG (SEILE, QUERBALKEN) IST BEIZUSTELLEN.
- 4 - DIE TRAGKRAFT JEDES EINZELNEN SEILES SOWIE DES QUERBALKENS MUSS MINDESTENS DEM TRANSPORTGEWICHT DER MASCHINE ENTSPRECHEN.
- 5 - BEIM ANHEBEN VORSICHTIG VORGEHEN, STOESSE UND ERSCHUETTERUNGEN UNBEDINGT VERMEIDEN.

SPECIAL LIFTING AND MOVING INSTRUCTIONS

IT IS RECOMMENDED TO USE THE SPECIAL BUILT-IN RIGGING POINTS SHOWN IN THE DIAGRAM LEFT AND TO FOLLOW THE FOLLOWING INSTRUCTIONS :

- 1 - USE THE FOUR RIGGING POINTS WHICH ARE BUILT INTO THE UNIT.
- 2 - ATTACH SAFETY CHAIN (CABLE) AS SHOWN WITHOUT TENSION, NOT AS A LIFTING CHAIN BUT TO PREVENT UNIT FROM ROLLING.
- 3 - SLINGS AND A SPREADER BAR ARE TO BE PROVIDED BY THE RIGGER.
- 4 - THE MINIMUM LIFTING CAPACITY OF EACH SLING AS WELL AS THE SPREADER BAR MUST BE EQUAL OR HIGHER THAN THE TABULATED UNIT SHIPPING WEIGHT.
- 5 - CAUTION : THIS UNIT MUST BE LIFTED AND HANDLED WITH CARE. AVOID SHOCKS WHILE HANDLING.

ISTRUZIONI PER IL SOLLEVAMENTO E LA MOVIMENTAZIONE DELL'UNITA

SI RACCOMANDA DI SEGUIRE LE ISTRUZIONI QUI RIPORTATE PER IL SOLLEVAMENTO E LA MOVIMENTAZIONE DELL'UNITA :

- 1 - L'UNITA VIENE FORNITA COMPLETA DI 4 FORI DI SOLLEVAMENTO.
- 2 - ATTACCARE IL CAVO DI SICUREZZA COME MOSTRATO, SENZA TENDERLO, PER EVITARE CHE LA MACCHINA SI ROVESCI.
- 3 - IMBRAGATURE E BARRE DISTANZIATRICI DEVONO ESSERE FORNITE DALL'INSTALLATORE E FISSATE AI 4 FORI DI SOLLEVAMENTO.
- 4 - LA CAPACITA MINIMA NOMINALE DI SOLLEVAMENTO (VERTICALE) DI CIASCUNA IMBRAGATURA E BARRA DISTANZIATRICE NON DEVE ESSERE INFERIORE AL PESO DI SPEDIZIONE DELL'UNITA.
- 5 - ATTENZIONE : EFFETTUARE IL SOLLEVAMENTO DELL'UNITA CON LA MASSIMA CURA, EVITARE CARICHI ECCESSIVI, SOLLEVARE LENTAMENTE E UNIFORMEMENTE.

HIJS EN TRANSPORT INSTRUCTIES

DE TOE TE PASSEN HIJSMETHODE IS ALS VOLGT VOORGESCHREVEN :

- 1 - OP DE UNIT ZIJN VIER HIJSOGEN AANGEBRACHT.
- 2 - SLUIT DE VEILIGHEIDSKABEL ZOALS OPTEKENING STAAT AANGEGEVEN ZONDER SPANNING AAN.
DEZE KABEL IS NIET BEDOELD ALS HIJSKABEL MAAR ALLEEN OM DE MACHINE TEGEN OM VALLLEN TE BEVEILIGEN.
- 3 - STROPEN EN SPREIDBALK DIENEN DOOR HET KRAANBEDRIJF TE VORDEN TOEGELEVERD EN OP DE AANGEGEVEN MANIER TE WORDEN BEVESTIGD.
- 4 - DE MAXIMAAL TOEGESTANE VERTIKALE HIJSCAPACITEIT VAN ELKE STROP EN DE SPREIDBALK MAG NIET MINDER ZIJN DAN HET TRANSPORTGEWICHT UIT DE TABEL.
- 5 - WAARSCHUWING : DEZE MACHINE VOORZICHTIG VERPLAATSEN. VOORKOM SCHOKKEN EN STOTEN BIJ HET HIJSEN.

INSTRUCCIONES DE TRANSPORTE Y DESCARGA

SE RECOMIENDA SEGUIR LAS INSTRUCCIONES SIGUIENTES PARA LA CARGA Y DESCARGA DE LA UNIDAD :

- 1 - LA MAQUINA ESTA PROVISTA DE CUATRO PUNTOS DE ENGANCHE.
- 2 - ATAR LA CADENA DE SEGURIDAD COMO INDICADO, SIN TENSARLA, PARA IMPEDIR QUE LA MAQUINA SE RETORNA.
- 3 - LOS CABLES Y LA BARRA SEPARADORA DEBEN SER SUMINISTRADOS POR EL INSTALADOR Y FIJADOS A LOS CUATRO PUNTOS DE ENGANCHE.
- 4 - LA CAPACIDAD MINIMA DE CARGA (VERTICAL) DE CADA CABLE Y DE LA BARRA SEPARADORA NO DEBERA SER INFERIOR AL PESO DE LA UNIDAD.
- 5 - ATENCION : ESTA UNIDAD DEBE SER DESCARGADA CON EL MAYOR CUIDADO PARA EVITAR CHOQUES. DESCARGAR DESPACIO Y CUIDADOSAMENTE.

C	5712-2328	1 / 1
---	-----------	-------




















Fig. 1 is a side view of the machine assembly. It shows the main body with a large circular component (16) on the right side. The assembly is mounted on a base. Dimensions are indicated: 2745 (total width), 2500 (width to the center of the main body), 186 (height of the main body), 137 (height of the base), 948 (height of the base), and 664 (height of the base). Labels (21) and (20) point to specific components on the top. Label (23) points to a component on the right side. Arrows F and E indicate directions.

 TRANE®	RTHD	C	5712-2977	1 / 1
		Date : 05-12-2003 Rev : A		
			Std	
C1 D6 E5 - C1 D5 E4 - C1 D3 E3 - C2 D6 E5 - C2 D5 E4 - C2 E1 F1 D1 D4 E4 - D1 D3 E3 - D2 D1 E1 - D3 D1 E1 E3 D2 E2				



		RTHD		C 5712-2980 1 / 1						
				Date : 05-12-2003 Rev : B						
				 Std						
										
(1) EVAPORATEUR	VERDAMPFER	EVAPORATOR								
(2) CONDENSEUR	VERFLUESSIGER	CONDENSER								
(3) COMPRESSEUR	VERDICHTER	COMPRESSOR								
(4) RESERVOIR D'HUILE	OELTANK	OIL TANK								
(5) SEPARATEUR D'HUILE	OELABSCHIEDER	OIL SEPARATOR								
(6) ARMOIRE ELECTRIQUE	STEUERSCHRANK	ELECTRICAL PANEL								
(7) ACCES RACCORDEMENT CLIENT PUISSANCE	ABDECKPLATTE FÜR BAUSEITIGE KABELINFÜHRUNG	POWER CABLE GLAND PLATE FOR CUSTOMER WIRING								
(8) ACCES RACCORDEMENT CLIENT CONTRÔLE ET REGULATION	ABDECKPLATTE FÜR BAUSEITIGE STEUERVERKABELUNG	EXTERNAL CONTROL WIRING CABLE GLAND PLATE FOR CUSTOMER WIRING								
(9) CONNEXION ENTREE EAU EVAPORATEUR	WASSER- EINTRITT- VERDAMPFER	EVAPORATOR WATER INLET CONNECTION								
(10) CONNEXION SORTIE EAU EVAPORATEUR	WASSER- AUSTRITT- VERDAMPFER	EVAPORATOR WATER OUTLET CONNECTION								
(11) CONNEXION ENTREE EAU CONDENSEUR	WASSER- EINTRITT- VERFLUESSIGER	CONDENSER WATER INLET CONNECTION								
(12) CONNEXION SORTIE EAU CONDENSEUR	WASSER- AUSTRITT- VERFLUESSIGER	CONDENSER WATER OUTLET CONNECTION								
(13) AIRE CONSEILLEE POUR MAINTENANCE	MINDEST- WANDABSTAND (ZUR WARTUNG)	MINIMUM CLEARANCE (FOR MAINTENANCE)								
(14) AIRE NECESSAIRE POUR LE RETUBAGE DES ECHANGEURS (D'UN COTE OU DEL'AUTRE)	MINDEST- WANDABSTAND (FÜR DEN AUSBAU DER ROHRE AUS DEM VERDAMPFER/VERFLUESSIGER) AUF EINER DER BEIDEN STIRNSEITEN DER MASCHINE	MINIMUM CLEARANCE (TO REINSTALL EVAPORATOR AND CONDENSER TUBES) AT EITHER END OF THE UNIT								
(15) POINTS DE LEVAGE Ø 55	TRANSPORT- OESEN Ø 55	RIGGING EYES Ø 55								
(16) RACCORDEMENT SOUPAPE BASSE PRESSION : 3/4" G MALE	ANSCHLUSS ÜBERSTRÖM VENTIL NIEDERDRUCK- SEITE : 3/4" GASGEWINDE (AUSSERGEWINDE)	LOW PRESSURE RELIEF VALVE CONNECTION : 3/4" G MALE								
(17) CHARGE DE FLUIDE FRIGORIGENE (Kg)	KAELTEMITTEL- FUELLUNG (Kg)	REFRIGERANT CHARGE (Kg)								
(18) CHARGE D'HUILE (Litres)	OELFUELLUNG (Liter)	OIL CHARGE (Litres)								
(19) MASSE EN FONCTIONNEMENT (Kg)	BETRIEBSGEWICHT (Kg)	OPERATING WEIGHT (Kg)								
OPTIONS		OPTIONS								
(20) MANOMETRES	MANOMETER	PRESSURE GAUGES								
(21) VANNES D'ISOLEMENT	ABSPERRVENTILE	ISOLATING VALVES								
(22) SECTIONNEUR PUISSANCE	SCHALTSCHRANK HAUPTSCHALTER	DISCONNECT SWITCH								
(23) RACCORDEMENT SOUPAPE HAUTE PRESSION : 3/4" G MALE	ANSCHLUSS ÜBERSTRÖM VENTIL HOCHDRUCK- SEITE : 3/4" GASGEWINDE (AUSSERGEWINDE)	HIGH PRESSURE RELIEF VALVE CONNECTION : 3/4" G MALE								
A LA LONGUEUR MENTIONNEE EST SANS LES BOITES A EAU. POUR CALCULER LA LONGUEUR TOTALE, VOIR LE PLAN DES BOITES A EAU.	DIE ANGEGEBENE LAENGE IST OHNE WASSERDECKEL. ZUR BERECHNUNG DER GESAMTLAENGE DER MASCHINE, SIEHE MASSZEICHNUNG WASSERDECKEL	THE LENGTH MENTIONNED IS WITHOUT WATERBOXES. FOR CALCULATION OF THE TOTAL UNIT LENGTH, SEE WATERBOXES DRAWING								
B LARGEUR SANS ARMOIRE ELECTRIQUE	BREITE OHNE STEUERSCHRANK	WIDTH WITHOUT ELECTRICAL PANEL								
C DIMENSIONS ET POSITION DES BASES	ABMESSUNGEN UND POSITIONNIERUNG DER STUETZEN	BASE DIMENSIONS AND POSITION								
D UNITE AVEC BOITES A EAU	KÜHLMASCHINE MIT WASSERDECKEL	UNIT WITH WATERBOXES								
E MAIN DROITE	RECHTE SEITE	RIGHT HAND								
F MAIN GAUCHE	LINKE SEITE	LEFT HAND								
G EVAPORATEUR 2 PASSES	VERDAMPFER MIT 2 DURCHGÄNGEN	2 PASSES EVAPORATOR								
H EVAPORATEUR 3 PASSES	VERDAMPFER MIT 3 DURCHGÄNGEN	3 PASSES EVAPORATOR								
J EVAPORATEUR 4 PASSES	VERDAMPFER MIT 4 DURCHGÄNGEN	4 PASSES EVAPORATOR								
K EVAPORATEUR 6 PASSES	VERDAMPFER MIT 6 DURCHGÄNGEN	6 PASSES EVAPORATOR								
L CONDENSEUR 2 PASSES	VERFLUESSIGER MIT 2 DURCHGÄNGEN	2 PASSES CONDENSER								
M LONGUEUR MANCHETTE (ACCESSOIRE)	LAENGE DER KANNELIERTEN PFEIFE (ZUBEHOER)	LENGTH OF THE GROOVED PIPE STUB (ACCESSORY)								
RTHD	B1 B1 B1 B1 C1 D1	B2 B1 B1 B2 C1 D1 C1 D6 E5 C1 D5 E4 C1 D3 E3 C2 D6 E5 C2 D5 E4 C2 E1 F1								
(17)	186	222	186	222	222	222	222	222	222	238
(18)	17	17	17	17	23	23	23	23	23	38
(19)	4476	4787	4476	4787	6077	6202	6824	6077	6202	7175

(1) EVAPORATORE	ITALIANO	VERDAMPFER	NEDERLANDS	EVAPORADOR	ESPAÑOL						
(2) CONDENSATORE		CONDENSOR		CONDENSADOR							
(3) COMPRESSORE		COMPRESSOR		COMPRESOR							
(4) SERBATOIO OLIO		OLIETANK		TANQUE DE ACEITE							
(5) SEPARATORE OLIO		OLIEAFSCHEIDER		SEPARADOR DE ACEITE							
(6) PANNELLO ELETTRICO		ELEKTRISCH PANEEL		PANEL ELECTRICO							
(7) ACCESSO RACCORDI CLIENTE ALIMENTAZIONE DI POTENZA		BLINDPLAAT TEN BEHOEVE VAN VOEDINGSKABEL KLANT		ACCESO PARA EL CABLEADO DE FUERZA A REALISAR POR EL CLIENTE							
(8) ACCESSO RACCORDI CLIENTE CONTROLLO E REGOLAZIONE		BLINDPLAAT TEN BEHOEVE VAN AANSLUITKABEL DOORMELDINGEN KLANT		ACCESO PARA EL CABLEADO DE CONTROL EXTERNO A REALISAR POR EL CLIENTE							
(9) COLLEGAMENTO INGRESSO ACQUA EVAPORATORE		VERDAMPFER WATERINLAAT		CONEXION DE ENTRADA DE AGUA AL EVAPORADOR							
(10) COLLEGAMENTO USCITA ACQUA EVAPORATORE		VERDAMPFER WATERUULAAT		CONEXION DE SALIDA DE AGUA AL EVAPORADOR							
(11) COLLEGAMENTO INGRESSO ACQUA CONDENSATORE		CONDENSOR WATERINLAAT		CONEXION DE ENTRADA DE AGUA AL CONDENSADOR							
(12) COLLEGAMENTO USCITA ACQUA CONDENSATORE		CONDENSOR WATERUULAAT		CONEXION DE SALIDA DE AGUA AL CONDENSADOR							
(13) MINIMO SPAZIO DI SERVIZIO		GEADVISEERDE VRIJE RUIMTE VOOR ONDERHOUD		ESPACIO LIBRE MINIMO PARA MANTENIMIENTO							
(14) SPAZIO NECESSARIO PER LA SOSTITUZIONE DEI TUBI DEL EVAPORATORE E DELL' CONDENSATORE		GEADVISEERDE RUIMTE VOOR HET TREKKEN EN HET OP NIEUW AANBRENGEN VAN PIJPEN VAN VERDAMPFER EN CONDENSOR		ESPACIO NECESARIO PARA SACAR LOS TUBOS DEL EVAPORADOR O DEL CONDENSADOR							
(15) GOLFARI Ø 55		HJUSØGEN Ø 55		PUNTOS DE ELEVACION Ø 55							
(16) RACCORDO VALVOLA DI SCARICO BASSA PRESSIONE : MASCHIO 3/4"G		AANSLUITING LAGEDRUKONTLASTKLEP : 3/4"G PEN (MANNELIJKE AANSLUITING)		CONEXION DE LA VALVULA DE ALVIO DE BAJA PRESION : MACHO G 3/4"							
(17) CARICA DI FLUIDO FRIGORIGENO (Kg)		KOELMIDDELVULLING (Kg)		CARGA DE REFRIGERANTE (Kg)							
(18) CARICA D'OLIO (Litri)		OLIEVULLING (Liters)		CARGA DE ACEITE (L.litros)							
(19) PESO IN FUNZIONAMENTO (Kg)		BEDRIJFSGEWICHT (Kg)		PESO EN OPERACION (Kg)							
OPZIONI		TOEBEHOREN		OPCIONES							
(20) MANOMETRI		MANOMETERS		MANOMETROS							
(21) VALVOLE DI INTERCETTAZIONE		ISOLATIEKLEPPEN		VALVULAS DE SERVICIO							
(22) SEZIONATORE DI POTENZA		HOOFDSCHAKELAAR		SECCIONADOR DE FUERZA							
(23) RACCORDO VALVOLA DI SCARICO ALTA PRESSIONE : MASCHIO 3/4"G		AANSLUITING HOGEDRUKONTLASTKLEP : 3/4"G PEN (MANNELIJKE AANSLUITING)		CONEXION DE LA VALVULA DE ALVIO DE ALTA PRESION : MACHO G 3/4"							
A	LA LUNGHEZZA INDICATA NON COMPRENDE L'INGOMBRO DELLE CASSE D'ACQUA. PER CONOSCERE LA LUNGHEZZA TOTALE, VEDERE LO SCHEMA DELLE CASSE D'ACQUA	DE VERMELDE LENGTE IS ZONDER WATERKASTEN. VOOR HET BEPALEN VAN DE TOTALE LENGTE, ZIE TEKENING WATERKASTEN		PARA CALCULAR LA LONGITUD TOTAL DE LA MAQUINA, HAJ QUE ANADIR LOS CAJAS DE AGUA, REMITASE A LA ILUSTRACION DE LOS CAJAS DE AGUA							
B	LARGHEZZA SENZA PANNELLO ELETTRICO	BREEDTE ZONDER ELEKTRISCH PANEEL		ANCHURA SIN EL PANEL ELECTRICO							
C	DIMENSIONI DELLA BASE E POSIZIONE	BASIS AFMETINGEN EN POSITIE		DIMENSIONS Y POSICION DE LA BASE							
D	UNITA CON CASSE D'ACQUA	UNIT MET WATERKASTEN		UNIDAD CON CAJAS DE AGUA							
E	DESTRA	RECHTS		DERECHA							
F	SINISTRA	LINKS		IZQUIERDA							
G	EVAPORATORE 2 CANALI	VERDAMPFER 2 DOORGANGEN		EVAPORADOR 2 PASOS							
H	EVAPORATORE 3 CANALI	VERDAMPFER 3 DOORGANGEN		EVAPORADOR 3 PASOS							
J	EVAPORATORE 4 CANALI	VERDAMPFER 4 DOORGANGEN		EVAPORADOR 4 PASOS							
K	EVAPORATORE 6 CANALI	VERDAMPFER 6 DOORGANGEN		EVAPORADOR 6 PASOS							
L	CONDENSATORE 2 CANALI	CONDENSOR 2 DOORGANGEN		CONDENSADOR 2 PASOS							
M	LUNGHEZZA DEL TRONCHETTO (ACCESSORIO)	LENGTE LASSTOMP TEGENVICTAULIC (TOEBEHOREN)		LONGITUD DEL CARRETE VICTAULIC (OPCIONAL)							
D1 D4 E4	D1 D3 E3	D2 D1 E1	D3 D1 E1	D2 F1 F2	D3 F1 F2	D1 G1 G1	D2 G2 G1	D3 G2 G2	E3 D2 E2	E3 F2 F3	E3 G3 G3
215	215	215	215	284	284	318	318	318	215	284	318
23	23	23	23	38	38	42	42	42	23	38	42
6201	6824	6978	6978	7955	7955	8943	9360	9555	7134	8326	9882


131 —
132 —
133 —
134 —
135 —
136 —
137 —
138 —
139 —
140 —
141 —
142 —
143 —
144 —
145 —
146 —
147 —
148 —
149 —
150 —
151 —
152 —
153 —
154 —
155 —
156 —
157 —
158 —
159 —
160 —
161 —
162 —
163 —
164 —
165 —
166 —
167 —
168 —
169 —
170 —
171 —
172 —
173 —
174 —
175 —
176 —
177 —
178 —
179 —
180 —
181 —
182 —
183 —
184 —
185 —
186 —
187 —
188 —
189 —

/1. 130

4


TRANE A DIVISION OF AMERICAN STANDARD INC. ALL RIGHTS ARE RESERVED THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN CONSENT OF TRANE		2309-1697 X	REV SHEET 3/6 A
DRAWN BY: FLEUROT @ DATE: 21-10-03			
REPLACES: /			
REVISION DATE: 14-11-03			
SIMILAR TO: /			
DEMARRAGE ETOILE TRIANGLE — STERN-DREIECK ANLAUF — WYE-DELTA START		RTHD	

EISBEHALTERBETRIEB




ALIMENTATION SEPARÉE
STEUEERSPANNUNG
SEPARATE SUPPLY


STROMUNGSWÄRMER VERDAMPFER






VERDAMPFER WASSERPUMPE



VERFLÜSSIGER WASSERPUMPE



ERDUNGSGEFÜHRER RELAYS



/4. 191

190 —
191 —
192 —
193 —
194 —
195 —
196 —
197 —
198 —
199 —
200 —
201 —
202 —
203 —
204 —
205 —
206 —
207 —
208 —
209 —
210 —
211 —
212 —
213 —
214 —
215 —
216 —
217 —
218 —
219 —
220 —
221 —
222 —
223 —
224 —
225 —
226 —
227 —
228 —
229 —
230 —
231 —
232 —
233 —
234 —
235 —
236 —
237 —
238 —
239 —
240 —
241 —
242 —
243 —
244 —
245 —
246 —
247 —
248 —
249 —
250 —
251 —
252 —
253 —

/3. 188

4

TRANE

ALL RIGHTS RESERVED
THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS
CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN
CONSENT OF TRANE

DRAWN BY: FLEUROT @ DATE: 21-10-03

REPLACES: /

REVISION DATE: 14-11-03

SIMILAR TO: /

DEMARRAGE ETOILE TRIANGLE -- STERN-DREIECK ANLAUF -- WYE-DELTA START


2309-1697 X

SHEET
4/6


REV
A

RTHD




EXTERNE SOLLWERTE




INTERFACE



EISGESCHIEBEBETRIEB





TRANS
THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS CONTENTS DISCLOSED WITHOUT THE WRITTEN CONSENT OF TRANS
DRAWN BY: FLEUROT © DATE: 21-10-03
REPLACES: /
REVISION DATE: 14-11-03
SIMILAR TO: /

DEMARRAGE ETOILE TRIANGLE - STERN-DREIECK ANLAUF - WYE-DELTA START

RTHD

AVEC OPTION J
MIT ZUBEHOER J
WITH OPTION J

SANS OPTION J
OHNE ZUBEHOER J
WITHOUT OPTION J

DETAIL 3M1
3M1 EINZELHEIT
3M1 DETAIL

1A1
1A2
1A3
1A4
1A5
1A6
1A7
1A8
1A9
1A10
1A11
1A12
1A13
1A14
1A15
1A16
1A17
1A18
1A19
1A20
1A21
1A22
1A23
1A24
1A25
1A26
1A27
1A28
1A29
1A30
1A31
1A32
1A33
1A34
1A35
1A36
1A37
1A38
1A39
1A40
1A41
1A42
1A43
1A44
1A45
1A46
1A47
1A48
1A49
1A50
1A51
1A52
1A53
1A54
1A55
1A56
1A57
1A58
1A59
1A60
1A61
1A62
1A63
1A64
1A65
1A66
1A67
1A68
1A69
1A70
1A71
1A72
1A73
1A74
1A75
1A76
1A77
1A78
1A79
1A80
1A81
1A82
1A83
1A84
1A85
1A86
1A87
1A88
1A89
1A90
1A91
1A92
1A93
1A94
1A95
1A96
1A97
1A98
1A99
1A100

1T1
1T2
1T3
1T4
1T5
1T6
1T7
1T8
1T9
1T10
1T11
1T12
1T13
1T14
1T15
1T16
1T17
1T18
1T19
1T20
1T21
1T22
1T23
1T24
1T25
1T26
1T27
1T28
1T29
1T30
1T31
1T32
1T33
1T34
1T35
1T36
1T37
1T38
1T39
1T40
1T41
1T42
1T43
1T44
1T45
1T46
1T47
1T48
1T49
1T50
1T51
1T52
1T53
1T54
1T55
1T56
1T57
1T58
1T59
1T60
1T61
1T62
1T63
1T64
1T65
1T66
1T67
1T68
1T69
1T70
1T71
1T72
1T73
1T74
1T75
1T76
1T77
1T78
1T79
1T80
1T81
1T82
1T83
1T84
1T85
1T86
1T87
1T88
1T89
1T90
1T91
1T92
1T93
1T94
1T95
1T96
1T97
1T98
1T99
1T100

1K1
1K2
1K3
1K4
1K5
1K6
1K7
1K8
1K9
1K10
1K11
1K12
1K13
1K14
1K15
1K16
1K17
1K18
1K19
1K20
1K21
1K22
1K23
1K24
1K25
1K26
1K27
1K28
1K29
1K30
1K31
1K32
1K33
1K34
1K35
1K36
1K37
1K38
1K39
1K40
1K41
1K42
1K43
1K44
1K45
1K46
1K47
1K48
1K49
1K50
1K51
1K52
1K53
1K54
1K55
1K56
1K57
1K58
1K59
1K60
1K61
1K62
1K63
1K64
1K65
1K66
1K67
1K68
1K69
1K70
1K71
1K72
1K73
1K74
1K75
1K76
1K77
1K78
1K79
1K80
1K81
1K82
1K83
1K84
1K85
1K86
1K87
1K88
1K89
1K90
1K91
1K92
1K93
1K94
1K95
1K96
1K97
1K98
1K99
1K100

1X1
1X2
1X3
1X4
1X5
1X6
1X7
1X8
1X9
1X10
1X11
1X12
1X13
1X14
1X15
1X16
1X17
1X18
1X19
1X20
1X21
1X22
1X23
1X24
1X25
1X26
1X27
1X28
1X29
1X30
1X31
1X32
1X33
1X34
1X35
1X36
1X37
1X38
1X39
1X40
1X41
1X42
1X43
1X44
1X45
1X46
1X47
1X48
1X49
1X50
1X51
1X52
1X53
1X54
1X55
1X56
1X57
1X58
1X59
1X60
1X61
1X62
1X63
1X64
1X65
1X66
1X67
1X68
1X69
1X70
1X71
1X72
1X73
1X74
1X75
1X76
1X77
1X78
1X79
1X80
1X81
1X82
1X83
1X84
1X85
1X86
1X87
1X88
1X89
1X90
1X91
1X92
1X93
1X94
1X95
1X96
1X97
1X98
1X99
1X100

1Q1
1Q2
1Q3
1Q4
1Q5
1Q6
1Q7
1Q8
1Q9
1Q10
1Q11
1Q12
1Q13
1Q14
1Q15
1Q16
1Q17
1Q18
1Q19
1Q20
1Q21
1Q22
1Q23
1Q24
1Q25
1Q26
1Q27
1Q28
1Q29
1Q30
1Q31
1Q32
1Q33
1Q34
1Q35
1Q36
1Q37
1Q38
1Q39
1Q40
1Q41
1Q42
1Q43
1Q44
1Q45
1Q46
1Q47
1Q48
1Q49
1Q50
1Q51
1Q52
1Q53
1Q54
1Q55
1Q56
1Q57
1Q58
1Q59
1Q60
1Q61
1Q62
1Q63
1Q64
1Q65
1Q66
1Q67
1Q68
1Q69
1Q70
1Q71
1Q72
1Q73
1Q74
1Q75
1Q76
1Q77
1Q78
1Q79
1Q80
1Q81
1Q82
1Q83
1Q84
1Q85
1Q86
1Q87
1Q88
1Q89
1Q90
1Q91
1Q92
1Q93
1Q94
1Q95
1Q96
1Q97
1Q98
1Q99
1Q100

1F1
1F2
1F3
1F4
1F5
1F6
1F7
1F8
1F9
1F10
1F11
1F12
1F13
1F14
1F15
1F16
1F17
1F18
1F19
1F20
1F21
1F22
1F23
1F24
1F25
1F26
1F27
1F28
1F29
1F30
1F31
1F32
1F33
1F34
1F35
1F36
1F37
1F38
1F39
1F40
1F41
1F42
1F43
1F44
1F45
1F46
1F47
1F48
1F49
1F50
1F51
1F52
1F53
1F54
1F55
1F56
1F57
1F58
1F59
1F60
1F61
1F62
1F63
1F64
1F65
1F66
1F67
1F68
1F69
1F70
1F71
1F72
1F73
1F74
1F75
1F76
1F77
1F78
1F79
1F80
1F81
1F82
1F83
1F84
1F85
1F86
1F87
1F88
1F89
1F90
1F91
1F92
1F93
1F94
1F95
1F96
1F97
1F98
1F99
1F100

1S1
1S2
1S3
1S4
1S5
1S6
1S7
1S8
1S9
1S10
1S11
1S12
1S13
1S14
1S15
1S16
1S17
1S18
1S19
1S20
1S21
1S22
1S23
1S24
1S25
1S26
1S27
1S28
1S29
1S30
1S31
1S32
1S33
1S34
1S35
1S36
1S37
1S38
1S39
1S40
1S41
1S42
1S43
1S44
1S45
1S46
1S47
1S48
1S49
1S50
1S51
1S52
1S53
1S54
1S55
1S56
1S57
1S58
1S59
1S60
1S61
1S62
1S63
1S64
1S65
1S66
1S67
1S68
1S69
1S70
1S71
1S72
1S73
1S74
1S75
1S76
1S77
1S78
1S79
1S80
1S81
1S82
1S83
1S84
1S85
1S86
1S87
1S88
1S89
1S90
1S91
1S92
1S93
1S94
1S95
1S96
1S97
1S98
1S99
1S100

1R1
1R2
1R3
1R4
1R5
1R6
1R7
1R8
1R9
1R10
1R11
1R12
1R13
1R14
1R15
1R16
1R17
1R18
1R19
1R20
1R21
1R22
1R23
1R24
1R25
1R26
1R27
1R28
1R29
1R30
1R31
1R32
1R33
1R34
1R35
1R36
1R37
1R38
1R39
1R40
1R41
1R42
1R43
1R44
1R45
1R46
1R47
1R48
1R49
1R50
1R51
1R52
1R53
1R54
1R55
1R56
1R57
1R58
1R59
1R60
1R61
1R62
1R63
1R64
1R65
1R66
1R67
1R68
1R69
1R70
1R71
1R72
1R73
1R74
1R75
1R76
1R77
1R78
1R79
1R80
1R81
1R82
1R83
1R84
1R85
1R86
1R87
1R88
1R89
1R90
1R91
1R92
1R93
1R94
1R95
1R96
1R97
1R98
1R99
1R100

1C1
1C2
1C3
1C4
1C5
1C6
1C7
1C8
1C9
1C10
1C11
1C12
1C13
1C14
1C15
1C16
1C17
1C18
1C19
1C20
1C21
1C22
1C23
1C24
1C25
1C26
1C27
1C28
1C29
1C30
1C31
1C32
1C33
1C34
1C35
1C36
1C37
1C38
1C39
1C40
1C41
1C42
1C43
1C44
1C45
1C46
1C47
1C48
1C49
1C50
1C51
1C52
1C53
1C54
1C55
1C56
1C57
1C58
1C59
1C60
1C61
1C62
1C63
1C64
1C65
1C66
1C67
1C68
1C69
1C70
1C71
1C72
1C73
1C74
1C75
1C76
1C77
1C78
1C79
1C80
1C81
1C82
1C83
1C84
1C85
1C86
1C87
1C88
1C89
1C90
1C91
1C92
1C93
1C94
1C95
1C96
1C97
1C98
1C99
1C100

1L1
1L2
1L3
1L4
1L5
1L6
1L7
1L8
1L9
1L10
1L11
1L12
1L13
1L14
1L15
1L16
1L17
1L18
1L19
1L20
1L21
1L22
1L23
1L24
1L25
1L26
1L27
1L28
1L29
1L30
1L31
1L32
1L33
1L34
1L35
1L36
1L37
1L38
1L39
1L40
1L41
1L42
1L43
1L44
1L45
1L46
1L47
1L48
1L49
1L50
1L51
1L52
1L53
1L54
1L55
1L56
1L57
1L58
1L59
1L60
1L61
1L62
1L63
1L64
1L65
1L66
1L67
1L68
1L69
1L70
1L71
1L72
1L73
1L74
1L75
1L76
1L77
1L78
1L79
1L80
1L81
1L82
1L83
1L84
1L85
1L86
1L87
1L88
1L89
1L90
1L91
1L92
1L93
1L94
1L95
1L96
1L97
1L98
1L99
1L100

1D1
1D2
1D3
1D4
1D5
1D6
1D7
1D8
1D9
1D10
1D11
1D12
1D13
1D14
1D15
1D16
1D17
1D18
1D19
1D20
1D21
1D22
1D23
1D24
1D25
1D26
1D27
1D28
1D29
1D30
1D31
1D32
1D33
1D34
1D35
1D36
1D37
1D38
1D39
1D40
1D41
1D42
1D43
1D44
1D45
1D46
1D47
1D48
1D49
1D50
1D51
1D52
1D53
1D54
1D55
1D56
1D57
1D58
1D59
1D60
1D61
1D62
1D63
1D64
1D65
1D66
1D67
1D68
1D69
1D70
1D71
1D72
1D73
1D74
1D75
1D76
1D77
1D78
1D79
1D80
1D81
1D82
1D83
1D84
1D85
1D86
1D87
1D88
1D89
1D90
1D91
1D92
1D93
1D94
1D95
1D96
1D97
1D98
1D99
1D100

1U1
1U2
1U3
1U4
1U5
1U6
1U7
1U8
1U9
1U10
1U11
1U12
1U13
1U14
1U15
1U16
1U17
1U18
1U19
1U20
1U21
1U22
1U23
1U24
1U25
1U26
1U27
1U28
1U29
1U30
1U31
1U32
1U33
1U34
1U35
1U36
1U37
1U38
1U39
1U40
1U41
1U42
1U43
1U44
1U45
1U46
1U47
1U48
1U49
1U50
1U51
1U52
1U53
1U54
1U55
1U56
1U57
1U58
1U59
1U60
1U61
1U62
1U63
1U64
1U65
1U66
1U67
1U68
1U69
1U70
1U71
1U72
1U73
1U74
1U75
1U76
1U77
1U78
1U79
1U80
1U81
1U82
1U83
1U84
1U85
1U86
1U87
1U88
1U89
1U90
1U91
1U92
1U93
1U94
1U95
1U96
1U97
1U98
1U99
1U100

1V1
1V2
1V3
1V4
1V5
1V6
1V7
1V8
1V9
1V10
1V11
1V12
1V13
1V14
1V15
1V16
1V17
1V18
1V19
1V20
1V21
1V22
1V23
1V24
1V25
1V26
1V27
1V28
1V29
1V30
1V31
1V32
1V33
1V34
1V35
1V36
1V37
1V38
1V39
1V40
1V41
1V42
1V43
1V44
1V45
1V46
1V47
1V48
1V49
1V50
1V51
1V52
1V53
1V54
1V55
1V56
1V57
1V58
1V59
1V60
1V61
1V62
1V63
1V64
1V65
1V66
1V67
1V68
1V69
1V70
1V71
1V72
1V73
1V74
1V75
1V76
1V77
1V78
1V79
1V80
1V81
1V82
1V83
1V84
1V85
1V86
1V87
1V88
1V89
1V90
1V91
1V92
1V93
1V94
1V95
1V96
1V97
1V98
1V99
1V100

1W1
1W2
1W3
1W4
1W5
1W6
1W7
1W8
1W9
1W10
1W11
1W12
1W13
1W14
1W15
1W16
1W17
1W18
1W19
1W20
1W21
1W22
1W23
1W24
1W25
1W26
1W27
1W28
1W29
1W30
1W31
1W32
1W33
1W34
1W35
1W36
1W37
1W38
1W39
1W40
1W41
1W42
1W43
1W44
1W45
1W46
1W47
1W48
1W49
1W50
1W51
1W52
1W53
1W54
1W55
1W56
1W57
1W58
1W59
1W60
1W61
1W62
1W63
1W64
1W65
1W66
1W67
1W68
1W69
1W70
1W71
1W72
1W73
1W74
1W75
1W76
1W77
1W78
1W79
1W80
1W81
1W82
1W83
1W84
1W85
1W86
1W87
1W88
1W89
1W90
1W91
1W92
1W93
1W94
1W95
1W96
1W97
1W98
1W99
1W100

1X1
1X2
1X3
1X4
1X5
1X6
1X7
1X8
1X9
1X10
1X11
1X12
1X13
1X14
1X15
1X16
1X17
1X18
1X19
1X20
1X21
1X22
1X23
1X24
1X25
1X26
1X27
1X28
1X29
1X30
1X31
1X32
1X33
1X34
1X35
1X36
1X37
1X38
1X39
1X40
1X41
1X42
1X43
1X44
1X45
1X46
1X47
1X48
1X49
1X

131 —
132 —
133 —
134 —
135 —
136 —
137 —
138 —
139 —
140 —
141 —
142 —
143 —
144 —
145 —
146 —
147 —
148 —
149 —
150 —
151 —
152 —
153 —
154 —
155 —
156 —
157 —
158 —
159 —
160 —
161 —
162 —
163 —
164 —
165 —
166 —
167 —
168 —
169 —
170 —
171 —
172 —
173 —
174 —
175 —
176 —
177 —
178 —
179 —
180 —
181 —
182 —
183 —
184 —
185 —
186 —
187 —
188 —
189 —

/1. 130


4

TRANE
A DIVISION OF AMERSON TECHNOLOGY INC.
ALL INFORMATION CONTAINED
HEREIN IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS
CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN
CONSENT OF TRANE
DRAWN BY: FLEUROT © DATE: 21-10-03
REPLACES: /
REVISION DATE: 14-11-03
SIMILIAR TO: /

2309-1697 X
SHEET 3/6
REV A

RTHD

DEMARRAGE ETOILE TRIANGLE -- STERN-DREIECK ANLAUF -- WYE-DELTA START



/4. 191

190 —
191 —
192 —
193 —
194 —
195 —
196 —
197 —
198 —
199 —
200 —
201 —
202 —
203 —
204 —
205 —
206 —
207 —
208 —
209 —
210 —
211 —
212 —
213 —
214 —
215 —
216 —
217 —
218 —
219 —
220 —
221 —
222 —
223 —
224 —
225 —
226 —
227 —
228 —
229 —
230 —
231 —
232 —
233 —
234 —
235 —
236 —
237 —
238 —
239 —
240 —
241 —
242 —
243 —
244 —
245 —
246 —
247 —
248 —
249 —
250 —
251 —
252 —
253 —

/3. 188


4

TRANE
A DIVISION OF AMERSON TECHNOLOGY INC.
ALL RIGHTS RESERVED
THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS
CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN
CONSENT OF TRANE
DRAWN BY: FLEUROT @DATE: 21-10-03
REPLACES: /
REVISION DATE: 14-11-03
SIMILIAR TO: /

2309-1697 X
RTHD

REV SHEET
A 4/6

DEMARRAGE ETOILE TRIANGLE -- STERN-DREIECK ANLAUF -- WYE-DELTA START



TRANE
A DIVISION OF AMERSON INTERNATIONAL INC.
ALL RIGHTS RESERVED
THIS DRAWING IS PROPRIETARY AND NOT BE COPIED OR ITS
CONTENTS DISCLOSED TO OUTSIDE PARTIES WITHOUT THE WRITTEN
CONSENT OF TRANE

2309-1697 X

REV
SHEET
5/6
A

RTHD

DRAWN BY: FLEUROT © DATE: 21-10-03

REPLACES: /

REVISION DATE: 14-11-03

SIMILAR TO: /

NOMENCLATURE – LEGEND – COMPONENTS DESIGNATION

—	CABLAGE TRANE	TRANE VERDRAHTUNG	TRANE WIRING
—	CABLAGE CLIENT	VERDRAHTUNG DURCH KUNDEN	CUSTOMER WIRING

CODE COULEUR FARBMARKIERUNG COLOUR CODE	
BK: NOIR	SCHWARZ BLACK
BN: BRUN	BRAUN BROWN
BL: BLEU	BLAU BLUE
GD: OR	GOLD GOLD
GN: VERT	GRUEN GREEN
GY: GRIS	GRAU GRAY
OG: ORANGE	ORANGE ORANGE
PK: ROSE	ROSE PINK
RD: ROUGE	ROT RED
SR: ARGENT	SILBER SILVER
VT: VIOLET	VIOLETT PURPLE
WH: BLANC	WEISS WHITE
YE: JAUNE	GELB YELLOW

1K20-1	INDEX	ZAHLENINDEX	INDEX
	ATTRIBUTE	ATTRIBUT	ATTRIBUTE
	DESIGNATION	BEZEICHNUNG	DESIGNATION
	EMPLACEMENT	STELLE	LOCATION
	EMPLACEMENT	STELLE	LOCATION
1	COFFRET UNITE	GERATE-SCHALTAFEL	UNIT PANEL
2	PAS UTILISE	NITCH BENUTZT	NOT USED
3	COMPRESSEUR	VERDICHTER	COMPRESSOR
4	MONTE EN USINE	AN DER MASCHINE	UNIT MOUNTED
5	CABLAGE CLIENT	VERDRAHT. KUNDEN	CUSTOMER WIRING

NOTES – BEACHTEN – NOTIZEN:

- 1

–VOIR DETAIL SI OPTION A, E, OU F MONTÉE
- 2

–SEULEMENT POUR COMPRESSEUR C ET AU DESSUS
- 3

–SONDE EXTERIEURE INSTALLEE EN USINE
- 4

–COUPLE EN 400V EN USINE
- 5

–OTER CE PONTAGE QUAND UTILISATION DE CE CONTACT
- SIEHE EINZELHEIT, WENN OPTION A,E ORDER F MONTIERT IST
- NUR FÜR VERDICHTER C UND HÖRER
- FÜHLER, UMGEBUNGSTEMPERATUR WERKS MONTIERT
- 400V VERDRAHTET (WERKS MONTIERT)
- ENTFERNE DIESE BRÜCKE, WENN DIESER KONTAKT BELEGT IST
- SEE DETAIL IF OPTION AE OR F MOUNTED
- ONLY FOR COMPRESSOR C AND OVER
- OUTDOOR AIR TEMP FACTORY INSTALLED LEAD LENGTH EXTENDED BY CUSTOMER
- CONNECTED IN 400V (FACTORY WIRED)
- REMOVE THIS JUMPER WHEN USING THIS CONTACT

ENTRÉES CARTES POUR RACCORDEMENT CLIENT – MODULLEINGANG – CUSTOMER INPUTS:

- E1

–POINT DE CONSIGNE EXTERNE D'INTENSITE
- E2

–POINT DE CONSIGNE EXTERNE EAU FROIDE
- E3

–CONTROLE DE CHARGE EXTERNE
- E4

–FONCTIONNEMENT STOCKAGE DE GLACE
- E5

–ENTREE CONTROLE DE CHARGE EXTERNE
- E6

–ENTREE DETECTEUR DE REFRIGERANT
- SOLLWERT EXT. STROMBEGRENZUNG
- SOLLWERT EXT. KALTWASSESTEMPERATUR
- AKTIVIERUNG EXTERNE GRUNDLAST
- EISSPEICHERBETRIEB
- EINGANG EXTERNER GRUNDLAST–SOLLWERT
- EINGANG KALTEMITTEL–ÜBERWACHUNG
- EXTERNAL CURRENT LIMIT SETPOINT
- EXTERNAL CHILLED WATER SETPOINT
- EXTERNAL BASE LOAD ENABLE
- ICE BUILDING CONTROL
- EXTERNAL BASELOAD SETPOINT INPUT
- REFRIGERANT MONITOR INPUT

SORTIES CARTES POUR RACCORDEMENT CLIENT – MODULAUSGANG – CUSTOMER OUTPUTS:

- S2

–RELAIS PROGRAMMABLES
- S8

–FONCTIONNEMENT STOCKAGE DE GLACE
- S11

–0-10VDC : INFORMATION % RLA COMPRESSEUR
- S12

–0-10VDC : INFORMATION CONTROLE CONDENSEUR (PRESSION ...)
- S13

– VERS AUTRE UNITE
- S14

– VERS TRACER OU AUTRE UNITE TRANE
- FUNKTION DES RELAIS PROGRAMMIERBAR
- RELAIS EISSPEICHERBETRIEB
- 0-10VDC : INFO NOMINALSTROM VERDICHTER (RLA)
- 0-10VDC : INFO VERFLUESSIGUNGSDRUCK (DRUCK ...)
- ZUE ANDERE UNIT
- NACH TRACER
- PROGRAMMABLE RELAYS
- ICE MAKING ENABLE
- 0-10VDC COMPRESSOR % RLA OUTPUT
- 0-10VDC CONDENSER CONTROL OUTPUT (CONDENSER PRESSURE , DELTA PRESSURE ...)
- TO NEXT UNIT
- TO TRACER OR OTHER TRANE REMOTE DEVICE

REPÈRE	OPTIONS	ZUBEHÖR	OPTIONS
A	INTERRUPTEUR-SECTIONNEUR	HAUPTSCHALTER	DISCONNECT SWITCH
E	INTERRUPTEUR-SECTIONNEUR + FUSIBLES	HAUPTSCHALTER + SICHERUNG	DISCONNECT SWITCH + FUSES
F	DISJONCTEUR	SCHUTZSCHALTER	CIRCUIT BREAKER
J	TRANSFO. DE SUR/SOUS TENSION	UEBER/UNTERSCHNUNGSTRAFO.	OVER/UNDER VOLTAGE TRANSFO.
K	DEFAULT DE MISE A LA TERRE	ERDUNGSTFELER RELAIS	GROUND FAULT RELAY
20	FONCTIONNEMENT MACHINE A GLACE	EISSPEICHERBETRIEB	ICE MAKING ENABLE
22	POINTS DE CONSIGNES EXTERNES	EXTERNER SOLLWERT	EXTERNAL SETPOINTS
23	SORTIES COMPRESSEUR / CONDENSEUR	AUSGANG COMPRESSOR / VERFLUSSIGER	CONDENSER / COMPRESSOR OUTPUT
24	INTERFACE COMM4 OU COMM5	COMM4 ORDER COMM5	COMM4 OR COMM5
25	ENTREE DETECTEUR DE REFRIGERANT ET CONTROLE DE CHARGE EXTERNE	EINGANG KALTEMITTELUBERWACHUNG UND SOLLWERT EXTERNE GRUNDLAST	REFRIGERANT MONITOR INPUT & EXTERNAL BASELOAD SETPOINT INPUT
26	RELAIS PROGRAMMABLE	FUNKTION DES RELAIS PROGRAMMIERBAR	PROGRAMMABLE RELAYS

TRANS
A DIVISION OF TRANE COMPANY INC.
ALL RIGHTS RESERVED

THIS DRAWING IS PROPRIETARY AND SHALL NOT BE COPIED OR ITS
CONTENTS DISCLOSED TO ANY OTHER PARTY WITHOUT THE WRITTEN
CONSENT OF TRANE

DRAWN BY: FLEUROT ©DATE: 21-10-03

REV SHEET A
2309-1697 X 6/6

REPLACES: /

REVISION DATE: 14-11-03

SIMILAR TO: /

RTHD

NOMENCLATURE - LEGEND - COMPONENTS DESIGNATION

LINE #	ITEM	FRANCAIS	DEUTCH	ENGLISH
		BORNE	KLEMMEN	TERMINAL BLOCK
51-57	X	INTERFACE UTILISATEUR LOCAL	LOKALE MENSCH/MASCHINE SCHNITTSTEL.	DYNA VIEW DISPLAY AND INTERFACE
61-65	1A1	MODULE ALIMENTATION	MODUL SPANNUNGSEINGANG	POWER SUPPLY MODULE
78-105	1A2	MODULE DEMARREUR	STARTER MODUL	STARTER MODULE
106-113	1A3	MODULE MODULE PRESSION	MODUL MITTELSPANNUNGSEINGANG BINAR	HIGH PRESSURE CUTOUT SWITCH
113-121	1A4	MODULE ELECTROVANNES CHARGE ET DECHARGE	MODUL MIT 2 AUSGANGEN TRIAC	SLIDE VALVE IN/LOAD AND LOAD CONTROL SOLENOID VALVE
121-128	1A5	MODULE ELECTROVANNES REMPLISSAGE ET VIDANGE	MODUL MIT 2 AUSGANGEN TRIAC	OIL RETURN GAS PUMP DRAIN AND FILL SOLENOID VALVE
148-159	1A6	MODULE MODULE PRESSION	MODUL MITTELSPANNUNGSEINGANG BINAR	CONDENSER AND CHILLED WATER FLOW SWITCH INTERLOCKS
139-148	1A7	MODULE ETAT MODE STOCKAGE GLACE/ELECTROVANNE D'HUILE	MODUL MIT ZWEI RELAIS AUSGANGEN	ICE BUILDING STATUS OUTPUT AND MASTER OIL LINE SOLENOID VALVE
160-169	1A8	MODULE DEMARRAGE POMPE EVAPORATEUR ET CONDENSEUR	MODUL MIT ZWEI RELAIS AUSGANGEN	CONDENSER AND CHILLED WATER PUMP STARTER
234-251	1A9	MODULE SORTIES RELAIS D'INDICATEUR D'ETAT PROGRAMMABLE	MODUL MIT VIER RELAIS AUSGANGEN	OPERATING STATUS PROGRAMMABLE RELAYS
177-183	1A10	MODULE INDICATEUR PRESSION D'HUILE	MODUL OELSTANDSKONTROLLE	OIL LOSS LEVEL SENSOR AND UNUSED INPUTS
170-176	1A11	MODULE SORTIES MARCHES/ARRETS EXTERNE ET ARRET D'URGENCE	MODUL NIEDERSPANNUNGSEINGANG BINAR	EXTERNAL AUTO/STOP AND EMERGENCY STOP INPUT
185-188	1A12	MODULE SORTIES CONTROLE CONDENSEUR ET SORTIE RLA	ANALOG I/O MODUL MIT 2 I/O ANSCHLIESSEN	CONDENSER CONTROL AND 2 RLA OUTPUT
197-205	1A13	MODULE SORTIE PNT CONSI. EXT. LIM. COURANT ET EAU GLACEE	ANALOG I/O MODUL MIT 2 I/O ANSCHLIESSEN	EXTERNAL CURRENT LIMIT AND CHILLED WATER
216-222	1A14	MODULE MODE STOCKAGE GLACE/CONTROLE CHARGE EXTERNE	MODUL NIEDERSPANNUNGSEINGANG BINAR	ICE BUILDING CONTROL AND EXTERNAL BASE LOADING ENABLE
208-214	1A15	MODULE ENTREE DETECTEUR RFGT/CONTROLE CHARGE EXTERNE	COMM4 ORDER COMMS	COMM 4 OR LCI-C (COMM 5)
224-233	1A16	MODULE ENTREE DETECTEUR RFGT/CONTROLE CHARGE EXTERNE	ANALOG I/O MODUL MIT 2 I/O ANSCHLIESSEN	REFRIGERANT MONITOR INPUT AND EXTERNAL BASE LOADING SETPOINT
12	1F10	FUSIBLE COMPRESSEUR	SICHERUNG, VERDICHTER	COMPRESSOR FUSE
36..44	1K1	CONTACTEUR LIGNE COMPRESSEUR	SCHUTZ, BETRIEB VERDICHTER	COMPRESSOR LINE CONTACTOR
36..46	1K2	CONTACTEUR TRIANGLE COMP.	SCHUTZ DREIECK VERDICHTER	DELTE COMPRESSOR CONTACTOR
36..48	1K3	CONTACTEUR ETOILE COMPRESSEUR	SCHUTZ STERN VERDICHTER	STAR COMPRESSOR CONTACTOR
37..45	1K4	CONTACTEUR TRANSITION COMP.	SCHUTZ, UEBERGANG VERDICHTER	COMPRESSOR TRANSITION CONTACTOR
56,174	1K5	RELAIS PROTECTION	RELAIS STÖRUNG	PROTECTION RELAY
23/45	102/3/4	DISJONCTEUR MAGNETOTHERMIQUE	ÜBERSTROMREL. MAGNET THERMIQUE	MAGNETOTHERMIC OVERLOAD RELAY
11	1010	INTERRUPTEUR SECTIONNEUR UNITE	TRENNER MASCHINE	UNIT DISCONNECT SWITCH
11	1011	DISJONCTEUR UNITE	ÜBERSTROMREL. MASCHINE	UNIT CIRCUIT BREAKER
37..45	1R1	RESISTANCE DE TRANSITION	WIDERSTAND UEBERGANG	TRANSITION RESISTOR
39	1T1	TRANSFORMATEUR	TRANSFORMATOR	TRANSFORMER
10..15	1T2 ...	TRANSFORMATEUR D'INTENSITE	STROMWANDLER	CURRENT TRANSFORMER
30,77..82	1T3 ...	TRANSFO. DE SUR/SOUS TENSION	ÜBER/UNTERS PANNUNGSSTRAFO.	OVER/UNDER VOLTAGE TRANSFORMER
2	1X1	BORNIER PUISSANCE COMPRESSEUR	KLEMMEN, KRAFTSTROM, VERDICHTER	COMPRESSOR POWER CIRCUIT TERMINAL STRIP
40	3M1	MOTEUR COMPRESSEUR	MOTOR, VERDICHTER	COMPRESSOR MOTOR
116	3Y1	ELECTROVANNE CHARGE COMPRESSEUR	MAGNETVENTIL, LEISTUNGSREGELUNG	COMPRESSOR LOAD SOLENOID VALVE
119	3Y2	ELECTROVANNE DECHARGE COMPRESSEUR	MAGNETVENTIL, LEISTUNGSREGELUNG	COMPRESSOR UNLOAD SOLENOID VALVE
179..183	4B2	DETECTEUR PRESSION HUILE	OELSTANDSKONTROLLE	OIL LOSS LEVEL SWITCH
48	4B3	CONTROL NIVEAU REFRIGERANT EVAPORATEUR	VERD. KÄLTEMITTEL NIVEAU SENSOR	EVP. REFRIGERANT LIQUID LEVEL SENSOR
55	4B20	SONDE TEMPERATURE ENTREE D'EAU EVAPORATEUR	FUEHLER WASSEREINTRITT VERD.	ENTERING EVAPORATOR WATER TEMPERATURE SENSOR
57	4B21	SONDE TEMPERATURE SORTIE D'EAU EVAPORATEUR	FUEHLER, WASSERAUSSTRIIT VERD.	LEAVING EVAPORATOR WATER TEMPERATURE SENSOR
59	4B22	SONDE TEMPERATURE ENTREE D'EAU CONDENSEUR	FUEHLER, WASSERAUSSTRIIT VERFL.	ENTERING CONDENSER WATER TEMPERATURE SENSOR
62	4B23	SONDE TEMPERATURE SORTIE D'EAU CONDENSEUR	FUEHLER, WASSERAUSSTRIIT VERD.	LEAVING CONDENSER WATER TEMPERATURE SENSOR
64	4B24	CAPTEUR DE PRESSION D'HUILE	OELSTANDSKONTROLLE	OIL PRESSURE TRANSDUCER
51	4B25	CONTROL PRESSION EVAPORATEUR	GEBER VERDAMPFUNGSDRUCK	EVAPORATOR REFRIGERANT PRESSURE TRANSDUCER
53	4B26	CONTROL PRESSION CONDENSEUR	VERFLUESSIGUNGSDRUCKKONTROLLE	CONDENSOR REFRIGERANT PRESSURE TRANSDUCER
49	4B27	SONDE TEMPERATURE REFOULEMENT	FUEHLER, HEISSGASTEMPORATUR	DISCHARGE TEMPERATURE SENSOR
72	4B29	PRESSOSTAT HAUTE PRESSION	DRUCKSCHALTER,HOCHDRUCK	HIGH PRESSURE CUTOOUT SWITCH
74/76	4E1/2	RESISTANCE CARTER HUILE	OELHEIZUNG, VERDICHTER	OIL SUMP HEATERS
121	4Y1	ELECTROVANNE REMPLISSAGE	MAGNETVENTIL FUELLEN	FILL SOLENOID VALVE
126	4Y2	ELECTROVANNE VIDANGE	MAGNETVENTIL ABLASSEN	DRAIN SOLENOID VALVE
78	4Y3	ELECTROVANNE CIRCUIT HUILE	MAGNETVENTIL OELKREIS	MASTER OIL LINE SOLENOID VALVE
50/53	4Y20-21	VANNE D' EXPANSION ELECTRONIQUE	ELEKTRONISCHES EXPANSIONVENTIL	DUAL PORT EXP. ACTUATOR
58	5B28	SONDE TEMPERATURE AIR EXTERIEUR	FUEHLER, UMGEBUNGSLUFT	OUTDOOR TEMPERATURE AIR SENSOR
9	5F10	FUSIBLES	SICHERUNG	FUSES
163	5K1	CONTACTEUR POMPE A EAU EVAPORATEUR	SCHUTZ, WASSERPUMPE VERDAMPFER	CHILLED WATER PUMP STARTER
168	5K2	CONTACTEUR POMPE A EAU CONDENSEUR	SCHUTZ, WASSERPUMPE VERFLUESS	CONDENSER WATER PUMP STARTER
236..251	5K4..20	RELAIS	RELAIS	UNIT STATUS RELAYS
219	5K12	FONCTIONNEMENT EN MODE STOCKAGE DE GLACE	EISPEICHERBETRIEB	ICE BUILDING CONTROL
216	5K13	VALIDATION EXTERNE DU CONTROLE DE CHARGE	SOLLWERT "EXTERNAL BASE LOADING "	EXTERNAL BASE LOAD ENABLE
174	5K21	ARRET UNITE	EIN/AUS MASCHINE	EXTERNAL STOP
171	5K22	ARRET D' URGENCE UNITE	NOTSCHALTER-AUS	EXTERNAL EMERGENCY STOP
6	5T10	TRANSFORMATEUR D' INTENSITE	STROMWANDLER	CURRENT TRANSFORMER
151	5S1	INTERRUPTEUR DEBIT EAU EVP	STROMUNGSWAECHTER VERD.	EVP WATER FLOW SWITCH
155	5S2	INTERRUPTEUR DEBIT EAU CDS	STROMUNGSWAECHTER VERFLUESSIGER	CDS WATER FLOW SWITCH

