

REGsys


Petersen - Coils


Regulator
REG - DP

Operating Manual

Issue: 07.01.2002

Version: 2.1.02

delivered
Software - Version:



Operating manual

Version 07.01.2002

Copyright 2002 by a.eberle gmbh. All rights reserved.


Edited by:

a.eberle gmbh

Aalener Straße 30/32
D-90441 Nürnberg


Tel.: 0911 / 62 81 08 - 0
Fax: 0911 / 66 66 64

e-mail: info@a-eberle.de
Internet: www.a-eberle.de




The company **a. eberle gmbh** cannot be held liable for any damages or losses emitting from printing errors or changes in this operating manual.

Furthermore, **a. eberle gmbh** does not assume responsibility beyond the guarantee period for any damages and losses resulting from deficient devices or from devices changed by the applicant.




Index

1	Warnings and Notes	9
2	Delivery contents	10
4	The Regulation	13
4.1	Principle of the earth-fault neutralizer	13
4.2	A closer look onto the zero phase-sequence system	14
4.3	Principle of the regulation	18
5	Technical Characteristics	21
5.1	Electrical Data	21
5.1.1	Rules and regulations	21
5.1.2	Alternating voltage input (U_{NE} and U_{I2})	21
5.1.3	Alternating current input (I_1 and I_2)	21
5.1.4	Position message (I_{pos})	21
5.1.5	20 mA – Analog outputs	21
5.1.6	Binary inputs	22
5.1.7	Relay outputs	22
5.1.8	Reference conditions	22
5.1.9	Electrical safety	22
5.1.10	Electromagnetical compability	23
5.1.11	Power supply	24
5.1.12	Indication, Status	24
5.2	Mechanical Structure	25
5.2.1	Plug-in group	25
5.2.2	Contact assignment of the Plug-in group	27
5.2.2.1	Contact assignment of the terminal blocks	27
5.2.2.2	Terminal block 1: Binary outputs REL	28
5.2.2.3	Terminal block 2: Binary inputs E	30
5.2.2.4	Terminal block 3: I_{pos} , U_{en} , U_{sync} and Auxiliary voltage	31
5.2.2.5	Terminal block 5: Coil position (only with REG-DE)	36
5.2.2.6	Terminal block 4: Current inputs, f.e. by the P-coil	37
5.2.2.7	Terminal block 6: 20 mA Inputs / Outputs; COM1- 3	38
5.2.2.8	Serial Interface COM1	40
5.2.3	Wall-mounting rack 49TE	41
5.2.4	Panel-mounting rack 30TE	42
5.2.5	19 Inch Plug-in group rack	43
5.2.5.1	Plug-in group rack with Phoenix-terminals	43
5.2.5.2	Plug-in group rack with screw terminals	43
5.2.6	Standard assignment for Phoenix-terminals	45
5.2.7	Example for the link of the REG-DP to a P-Coil	46
5.3	Upgrading of analog inputs resp. outputs	47
6	Operation	48
6.1	Indication and operation elements	48
6.1.1	Indication and operation elements	48
6.1.2	Function keys	51
6.1.3	Plug connection at the front	52



6.2	Operation principle	52
6.3	Selection of the indication mode	55
6.3.1	Indication mode indication	55
6.3.1.1	<F1> Resonance wave:	55
6.3.1.2	<F2> Detail indication:	56
6.3.1.3	<F3> Large-scale display:	58
6.3.2	Indication mode: Setup	59
6.3.3	Operation mode Recorder	60
6.3.3.1	Indication des recorders	60
6.3.3.2	Setting possibilities for the recorder	61
6.3.4	Statistics	65
6.3.4.1	Indication of the statistics	65
6.3.4.2	Sum statistics:	65
6.3.4.3	Statistics per calender week:	67
6.3.4.4	Example for statistics	68
6.3.5	Indication mode Interference help	68
7	Putting into operation	69
7.1	Hardware - Wiring	70
7.2	Putting into operation without medium-voltage system	71
7.3	Putting into operation with medium-voltage system	80
7.4	Check of the digital information regulator \Leftrightarrow supervisory remote control	80
7.5	Check of the analog Information regulator \Rightarrow supervisory remote control	81
7.6	Operation with Fixcoil	81
8	SETUP	83
8.1	Regulation	84
8.1.1	Standard Parameter	85
8.1.1.1	Tolerance range	86
8.1.1.2	Uen – Tolerance range	86
8.1.1.3	Delay of the Search by x s	87
8.1.1.4	Delay of the forcing search: x s	88
8.1.1.5	Setpoint detuning in %	88
8.1.1.6	Setpoint detuning	88
8.1.1.7	Positioning tolerance	88
8.1.1.8	Minimum change dIpos	88
8.1.1.9	Overriding the resonance maximum	89
8.1.1.10	Pulling of Uref in [min]	89
8.1.1.11	Uen - Angle measuring	89
8.1.2	Earth fault	90
8.1.2.1	Behaviour when Earth fault	90
8.1.2.2	Uerd - Treshold [V]	92
8.1.2.3	Transient earth fault [s]	92
8.1.2.4	Uerd-Message delay [s]	92
8.1.2.5	Self-conduct when Uerd	92
8.1.2.6	Readjusting the P-coil during the earth fault.	92
8.1.3	Umax	95
8.1.4	Umin	96
8.1.4.1	Umin - Treshold	96
8.1.4.2	Final position when Umin	96
8.1.4.3	Delay of the message Umin	97
8.1.4.4	New search for [min]	97
8.1.4.5	Limitation of dUen when Umin	97



8.1.5	R - Control	98
8.1.5.1	In general	99
8.1.5.2	Description of the functions	99
8.1.6	Parallel - Regulation	104
8.1.6.1	Master-Slave Operation mode	104
8.1.6.2	Possible scenes for the Master Slave- operation:	105
8.1.6.2.1	Sound system :	105
8.1.6.2.2	Sound system but $U_{res} < U_{min}$:	106
8.1.6.2.3	Sound system but $U_{res} > U_{max}$:	106
8.1.6.2.4	Earth fault	106
8.1.6.3	Parall - Regulation without communication by E-LAN	107
8.2	Putting into operation	108
8.2.1	Interface to the Petersen coil	108
8.2.2	Voltage measuring	117
8.2.3	P-coil	118
8.2.3.1	Data of the P-coil	118
8.2.3.2	Coil calibration	119
8.2.3.3	Linearization of the coil	120
8.2.3.4	Indication Options	121
8.2.3.5	Fixcoil	122
8.2.4	Inputs & Outputs	123
8.2.4.1	Binary Inputs and Outputs	123
8.2.4.2	Binary inputs	124
8.2.4.3	Binary outputs	127
8.2.4.4	LED - Outputs	131
8.2.4.5	Analog Inputs/Outputs	132
8.2.4.6	Delays	136
8.2.5	Fault acknowledgement	137
8.2.6	Current measuring	138
8.3	Options	139
8.3.1	Local / Remote	139
8.3.2	Simulation	141
8.3.2.1	Principle of the system simulation in the REG-DP	141
8.3.2.2	Activation of the Simulation	141
8.3.2.3	Key assignment during the simulation	143
8.4	System	144
8.4.1	Language	145
8.4.2	COM & ELAN	145
8.4.2.1	COM1 and COM2	145
8.4.2.2	E-LAN	147
8.4.3	Station identification	149
8.4.4	Station name	150
8.4.5	LCD saver	150
8.4.6	Date & Clock-time	150
8.4.7	Password	151
8.4.8	Status	152
9	Update of the operation software	155
9.1	Operation system Windows 95/98, NT and Win2000	155
9.2	Menu Functions of the Update32-Programme	158
9.2.1	Update	158
9.2.2	Configure	158
10	Maintenance and Current consumption	160
10.1	Change of fuse	160




10.2	Change of batteries	160
10.3	Current consumption of the REG-DP	161
11	<i>WinREG-DP</i>	162
11.1	Installation	162
11.2	Panel	164
11.3	Terminal	164
11.4	Load	165
11.5	Save	165
11.6	RegPara	165
11.6.1	Cards	166
11.6.2	Parameter print-out sorted according to menu of the regulator	171
11.6.3	Parameter print-out sorted according to index cards:	176
12	<i>Background - programming REG-L</i>	181
12.1	The programming language REG-L	181
12.2	List of the REG-L / ECL-Interpreter-commands	181
12.3	REG-DP specific commands	182
13	<i>Control and instrumentation technology</i>	192
13.1	In general	192
13.2	Communication behaviour	192
13.3	Data points of the command direction	193
13.4	Data points of the message direction	193
14	<i>Definition of the abbreviations and icons</i>	196
15	<i>Index</i>	197

Mapping list

Map 3.1: REGSys™	11
Map 3.2: Principle of the automation island	12
Map 4.1: Principle of the earth-fault neutralizer	13
Map 4.2: One phase equivalent circuit of the Zero phase-sequence system (system analyzer)	14
Map 4.3: Offset voltage U_{NE} depending on the Coil position (resonance wave)	15



Map 4.4: Pointer display of the fault current for a P-Coil setting	16
Map 4.5: Sum of the fault current depending on the P-Coil setting (V-Wave)	16
Map 4.6: Neutralization limits according to VDE228, Part 2	18
Map 4.7: Resonance wave	18
Map 4.8: Parameter to describe the resonance wave	20
Map 5.1: Dimensions	25
Map 5.2: Location of the circuit boards and plug connectors (View from above)	26
Map 5.3: Location of the terminal blocks (View of the back)	26
Map 5.4: Contact assignment of the terminal blocks	27
Map 5.5: Terminal block 1: Binary Outputs R	28
Map 5.6: Location of the Wire jumper on the circuit board 1	29
Map 5.7: Terminal block 2: Binary Inputs E	30
Map 5.8: Terminal block 3: Offset voltage U_{en} and auxiliary voltage	31
Map 5.9: Wiring proposal for U _{sync} with auxiliary voltage of 230 VAC	32
Map 5.10: Principal structure of the analog Input for the Coil position	33
Map 5.11: Position of the Jumper for the Coil position	33
Map 5.12: Assembly of the Jumpers depending on the Input function	34
Map 5.13: Potentiometer in two-wire connection	35
Map 5.14: Terminal block 5: Coil position I_{pos}	36
Map 5.15: Terminal block 4: Current I_1 (e.g. I_p) and I_2	37
Map 5.16: Position of the Jumper for the current inputs I_1 and I_2	37
Map 5.17: Terminal block 6: 20 mA Inputs / Outputs; COM1-3	38
Map 5.18: Serial interface COM1	40
Map 5.19: Wall-mounting rack (49TE)	41
Map 5.20: Panel-mounting rack (30TE)	42
Map 5.21: Example for 19" mounting rack with Phoenix terminals	43
Map 5.22: Example for 19" mounting rack with screw terminals	43
Map 5.23: Standard - terminal assignment for wall- and panel-mounting rack	45
Map 5.24: Example for the link of the REG-DP to a P-Coil	46
Map 5.25: Slots for analog-double modules	47
Map 5.26: Pin assignment of the analog-double modules	47
Map 6.1: Indication and operation elements	48
Map 6.2: LCD - Indication in the regulator mode	49
Map 6.3: Principle of the navigation between the single menu levels	54
Map 7.1: Regulator with Petersen-Coil	69
Map 8.2: Position of the Jumper for the Coil position	112
Map 8.3: Assembly of the Jumpers depending on the Input function	113
Map 8.4: Potentiometer in two-wire connection	113
Map 10.1: Change of fuses on circuit board 3	160




1 Warnings and Notes

The P-coil regulator REG- DP is exclusively designed for installations and equipment of the electrical engineering in which only trained experts are permitted to do all required works. Experts are persons who are familiar with the installation, mounting, putting into operation and the operation of products of this kind. Furthermore experts have qualifications which comply with their field of work.


The P-coil regulator REG-DP has been built and tested in accordance with all important electrical safety regulations and left the factory in perfect condition. To maintain this condition and to ensure safe operation, the following instructions and warnings in this Operating Manual must be observed.

- The P-coil regulator REG-DP has been built in compliance with IEC 10110 / EN61010 (DIN VDE 0411), accuracy class I and checked on this norm before delivery.
- The P-coil regulator REG-DP must not be operated with but with a connected non-fused earthed conductor. This condition is complied with the connection to an auxiliary voltage line system with a non-fused earthed conductor (European net). Should the auxiliary voltage line system have no non-fused earthed conductor, an additional connection from the earth-conducting terminal to the earth must be made.
- The upper limit of the admissible auxiliary voltage U_{AUX} must not be exceeded neither permanently nor for a short while.
- Before changing the fuse separate the P-coil regulator REG - DP completely from the auxiliary voltage U_{AUX}. Any use of orr fuses than those being of the indicated type and current intensity is prohibited.
- A P-coil regulator REG - DP, which shows a visible damage or a clear malfunction must not be used and has to be secured against unintentional on-switching.
- Adjustments, maintenance and repair works which are made when the lines of P-coil regulator REG - DP are laid bare may only be made by authorized experts.




2 Delivery contents

- | | |
|---------|---|
| 1 Piece | P-coil regulator REG - DP |
| 1 Piece | Operation manual in German, English or another language |



3 Application

The P-coil regulator REG-DP is a component of the Measuring, Control, Regulation and Registration system REGSys™.





Trafo - Regelung
E-Spulen - Regelung
Erdschluss - Ortung

map 3.1: REGSys™

The P-coil regulator is used for the regulation of Petersen-Coils in medium and high-voltage systems. (Orr descriptions for the Petersen Coil: P-Coils, Earth fault-neutralizer, arc suppression coil, arc neutralization coil, E-Coils). By means of the P-coil regulator, a tuning of the P-Coils may be made already in the sound network. This tuning is made in a way that the currents which might override the fault location in case of an earth fault are as low as possible.

In a system structure by bus based on the RS485A, a P-coil regulator may be operated together with a voltage regulator REG-D, a supervisory unit PAN-D, an earth fault locating system EOR-Sys, a multi-transducer MMU-D, or the Power-Quality-Interface PQI-D.




Map 3.2: Principle of the automation island

All measuring values and binary inputs and outputs are defined as data objects, the access of which is possible from any device in this network, provided that the device address is indicated. By means of the background programming, even complex control tasks may be resolved easily.

The module REG-P, which is available either as internal or external unit, permits a serial link to a higher-levelled control and instrumentation technology.


Furthermore, it is possible to solve all measuring, control and registrating tasks around the P-Coils through the free programmability of the regulator.



4 The Regulation

4.1 Principle of the earth-fault neutralizer

The earth-fault neutralizer is based on the principle, that the P-Coil is set in a way that the capacitive current overriding the fault location is being compensated by an inductive current of the same quantity. Thus, in case of an ideal compensation, only a little ohmic residual ohmic current is overriding the fault location.




Map 4.1: Principle of the earth-fault neutralizer

L_P	Inductivity of the P-Coils (Petersen Coil)
C_1, C_2, C_3	Capacities of the single conductors to the earth
N	Neutral point of the transformers
E	Earth
U_1, U_2, U_3	Phase-to-neutral voltages
U_{NE}	Offset voltage
I_{C1}, I_{C2}	Capacitive currents of the two sound phases
I_{LP}	Inductive current through the earth-fault coil (compensation current)
I_W	Active component of the fault current
I_F	Current over the fault location

4.2 A closer look onto the zero phase-sequence system

When using the "Symmetric components", the following simple equivalent circuit diagram (system analyzer) may be given for the Zero phase-sequence system:





Map 4.2: One- phase equivalent circuit of the Zero phase-sequence system (system analyzer)

U_1	Phase-to-neutral voltage = interlinked voltage / $\sqrt{3}$
Z_U	Unbalance impedance of the system; mainly caused by the capacitive unbalance ΔC against earth
C	Medium equivalent capacity of the three conductors against earth
X_P	Inductivity of the Petersen Coil
R	Ohmic losses in the system

This simplified equivalent circuit applies as well for the case of an earth-fault, as also for the sound system operation.

In the **sound system operation**, Z_U is essentially determined by the capacitive unbalance of the single conductors against earth. In the usual systems, the conductor-earth capacities are approximately equal so that the unbalance ΔC is very tiny. This, however, means that the unbalance impedance $Z_U = 1 / \omega \Delta C$ becomes very big. Taking a look at the voltage divider shown in map 4.2, the user recognizes that the offset voltage U_{NE} in the resonance point (The reactive components of X_P and $X_C = 1/\omega C$ offset each other) becomes very low.

In the resonance point through the Petersen coil there is a reactive current of the same quantity as of the equivalent conductor capacity against earth, but with reversed signs. As soon as the Petersen coil is being changed, an inductive or capacitive reactive resistance will be effective parallelly to the active resistance. By this parallel-switching, the impedance in the lower part of the voltage divider becomes lower and thus, the measurable voltage U_{NE} becomes lower as well. Therefore, the user gets the following process, depending on the coil position for the offset voltage:





Map 4.3: Offset voltage U_{NE} depending on the coil position (resonance wave)

In the **case of an earth fault**, the unbalance Z_U mainly is determined through the transition resistance of the fault location resp. through the resistance of the 'burning' arc. This unbalance Z_U may be in the range of some Ohm (dead earth-fault) up to some kOhm (high-ohmic earth fault).


In case of a **dead earth fault**, the unbalance impedance Z_U becomes very low. Thus, the offset voltage U_{NE} becomes more or less independent from the setting of the P-Coil roughly equalling the feeding voltage E_1 . The current I_F overriding the fault location is composed of the active current over the resistance R and of the resulting reactive current over the two reactive resistances. In the resonance point, both reactive currents are of the same quantity but opposite, so that there is no reactive current overriding the fault location in this case. Depending on the setting of the P-Coil, there is, additionally to the active current, an inductive reactive current in the case of an overcompensation and a capacitive reactive current in the case of an undercompensation. The active current I_w and the resulting reactive current add each other geometrically to the fault current I_F over the fault location (see Map 4.4).

In the following map, the pointer display in the complex level for a overcompensated coil setting is shown. It is easy to recognize that in this case there is an inductive current over the fault location in addition to the active current.



Map 4.4: Pointer display of the fault current for a P-Coil setting

If only the "sum of the current" over the fault location depending on the set coil position is regarded, the waveform shown in Map 4.5 is resulting. This depiction often is defined as "V-Wave".




Map 4.5: Sum of the fault current depending on the P-Coil setting (V-Wave)

The quantity of the reactive current over the fault location, e.g. the detuning v may be calculated either as "absolute value" or as "relative value". The following equations are describing both of these ways of calculation:

$$\text{Detuning in [A]:} \quad v[A] = I_{pos}[A] - I_{res}[A] \quad (4.1)$$

$$\text{Detuning in [%]:} \quad v[\%] = \frac{I_{pos}[A] - I_{res}[A]}{I_{res}[A]} * 100 \quad (4.2)$$

In both equations, **positive** values define an "overcompensation" and **negative** values an anthe-compensation. A value of **zero** corresponds to a tuning to resonance.



Example:

Resonance current of the system : $I_{res} = 150 \text{ A}$
 (this corresponds to the capacitive current over C in case of a dead earth fault):

Present setting of the P-Coils: $I_{pos} = 160 \text{ A}$

The **absolute detuning** thus is calculated to:

$$v = 160 - 150 = +10 \text{ A} \quad (\Rightarrow 10 \text{ A overcompensation })$$

and the **relative detuning** is calculated as follows:

$$v = \frac{160 - 150}{150} * 100 = 6,66\%$$

Advantages of the input of an absolute detuning:

The regulator sets the reactive current overriding the fault location in a way that it is always equal. The reactive current is equal for small and for big systems. Furthermore, no fix coils (resp. firm coils) installd in the same quenching district have to be consitheed. The result is a clear statement on how big the expected reactive current over the fault location will be as soon as the regulator has successfully finished the tuning procedure and the earth fault has been made.


When indicating the values for the detuning in per cent, the reactive current becomes *dependant* on the system size (I_{res}). In this case, there must be the consitheaton of a fixcoil which possibly is located in the system. Defining the present values of the fixcoil(s), resp. which and how many fixcoils are momentarily active in the system, mostly is very difficult to detect. It is even more difficult to steadily re-set the regulator to this present sum value of the fixcoils.

In case of a detuning in per cent, the expected reactive current I_v in [A] over the fault location is calculated according to the following formula:

$$I_v = \frac{(I_{res} + I_{fix}) * v}{100} \quad (4.3)$$

I_v	Detuning current (Reactive current) in [A]
I_{res}	Current through the setttable P-Coils in the resonance point. I_{res} corresponds to the capacitive current of the system when earth fault
I_{fix}	Current of an additionnally switched fixcoil in the system
v	Detuning in [%]

With a compensation in per cent, very big systems are endangered that the recommended value for the neutralization limit acc. to VDE 228 Part 2 may be exceeded (bis 20 kV: 60A, when 110kV approx. 120 A).



Map 4.6: Neutralization limits according to VDE228, Part 2


Wave a: Neutralization limit for earth fault-residual ohmic current for systems with earth fault-compensation. This wave also applies for cable systems up to 20 kV nominal voltage with small open line component even with isolated neutral point.

Wave b: systems with isolated neutral point.


The expected contact voltage in the case of an earth fault should be taken into consideration according to the DIN VDE 0101 as a further criteria for selecting the compensation.

4.3 Principle of the regulation

The regulation of the Petersen coil is made during the sound system status through the evaluation of the resonance wave.



Map 4.7: Resonance wave



As already mentioned above, the single-poly equivalent circuit diagram applies as well for the sound system status, as also for the earth-faulted system status.

A switching in the system corresponds to a change of the conductor capacity against earth. Through this change, the complex voltage divider and thus the corresponding measurable offset voltage are changed as already described above. This is mainly a shift of the resonance wave to the left (switching-off the conductor capacities) or to the right (additional switching of conductor capacities). In most cases, this is also linked with a change of the capacitive unbalance ΔC . The switching of the system changes the offset voltage. This change is used for the recognition of a switching operation in the system and is the beginning of a tuning process.

Since the regulator does not know immediately if the system was enlarged or made smaller, the search for the resonance maximum in direction of a neutral position defined by the menu will be started. This neutral position itself has been defined in a way that the P-coil will be set to this value, in case of the regulator being unable for some reason to make a successful tuning. This neutral position is used to be selected to describe the most usual switching status of the system. Thus, it is most probable to find the resonance maximum with a search into this direction.

After a little setting of the Petersen-Coil by approx. 1,5 % of the maximum setting range, the gradient will be checked. If an incrementing offset voltage is recognized, then, the P-coil will be set by at least 5 % of the setting range. If no increase in the offset voltage is recognized, the search direction will be reversed.

During this setting, as well the offset voltage U_{NE} as also the corresponding coil position l_{pos} are measured and saved. By means of a "Non-linear Least Square Procedure", the regulator tries to lay a resonance wave over these measuring points. The estimated evaluation will be improved by each additional measuring point. The evaluation will measure best if the resonance point has been overridden at least once.

As soon as the regulator has accepted the resonance point, the requested final position will be calculated according to the requested over- or undercompensation and to the kind of compensation (absolute or in per cent). Then, the regulator directly goes to the final position.


After having reached the final position, the offset voltage and the coil position will be measured. By means of the measured coil position, a requested-offset voltage is measured from the estimated wave. This requested-offset voltage is compared to the measured one. If this offset voltage is within the trigger threshold, the tuning procedure will be regarded as successful and finished. The presently measured offset voltage now is used as the new reference value for the recognition of new switching operations. If the measured offset voltage is beyond the trigger threshold, it will be assumed that a switching operation has been made during the regulation and a new tuning procedure will be started immediately.

The resonance wave may be described completely by three parameters:

I_{res}	Capacitive current of the system.
U_{res}	Offset voltage U_{NE} in the resonance point
I_w	Active current I_w through R when dead earth fault


Resulting from this, the attenuation d of the system may be calculated:

$$d = \frac{I_w}{I_{res}}$$



By means of these three parameters, the single-poly equivalent circuit diagram of the Zero phase-sequence system may be calculated corresponding to Map 4.2 .

The attenuation d is a measuring quantity for the gradient of the resonance wave. Waves with a big attenuation are flat and essentially caused by big losses in the system. Flat waves are therefore mainly in open line systems. Contrarily, waves with a small attenuation are mostly used in cable systems.




Map 4.8: Parameter to the description of the resonance wave

The measuring of the active current may approximately effect according to the equivalent circuit diagram as follows:

At first, the P-Coil is tuned to resonance. Then the Petersen Coil is set until the offset voltage U_{NE} sinks to the value $1/\sqrt{2}$. The sum of the difference of I_{res} to the present coil position corresponds to the active current I_w .

$$|I_w| = |I_{res} - I_{ist_0.7U_{res}}| \quad (4.4)$$

The reason may quite easily be shown by means of the single-poly equivalent circuit diagram. In case of resonance, the reactive resistance in the lower part of the voltage divider is $X = X_C - X_{LP} = 0$. Only the active component R is efficient. If, due to the detuning, there is a parallel-switching between this resistance and a reactive resistance of the same quantity, the sum of the current I_w will, due to the resistance, be approximately the same as the sum of the reactive current through the sum-reactive resistance X . The resulting sum of the impedance of the parallel-switching of R and X has been decremented to the value $R/\sqrt{2}$. Therefore, the offset voltage U_{NE} also decreases to the value $U_{res}/\sqrt{2}$.



5 Technical Characteristics

5.1 Electrical Data

5.1.1 Rules and regulations

IEC 1010 / EN61010 (VDE 0411)
 CAN / CSA - C 22.2 No. 1010.1 - 92
 VDE 0110
 IEC 255-4
 EN 55011 : 1991
 EN 50082 - 2 : 1995
 IEC 688 -1
 IEC 529
 EN 50178 / VDE 0160 / 11.94 (z.Zt. Entwurf)
 VDE0106 TEIL 100
 DIN 40050

5.1.2 Alternating voltage input (U_{NE} and U_{12})

Offset voltage U_{NE}	0,1V ... 120V
Synchronisation U_{sync}	0,1V ... 230V
Wave form	Sinus
Frequency range	45.... <u>50</u>60....65 Hz
Power consumption	$\leq U_{nenn}^2 / 20 \text{ k}\Omega$
Overloadability	$U_{nenn} * 1,2$

5.1.3 Alternating current input (I_1 and I_2)


Current range	1 A / 5 A (hardware- and software selectable)
Wave form	Sine
Frequency range	45.... <u>50</u>60....65 Hz
Power consumption	$\leq 0,5 \text{ VA}$
Overloadability	10 A permanent 60 I_{nenn} for 1 s 30 I_{nenn} for 10 s 500 A for 5 ms

5.1.4 Position message (I_{pos})

Measuring sensor	Potential meter
Nominal values R_n of the	REG-DP: 150 Ω bis 3 k Ω
Potential meter	(REG-DE: 0,2 k Ω , 0,5 k Ω , 1 k Ω , 3 k Ω)
Measuring voltage	ca. 5 VDC
Current source over jumper	1 mA (3 k Ω)
selectable (R_{ein} of the regula-	5 mA (600 Ω)
tor)	10 mA (300 Ω)
	20 mA (150 Ω)

Error message when interruption or short-circuit breaking of the sensor resp. when the voltage of the wiper outranges the measuring range.

5.1.5 20 mA – Analog outputs



Number	see order features
Output range (Y1...0...Y2)	-20 mA...0...20 mA, Y1 and Y2 are free programmable
potential separation	Optocoupler
Load range	$0 \leq R \leq 8 \text{ V} / Y2$
Alternating part	$< 0,5 \% \text{ of } Y2$
Ripple	0,5 % referred to Y2
The output may either be permanently short-circuited or operated with openly.	
The output connections are galvanically separated from all other circuits	

5.1.6 Binary inputs

Inputs E1 ... E16	
Input voltage	AC/DC 48 V...230 V
Wave form, admissible	Rectangular, Sine
H – Level	$> 35 \text{ V}$
L – Level	$< 25 \text{ V}$
Signal frequency f_s	$\text{DC} \leq f_s \leq 60 \text{ Hz}$
Input resistance	$\geq 47 \text{ k}\Omega$
potential separation	Optocoupler; all inputs separated against each other separated

5.1.7 Relay outputs

Relay R1 ... R11, incl. Status	
max. switching frequency	$\leq 1 \text{ Hz}$
potential separation	Separated from all device-intern potentials
Contact load	AC 250 V, 5 A ($\cos\varphi = 1,0$) AC 250 V, 3 A ($\cos\varphi = 0,4$) DC 220 V, 55 W ($L/R = 0 \text{ ms}$) DC 110 V, 55 W ($L/R = 0 \text{ ms}$) DC 60 V, 55 W ($L/R = 0 \text{ ms}$) DC 30 V, 150 W ($L/R = 0 \text{ ms}$)
Number of switches	$> 10^5$ electrical
Statusrelay	Relay as open or close (selectable by solder jumper)


5.1.8 Reference conditions

Ambient temperature	$23^\circ\text{C} \pm 1 \text{ K}$
Inputs quantities	1 V, 5 V, 20 V, 100V
Auxiliary voltage	$H = H_n \pm 1 \%$
Frequency	50 Hz...60 Hz
Wave form	Sine, Form factor 1,1107
Load for analog output	$R_n = 4 \text{ V} / Y2 \pm 1 \%$
Others	IEC 688 - part 1

5.1.9 Electrical safety

Protection class	I
Pollution level	2
Overvoltage category	II, III

III	II
Input circuits of the current and voltage transformer power supply	Control circuits(DC), Analog inputs, Analog outputs, ELAN's, COM's



Nominal insulation voltages

50V	230V
E-LAN, COM1 - COM3, Analog outputs	Voltage inputs, Current inputs, Power supply, Binary inputs (E1 ... E16), Relay outputs (R1 ... R11) incl. Status relay

5.1.10 Electromagnetical compability

This instrument corresponds to the requirements of the interference emission and the interference immunity according to test basics EN 55011: 1991, EN 50082-2: 1995

Interference emissions

according to EN 55011

Limit value class A Group 1

Interference immunity

Electrostatical discharges

according to EN 61000-4-2

Air discharge 8 kV

Contact discharge 4 kV

Electromagnetical Fields

according to ENV 50140, ENV 50204

80 MHz...1000 MHz 10 V / m

Radio frequency range 10 V / m

900 MHz \pm 5 MHz 10 V / m
puls moduled

Fast transient interference quantities (Bursts)

according to EN61000-4-4

Supply voltage AC 230 V, 2 kV

Data lines 2 kV

Line-guided interference quantities

according to EN 50141

0,15 MHz...80 MHz $U_{eff} = 10$ V

Radio frequency range $U_{eff} = 3$ V

Magnetic fields according to EN 61000-4-8


50 Hz-Fields 30 A / m

Resistance to climatic changes

temperature range

Function (housing) -10 °C...+50 °C

Function (Plug-in group) -10 °C...+60 °C



Transport and storage -25 °C...+65 °C

5.1.11 Power supply

Feature	H1	H2
AC	85 ... 264 V	
DC	88 ... 280 V	18 .. 72 V
Power consumption	≤ 15 VA	≤15 VA
Frequency	50 Hz / 60 Hz	
Fuse	T2 250V	T2 250V

For all features applies:

Voltage breakdowns of ≤ 80 ms do not lead neither to a data loss nor to malfunctions.

5.1.12 Indication, Status

Indication, Display

LC - Display 128 x 128 with graphics capabilities

Function supervision (Status)


In each regulator, the battery, the marginal run of the processor (Watchdog) and the operation voltage are controlled.

Status indication LED - green



5.2 Mechanical Structure

5.2.1 Plug-in group


Front plate	Plastic foil on Alu-carrier, RAL 7035 lightgrey
Height	3 U (128,5 mm)
Width	28 TE (142,2 mm)
Weight	≤1,5 kg
Protection class	
Plug-in group	IP 00
Terminal block	IP 00
Mounting acc. to	according to DIN 41494 Teil 5
Connector	DIN 41612




Map 5.1: Dimensions



Map 5.2: Location of the circuit boards and plug connectors (View from above)




Map 5.3: Position of the terminal blocks (View from the rear)




5.2.2 Contact assignment of the Plug-in group

5.2.2.1 Contact assignment of the terminal blocks




Map 5.4: Contact assignment of the terminal blocks



5.2.2.2 Terminal block 1: Binary outputs REL

Funktion	Bez.	Belegung	Pin	Pin	Belegung
Höher (2 Kontaktpaare) 1 Öffner und 1 Schließer	R1	Pol	b2	z2	Öffner
		Pol	b4	z4	Schließer
		--	b6	z6	--
Tiefer (2 Kontaktpaare) 1 Öffner und 1 Schließer	R2	Pol	b8	z8	Öffner
		Pol	b10	z10	Schließer
		--	b12	z12	--
frei programmierbar	R3	Pol	b14	z14	Schließer
frei programmierbar	R4	Pol	b16	z16	Schließer
		--	b18	z18	--
frei programmierbar	R5	Pol	b20	z20	Schließer
HAND / AUTO	R6	Pol	b22	z22	Schließer
		Öffner	b24		
Status	Status			z24	Schließer
		Pol	b26	z26	--
frei programmierbare Ausgänge	R7/R9 R8/R10	--	b28	z28	Pol R7...R10
		Schließer R7	b30	z30	Schließer R9
		Schließer R8	b32	z32	Schließer R10




Map 5.5: Terminal block 1: Binary outputs R

The regulators are delivered with the above mentioned parameterization. The relays however are, up to the Status relay, free parameterizable through the software.

R1 ... R10: Status	Potential free relay contacts
loadability:	AC 250 V, 5A, $\cos\phi = 1$

Caution:

The binary output "Status" may be used either as „open“ or as „close“ by a corresponding order of a wire jumper. The position of the wire jumper is shown in map 5.6. **The not used function (wire jumper) must disappear.**



In "sound status" of the regulator, the status-relay is excited, e.g. picked up. By means of the wire jumpers shown in Map 5.6, there will be the possibility to select if the contact will be opened or closed in case of a fault.

Status-Relay with function Open: In case of a fault, the contact is opened.

The relay-coil will not be excited if there is a disturbance. Via the wire jumper, the operating contact of the status relay will be chosen.

Note:

The message of the following faults will thus be sent also to the control and instrumentation technology:

- withdrawn plug-in module
- failure of the auxiliary voltage at the regulator
- regulator intern default

=> remove wire jumper for function Close, wire jumper for function Open remains.


Status-Relay with function Close: In case of a fault, the contact is closed.

The relay-coil will not be excited if there is a disturbance. Via the wire jumper, the resting contact of the status relay will be chosen.


Note:

No error message will be sent if plug-in module is withdrawn.

=> remove wire jumper for function Open, wire jumper for function Close remains.



Map 5.6: Position of the wire jumper on circuit board 1



5.2.2.3 Terminal block 2: Binary inputs E

Funktion	Bez.	Belegung	Pin	Pin	Belegung
Endschalter Höher	E1	+	b2	z2	-
Endschalter Tiefer	E2	+	b4	z4	-
frei programmierbar	E3	+	b6	z6	-
frei programmierbar	E4	+	b8	z8	-
AUTO (Impuls)	E5	+	b10	z10	-
HAND (Impuls)	E6	+	b12	z12	-
Motor Höher (Imp.)	E7	+	b14	z14	-
Motor Tiefer (Imp.)	E8	+	b16	z16	-
frei programmierbar	E9	+	b18	z18	-
frei programmierbar	E10	+	b20	z20	-
frei programmierbar	E11	+	b22	z22	-
frei programmierbar	E12	+	b24	z24	-
frei programmierbar	E13	+	b26	z26	-
frei programmierbar	E14	+	b28	z28	-
frei programmierbar	E15	+	b30	z30	-
frei programmierbar	E16	+	b32	z32	-


Binäre - Eingänge 48-250 VAC/VDC																															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16																
Endschalter-Höher	Endschalter-Tiefer	prog	prog	Automatik (Imp.)	Hand (Imp.)	Höher (Imp.)	Tiefer (Imp.)	prog	prog	prog	prog	prog	prog	prog	prog																
b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z	b	z
2	2	4	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32

2


Map 5.7: Terminal block 2: Binary inputs E

Note:

All inputs E1 ... E16 are not available but in the 19" mounting frame. When using the 49 TE- wide wall-mounting rack (B02) resp. the 30 TE- wide panel-mounting rack (B03), not all inputs are available which is due to the limited number of connection terminals.



5.2.2.4 Terminal block 3: I_{pos} , U_{en} , U_{Sync} and Auxiliary voltage





Map 5.8: Terminal block 3: Offset voltage U_{en} and Auxiliary voltage

The offset voltage U_{en} may be used up to a rating value of 110 V.

The synchronization voltage U_{sync} is used as reference voltage to measure the phase angle as well for the offset voltage U_{en} as also for the currents I_1 and I_2 . The quantities are used in some calculation procedures for the regulation. As synchronization voltage, there may serve for example the interlinked voltage U_{12} . Other voltages may also be used, however, they must at least be system synchronic and they must not be influenced by a one-pole earth fault. The input for the synchronization is made for a nominal voltage of a maximum of 230V AC; a voltage of 50 VAC, however, is already sufficient. The voltage is internally transformed into a rectangular signal, so that no special requirements will have to be fulfilled, apart from the demanded minimum value and the synchronicity with 50 Hz voltage. An intern PLL-Switching (phase-locked loop) is synchronized by this synchronization voltage and interruptions of the synchronization voltage in the range of seconds have no effects, as for instance switching of the EB-Transformer to another busbar.

To reset the Petersen-coil, the Petersen-coil regulator mostly requires an auxiliary voltage of 230 V in the motor-drive box. If this voltage is missing, the regulator may not set the Petersen-coil. Thus, a supply of the regulator with this auxiliary voltage is normally sufficient. The data and parameters of the regulator are put in a buffer stock and do not get lost. This offers the possibility to use the auxiliary voltage as synchronization voltage. This is very favourable in case of an operation with several busbars because there will always be a synchronization voltage, independently from the switching status.




Map 5.9: Wiring proposal for U_{sync} with the auxiliary voltage of 230 VAC

Caution:


The wiring of the synchronization input with 230 VAC requires a suitable hardware version.

Necessary indication in the status-display of the regulator (key sequence: <Menu>, <F2>, <F5>, <F1>, <F5>):

Measuring-HW: NTZ2 /230V




The coil position of the Petersen-coil is measured by the voltage divider ratio of the potentiometer. The resistance-range of the potentiometer (terminal Pot+ / Pot-) may be in a range of 150 Ohm up to 3 kOhm. The linearization of the function coil position – inductivity effects with the putting into operation.



Map 5.10: Principal construction of the analog input for the coil position


In the following map, the corresponding positions of the jumpers on the subprint of the circuit board 3 are shown:




Map 5.11: Position of the jumpers for the coil position

Note:


In row 1, the position 3-4 is an empty position and may serve as carrier for reserve jumpers and will possibly be equipped (on the following maps: orange resp. lightgrey jumper).




Potentiometer (180 Ohm 3 kOhm)




Stromquelle 20 mA




Stromquelle 10 mA



Stromquelle 5 mA





Stromquelle 1 mA




Map 5.12: Equipment of the jumpers depending on the input function

Note:

The usual delivery status of the jumpers for the position message is made by means of a potentiometer.




Map 5.13: Coil position by controlled current source



Map 5.14: Potentiometer of the coil position in two-line wiring


If the potentiometer of the coil position is not available but in two-line-link, the switching shown in Map 5.14 may be used. In this case, the jumper 1-2 of row 1 must not be equipped. According to the maximum resistance value of the potentiometer, a jumper in row 2 must be set, considering the chart below and Map 5.12

Resistance range of the Potentio meter	Equivalent current source mA
0 ... 225 Ohm	20
0 ... 450 Ohm	10
0 ... 900 Ohm	5
0 ... 4500 Ohm	1



5.2.2.5 Terminal block 5: Coil position (only with REG-DE)

Function	Name	Assignment	Pin
Current source	Ipos	Ik	z2
Sensor +		Us +	z4
Sensor -		Us -	z6
Weight		GND	z8



Map 5.15: Terminal block 5: coil position Ipos

The current source is set to the external resistance by the software.
The maximum voltage of the current source is $< 5V$ DC.

Depending on the available links to the E-Coil, one of the shown possibilities may be used.

Switching 1: (2 Phases measuring)

The line resistances from the regulator to the E-Coil are not compensated.

Setting at the regulator: **3-Phases**

Switching 2: (3 Phases measuring)

Line resistances of the same quantity are compensated.

Setting at the regulator: **3-Phases**


Switching 3: (4 Phases measuring)

There is a complete compensation even from different feeder resistances from the regulator to the E-Coil.

Setting at the regulator: **4-Phases**


Note:

Since relatively big wire cross sections are usually used from the regulator up to the E-Coil and the resistance of the potentiometer is $> 200 \text{ Ohm}$, Switching 1 is recommended.



5.2.2.6 Terminal block 4: Current inputs, f.e. by the P-coil


Funktion	Bez.	Belegung	Pin
Spulenstrom (AC)	I_1	k	6
		l	5
Strom (AC)	I_2	k	4
		l	3




Map 5.16: Terminal block 4: Current I_1 (f.e. I_p) and I_2

Note:

Before changing the current ranges, the jumpers on the circuit board of terminal block 3 must be re-plugged to the required range.





Map 5.17: Position of the jumpers for the current inputs I_1 and I_2




5.2.2.7 Terminal block 6: 20 mA Inputs / Outputs; COM1-3

Funktion	Belegung	Pin	Pin	Belegung
20 mA Ausgabe (Modul 1) Verlagerungsspannung (1.1)	Uo+	b2	z2	Ipos +
Spulenstellung (1.2)	Uo-	b4	z4	Ipos -
E-LAN	links EA+	b6	z6	rechts EA +
	links EA -	b8	z8	rechts EA -
	links E +	b10	z10	rechts E +
	links E -	b12	z12	rechts E -
20 mA Ausgabe (Modul 2) Spulenstrom (2.1)	Ip +	b14	z14	frei +
frei (2.2)	Ip -	b16	z16	frei -
COM 2 (RS232)		b18	z18	
	TxD	b20	z20	RTS
	RxD	b22	z22	CTS
20 mA Ausgabe (Modul 3) Option frei (3.1) frei (3.2)	GND	b24	z24	+12V
	3.1 +	b26	z26	3.2 +
	3.1 -	b28	z28	3.2 -
COM3 (RS 485)	Tx +	b30	z30	Rx +
	Tx -	b32	z32	Rx -



Map 5.18: Terminal block 6: 20 mA Inputs / Outputs; COM1-3



Analog Input / Output-Channels

Two analog channels are available for each pluggable module. As a rule, the regulator is delivered with two modules which offers four analog output channels. From part of the factory, three channels are already plugged in with U_{en} , I_{pos} and I_p . However, their configuration may be changed at any time when they are put into operation.

The analog channels may be freely configured by the menu or by means of WinREG-DP. This permits the realization of, for example, Knick-characteristics, characteristics for the range 4-20 mA, logarithmical or user specific characteristics. For details see chapter 8.2.4.5 Analog Inputs/Outputs

The current source works on a load up to a maximum voltage of $\pm 8V$.

Interface COM 2 (optional)

The serial interface COM 2 and serves to couple a regulating system to a higher-levelled leading equipment. By means of this interface, there may be contacted for example the **REG-P** module which serves to link the REGSys using the IEC870-5-101 / 103 record.

Interface COM 3 (RS485) (optional)

By means of this interface, there may be additional switches in any required sequence, so that the inputs and outputs may be multiplied up to 15 interface components (BIN-D, ANA-D).


E - LAN (Energy - Local Area systemwork)

The E-LAN serves to linke a maximum of 255 E-LAN-participants (REG-DP, REG-D, MMU-D, PAN-D). All participants may intercommunicate but may also be center-controlled. (For selection and details please refer to the operating manual of WinREG-DP).

Features of the E-LAN

- 255 subscribers may be addressed
- multimaster-structure
- repeater function integrated
- open ring, bus or combination of bus and ring
- record based on SDLC/HDLC-frames
- transmission rate 62,5 kbit/s resp. 115 kbit/s
- telegramme length 10 ... 30 Byte
- average throughput about 100 Telegramme/s


Configuration see "E - LAN (Energy - Local Area systemwork)" on page 147.




5.2.2.8 Serial Interface COM1

Function	Pin
DCD	1
Rx	2
Tx	3
DTR	4
GND	5
DSR	6
RTS	7
CTS	8
RI	9

The serial interface COM 1 is at the front of the regulator and serves to couple PC, Terminal or Modem



Map 5.19: Serial Interface COM1




5.2.3 Wall-mounting rack 49TE

(TE \leftrightarrow Rack-units: 1TE = 5,08 mm)


Material	Polycarbonate (UL 94 V-0)
Protection class	housing IP 65
Weight	$\leq 1,5$ kg
Dimensions	see below

connecting elements screw terminals


cross section of the
connecting lines $\leq 4,0 \text{ mm}^2$ one-wire stranded
 $\leq 2 \times 2,5 \text{ mm}^2$ fine-wire stranded



Ansicht von unten



Frontansicht



Seitenansicht

Map 5.20: Wall-mounting rack 49TE

Caution

Wall-mounting rack must be grounded!
The corresponding connection is at the side of the regulator.

The earthing of the regulator is made by the screwed connectors of the front plate. The earthing will only be totally effective if the front plate is screwed-in.


5.2.4 Panel-mounting rack 30TE

(TE \leftrightarrow Rack-units: 1TE = 5,08 mm)



Material Polycarbonate (UL 94 V-0)
 Protection class housing IP 65
 Weight $\leq 1,5$ kg
 Dimensions see map below

connecting elements screw terminals


cross section the $\leq 4,0$ mm² one-wire stranded
 connecting lines $\leq 2 \times 2,5$ mm² fine-wire stranded



Seitenansicht



Frontansicht



Rückansicht


Schalttafelauausschnitt:
 184,5+0,2 mm x 138,3+0,2 mm

Map 5.21: Panel-mounting rack (30TE)

Caution

Panel-mounting rack must be grounded!
 The corresponding connection is at the rear of the regulator.

The earthing of the regulator is made by the screwed connectors of the front plate. The earthing will only be totally effective if the front plate is screwed-in.



5.2.5 19 Inch Plug-in group rack

Caution

Plug-in group rack must be grounded!

The earthing of the regulator is made by the screwed connectors of the front plate. The earthing will only be totally effective if the front plate is screwed-in.

Caution

Plug-in group rack must be grounded !

The earthing of the regulator is made by the screwed connectors of the front plate. The earthing will only be totally effective if the front plate is screwed-in.

Each plug-in group rack is provided with space for 84 units and thus for 84 place numbers "n". Each single place number is the point of reference for the mounting of the aligning plugs and the connection elements at the rear of the rack.


Terminal block	1	2	3	4	5	6
Screws	n	n+4	n+8	N+11	n+16	n+25
Aligning plugs	n	-	-	-	-	n+26


5.2.5.1 Plug-in group rack with Phoenix-terminals

Map 5.22: Example for 19" Plug-in group rack with Phönix terminals

5.2.5.2 Plug-in group rack with screw terminals


Map 5.23: Example for 19" Plug-in group rack with screw terminals





5.2.6 Standard assignment for Phoenix-terminals


(Typ 30TE, 49TE and Plug-in group rack with Phoenix-terminals)



Map 5.24: Standard – terminal assignment for wall- and panel-mounting rack


Note:

In case of wall- and panel-mounting rack, not all possible links have been brought out of the regulator (e.g.: the second E-LAN). An assignment according to user-specific requirements is possible.




5.2.7 Example for the link of the REG-DP to a P-Coil

In the following map, as well the links which are at least required between the regulator and the P-Coil, are shown as also the usual links between the regulator and the control room.




Map 5.25: Example for the connection of the REG-DP to a P-coil



5.3 Upgrading of analog inputs resp. outputs

How to proceed:

- Remove front plate from the REG-DP
(untighten 4x slot screws and pull off flat ribbon cable)
- Remove CPU-Platine REG-CPU
(loosen 2x screws and 2x retaining ring, then carefully remove CPU-Platine)
- Equip CPU-Platine REG-CPU with analog modules and plug onto the regulator again
(consider 2x plug-in connection)



Map 5.26: Slots for analog-double modules

After the analog-double modules have been inserted, the modules are automatically recognized by the regulator and are operated with accordingly.

Analog - Kanäle (Option)												
Eingang oder Ausgang												
Modul 1				Modul 2				Modul 3				
+	-	+	-	+	-	+	-	+	-	+	-	+
U ₀		I _{pos}		I ₂		prog		prog		prog		
-20 ... 0 ... +20 mA		-20 ... 0 ... +20 mA		-20 ... 0 ... +20 mA		-20 ... 0 ... +20 mA		-20 ... 0 ... +20 mA		-20 ... 0 ... +20 mA		
b	b	z	z	b	b	z	z	b	b	z	z	
2	4	2	4	14	16	14	16	26	28	26	28	
Feder-Leisten Nr. 6												

Map 5.27: Pin assignment of the analog-double modules


For this, the following channel assignment applies:

Module	Channel
1.1	1
1.2	2
2.1	3
2.2	4
3.1	5
3.2	6

- Plug-in CPU-Platine REG-CPU and front plate with flat ribbon cable again and screw them
- Parameterize the analog modules by the regulator-menu, by means of WinREG-DP or by means of REG-L commands. See also chapter " 8.2.4.5 Analog Inputs/Outputs"



6 Operation

6.1 Indication and operation elements



Map 6.1: indication and operation elements

6.1.1 Indication and operation elements



Map 6.2: LCD - indication im regulator mode

Analog-indication in the resonance-wave display	Definition
Imin	Final position "Lower"
▼	Ipos, the present coil position.
Imax	Final position "Higher"
Ires	Resonsance point from the last calculation.
--	Present value the Offset voltage Uen

Analog-indication in the detail- and large-scale indication	Definition
Imin	Final position "Lower"
A	Present coil position.
A	Present coil position, Uen has left the tolerance range.
Imax	Final position "Higher"
Ires	Resonsance point resulting from the last calculation.

Light-emitting diodes		
Status	green	Status of the regulator.
Ⓜ resp. Interference	red	Sum - Interference message. In the status line, a small message box will appear. Details may be polled by MENU><F5>
⬆ ⬆	red	Final switch "Higher" or Final switch "Lower " has been reached.
⬆ ⬆	red	Setting command "Higher" or "Lower" is edited. (Running message)
⚡	red	Earth fault.



LED 6	red	free programmable.
LED 7	red	free programmable.
LED 8	red	free programmable.

6.1.2 Function keys

Functions keys (F1...F5)

To select the several indication modes and to parameterize the P-coil regulator REG-DP.

Operation mode AUTO

for automatical regulation under consideration of the set parameters.

Operation mode HAND

To parameterize the REG-DP and to manually control the P-coil.

Operation mode Local / Remote

In the Operation mode "Remote", the following keys are blocked:

- <HAND>
- <AUTO>
- <Higher>
- <Lower>

The keys for the menu continue to be available here as well. It is also possible to navigate in the menu, and to regard and change the setting values.

ESC (Abort)

Short pressing of the key:

In the menu leads to a return to the above menu level

Long pressing of the key:

Return to the previously active indication mode (standard display, large-scale display or resonance wave)

Manual control of the P-coil

In the operation mode "HAND", the arrow keys "Higher" and "Lower" are used to control the P-coil drive.

Note:

The keys will only be active, if the regulator is switched to operation mode "HAND".

MENU and arrow keys \Leftrightarrow and \Leftarrow

The key menu is used to switch to the different operation modes (indication, recorder, statistics and Interferences-help) and to switch to the "SETUP" for parameterization.

In the "SETUP", the horizontal arrow keys \Leftrightarrow and \Leftarrow are taken to turn the pages between the single menu pages. Alternatively, there also is function key <F1> to turn the pages.

ENTER

To confirm a changed parameter in the "SETUP" menu points.

Repeat function

If a key is pressed down for quite some time, the function of the key will at first be repeated every second. After approx. 10s, the repeat frequency will be increased.

6.1.3 Plug connection at the front

Serial Interface COM1

To link the P-coil regulator REG - DP to external devices as for example Laptop or Modem.

6.2 Operation principle

The operation of the P-coil regulator REG - DP is made completely menu-guided.

Should regulation parameters be set or changed, the following operation principle applies:

Switching of the operation mode AUTO / HAND


- <HAND> Operation mode is changed to hand operation
- <AUTO> Operation mode is changed to automatical operation

Switching of the operation mode local / remote


- With every striking of key <local / remote> there will be a change to the other operation status. (Note: The change is also possible by the menu)

Switching to operation mode menu and parameterization


- Key <MENU> lists all possible operation modes




- Select menu point „SETUP“ with <F2>



- Turn pages through the keys <F1> to <F5> and the horizontal arrow keys until the required parameter is reached.




- Set the value of the parameter by means of the function keys.
 - <F1> increments the value in big steps
 - <F2> increments the value in small steps
 - <F4> decrements the value in small steps
 - <F5> decrements the value in big steps
- By the horizontal arrow keys <←> and <⇒> the value of the range counter may be changed in the right column. Therefore it is possible to navigate very quickly even with very big number ranges.
- <F3> resp. <F5> are occupied by special functions in some "SETUP"- menus.
- If the insertion of a value is finished, the changed value will have to be confirmed by key <ENTER>. Then, the regulator will switch back to the nearest higher level.
- Leaving the setting menu without changing the value: short striking of <ESC> (abort)
- Leaving the parameterization and return to the initial indication mode: long pressing of key <ESC> (ESC++)



- If the menu is indicated, a regulation may be made in the background, provided that the regulator has been in the operation mode "AUTO".
- In the operation mode "AUTO", the keys "Higher" and "Lower" are locked.


In the following map, the principle of the navigation between the single menu-levels and its effects are shown.



Map 6.3: principle of the navigation between the single menu-levels


Legend:

- < ... key arrow at the left
- > ... key arrow at the right
- F1 ... key F1
- F2 ... key F2
- ESC ... key ESC
- ESC++ ... key ESC, pressed down for longer than approx. 3 sec
- Menu ... key Menu



6.3 Selection of the indication mode

6.3.1 Indication mode indication




This selection menu may be reached by striking keys <MENU> <F1>

On this screen, the single indication modes of the regulator may be selected:

Turn pages between the kinds of displays:

Apart from the menu, also key <F1> permits the changing between the indication-modes.

6.3.1.1 <F1> Resonance wave:




Here the following is displayed

- the regulator status,
- the measuring values U_{en} and I_{pos} ,
- the calculated detuning v and the active current I_w
- the graphic indication of the resonance wave

1. Line:

A:
REG-DP
07:16:40

Address of the regulator at the E-LAN - Bus
Name of the regulator
Clock-time

**2. Line:**

In this line, the present regulator-status and the present searching delay are shown.

From the 3. Line on, the following values are indicated:


Parameter	Description
Uen	Presently measured offset voltage Uen in [%] referred to 100V, as secondary voltage of the voltage transformer or as primary voltage in [kV]
Ipos	By the potentio meter presently measured and linearized coil position in [A] or [%]. In case of the activation of a fixcoil, this one will not be considered in the indication.
V	Present detuning of the current referred to point of resonance measured resp. calculated in the last searching procedure
Iw	Calculated active part of the current in [A] via the fault location in the case of a low-resistant earth fault.

The upper and lower final positions of the P-coil are additionally indicated as sum message by means of a red LED. The movement of the P-coil as running message is also displayed by means of a red LED.

Change of the indication options

<F2> Switching to the display of the offset voltage Uen (%, V, kV)

<F3> Switching to the display of kvd and lw

6.3.1.2 <F2> Detail indication:


Here is the display

- of the regulator status,
- of the measuring value of the offset voltage Uen acc. to amount and angle,
- of the present coil position Ipos,
- of the calculated detuning v,
- of the measured current of the input transformer I1 according to amount and angle and
- of the calculated wave parameters: Ires, Iw and Ures

1. Line:

A:
REG-DP
07:13:37

Adress of the regulator at the E-LAN - Bus
Name of the regulator
Clock-time

**2. Line:**

In this line, the present regulator-status and the present search delay are shown.

From the 3. Line on, the following values are indicated:


Parameter	Description
Uen	Presently measured offset voltage Uen in [%] referred to 100V, as secondary voltage of the voltage transformer in [V] or as primary voltage in [kV].
Ipos	By the potentio meter presently measured and linearized coil position in [A] or [%]. In case of the activation of a fixcoil, this one will not be considered in the indication.
v	Present detuning of the current referred to point of resonance measured resp. calculated in the last searching procedure
I ₁	Measured current of the current transformer 1 e.g.: actually measured current through the Petersen-coil in [A] by the current transformer
Ires	Last measured resp. calculated coil position in [A] of which the maximum of the offset voltage (Ures) has been found.
Iw	Calculated active part of the current in [A] via the fault location in the case of a low-resistant earth fault.
Ures	Measured or calculated offset voltage Uen in the point of resonance (Ipos => Ires)
<i>Alternatively to Ires, Iw, Ures:</i>	
Ires	Last measured resp. calculated coil position in [A] of which the maximum of the offset voltage (Ures) has been found.
d	Operating loss of the system in [A] or [%]. When indication in [%] an activated Fixcoil is considered
k	Calculated unsymmetry of the system

The upper and lower final positions of the P-coil are additionally indicated as sum message by means of a red LED. The movement of the P-coil as running message is also displayed by means of a red LED.


Change of the indication options

<F2> Switching to the display of the offset voltage Uen (%, V, kV)

<F3> Switching to the display of the calculated system parameter (k,v,d resp. Iw,v,Ures)



6.3.1.3 <F3> Large-scale display:



Here the display shows

- the regulator status,
- the measuring values Uen and Ipos,
- the graphic indication of the present coil position Ipos and
- the graphic indication of the last measured point of resonance Ires

1. Line:

A: Address of the regulator at the E-LAN - Bus
 REG-DP Name of the regulator
 07:14:32 Clock-time

2. Line:

In this line, the present regulator-status and the present search delay are indicated.


From the 3. Line on, the following values are shown in large-scale format:

Parameter	Description
Uen	Presently measured offset voltage Uen in [%] referred to 100V, as secondary voltage of the voltage transformer or as primary voltage in [kV]
Ipos	By the potentio meter presently measured and linearized coil position in [A] or [%]. In case of the activation of a Fixcoil, this one will not be considered in the indication.
<i>alternatively:</i>	
Uen	Presently measured offset voltage Uen in [%] referred to 100V, as secondary voltage of the voltage transformer or as primary voltage in [kV]
V	Present detuning of the current referred to the point of resonance measured resp. calculated in the last searching procedure
v (SP)	Set setpoint value - Detuning of the current

Change of the indication options


- <F2> Switching to the display of the offset voltage Uen (%, V, kV)
 <F3> Switching to the display of the calculated system parameter (v, v(SP) resp. Ipos)

Graphic display of the coil position.



In the graphic display of the coil position, the present coil position is shown in the changing range of Imin up to Imax of the P-coil. The measured resp. calculated point of resonance Ires is marked with a downwards arrow..

6.3.2 Indication mode: Setup



By this menu point, the parameterization up to the following groups may be reached:

F2: Regulation

- F2: Standard Parameter
- F3: Earth fault
- F4: Umax
- F5: Umin

- F2: R - Control
- F3: Parallel - Regulation

F3: Putting into operation

- F2: Voltage measuring
- F3: P-coil
- F4: Indication Options
- F5: Input & Outputs

- F2: Fault acknowledgement
- F3: Current measuring


F4: Options

- F2: Local/Remote
- F3: Loc/Rem Release
- F4: Loc/Rem Function

- F2: Simulation
- F3: system model

F5: System

- F2: language
- F3: COM & E-LAN
- F4: Station identification



F5: Station name

F2: LCD saver


F3: Date & Clock-time

F4: Password

F5: Status

6.3.3 Operation mode Recorder

6.3.3.1 Indication des recorders



On the display, the temporal characteristic of the coil position I_{pos} and of the offset voltage U_{en} is shown as line diagram. At the left, the linearized coil position I_{pos} is displayed in [A] and at the right the offset voltage U_{en} is monitored in [V] logarithmically in a range of three decades which corresponds to the range of 0.1 V ... 100 V.

In the grid chart, the present values are on top of the grid. These present values are marked downwards through small arrows. In order to permit a better reading of the values, the measuring values are also displayed digitally.

By the digital indication for I_{pos} and U_{en} , the present status of the regulator is displayed. Thus, it is possible to recognize, even in the operation mode "recorder", the status in which the regulator is presently operating.



The present forward speeds are shown in the bottom corner at the right of the screen and they are selectable by means of the keys <F4> and <F5> in the following steps:

- 12s / Div,
- 1 min / Div
- 5 min / Div
- 10 min / Div

Keys <F1> and <F2> will switch to mode "Hitstory" and the memory may be polled for the requested events according to the given arrow directions.


By striking key <F3> there will be a switch to a submenu in which additional parameters may be set for den recorder.

6.3.3.2 Setting possibilities for the recorder


**Screen Scroll:**

By this parameter, the different feedrates for the keys <F1:⤴> and <F2:⤵> may be set for the search in the Hitstory- buffer. The following *step sizes per key strike* are selectable:

- 1 Pixel
- 1 Div
- 3 Div
- 5 Div
- 1 min
- 1 h



Time search:




To enable a faster search in the History – buffer, here it is possible to directly insert the date and clock-time of the instant to be examined. The instant corresponds to the position of the pen.

Selection of the values to be changed by means of key <F3> or by means of the arrow- keys <=> > and <=>. Via keys <F1>, <F2> resp. <F4>, <F5> the required value may be set.

<ESC> aborts the insertion whereas the value is taken over by <ENTER>

Filling level:




The present filling level of the recorder is shown here in % resp. in days.

Registering procedure of the recorder:

Each second is checked, if the measuring channels to be recorded have changed by a defined threshold value. If the threshold value is exceeded in positive or negative direction, a complete set of data is stored in the recorder. By this measurement, a very compressed recording is effected.

The memory itself is made as a ring memory, e.g. as soon as the buffer is full, the oldest data are overwritten. The thresholds are set in a way that three channels may be stored over a period of approx. one week, provided that there are the usual changes in the system.



By means of key <F5> the memory may be deleted.


Start / Stop:

Key <F5> stops the recording resp. restarts it.

By means of this key, the recording may be frozen so that, for example, the data are transmitted to a PC much later.

Channel 1 , Graphic at the left:

The assignment and the threshold values of the measuring values to be recorded, are freely selectable:




Assignment of the measuring value to the left-hand recording channel in the graphic. The left channel is displayed linear!

Measuring value	Description
Not used	No recording is made
Uen	Amount of the Offset voltage Uen in [V] (primary values)
Uen_Phi	Angle of the Offset voltage Uen, referred to U _{sync} - 30°
I1	Amount of the current input I1 in [A] (primary values)
I1_Phi	Angle of the current I1, referred to U _{sync} - 30°
I2	Amount of the current input I2 in [A] (primary values)
I2_Phi	Angle of the current I2, referred to U _{sync} - 30°
Ipos	coil position in [A], linearized and recalculated to the coil data
U _{sync}	Amount of the synchronization voltage.

Key <F3> may set the threshold value for the trigger-off of a new recording. After the recording, the present value is taken as new reference value for the recording.

Channel 2 , Graphic at the right:


The right-hand channel is stored logarithmically and also displayed logarithmically. This recording is preferred for the offset voltage Uen, because the interesting part is shown clearly even if the offset voltage is very low.

**Channel 3 , (invisible):**

In this channel, an additional information may be stored, e.g. the angle information of the offset voltage U_{en} .

Caution:

If the assignment of a recording channel is changed, all data stored in the recorder will be deleted.



6.3.4 Statistics


6.3.4.1 Indication of the statistics





The statistics is displayed as sum statistics (sum) or as statistics divided in calendar weeks (KW). Key <F3> permits the change between the single display kinds. A turn of the page may be made by key <F1> resp. by the arrow keys <> and <> .

The following data are recorded in the statistics:


Parameter	Description
Automation	Sum time of the operation mode Automation: overshoot when 100 000 h Automatic change of the edit to days: d
Motor On	Sum time of the change commands "Higher" and "Lower" Also the input Mot_Lauf of the P-Coil is considered.
Earth fault duration	Sum time of the earth faults including transient earth fault
Search	Number of the started search procedures
Tuned	Number of the successful tunings
Tuned n.k.	Number of the unsuccessful tunings
Tuned Umin	Number of the reached position Umin
Transient earth fault	Number of the transient earth fault (Earth fault lower than the set transient earth fault time)
earth faults	Number of the permanent-earth faults (without transient earth fault)
Iw - increments	Number of the residual ohmic current trigger-offs (Number of the R_on)
Trigger-offs	Number of the Trigger-offs (Leaving the Tolerance range)

6.3.4.2 Sum statistics:






In the last map, the recorded data of the statistics may be deleted.



6.3.4.3 Statistics per calendar week:




In the above map, the statistics-data of the calendar week KW44 are shown.

The selection of the calendar week is made by means of the keys <F2>, <F4> and <F5>.

The data may also be read out directly by means of a terminal using the following REG-L commands and they may be transmitted to other programmes as, for instance, Excel or Work, with Cut-and-Paste:

```
EspCounter <aufz> [<KW>] [=0] aktuelle Statistiker-Zählerstände
<aufz>: 1:SuchAnzahl, 2:Abgestimmt, 3:AbgestNK,
4:AbgestUmin, 5:ErdschlussWischer, 6:Erdschluss,
7:WattRestStrom, 8:Auslösungen
ohne <KW>: liest/setzt die Summen-Zähler
mit <KW>=1..53: liest/setzt die KW-Zähler
Zuweisungen: nur mit Extension '*' möglich;
zuweisbarer Bereich: 0...1e9;
Nachkommastellen werden ignoriert
```

```
EspStatist [<KW>] [<KW2>] liefert Tabelle aller Zählerstände
ohne Parameter: liefert Summenzählerstände
mit <KW>: liefert die Zählerstände der KW
mit <KW> und <KW2>: liefert die Stände von KW bis KW2
```



6.3.4.4 Example for statistics

sum statistics:

<A>espstatist

Statistik

	Auto	MotorEin	Erdschl	Suche	Abgest	AbgestNK	AbgeUmin	ErdschlW	Erdschl lw-Erhöh	Auslösg
Summe	2:21:57	0:06:09	0:00:01	6	5	1	0	1	0	2

seit 01.01.90


statistics von KW 42 bis KW 44

espstatist 42 44

Statistik

	Auto	MotorEin	Erdschl	Suche	Abgest	AbgestNK	AbgeUmin	ErdschlW	Erdschl lw-Erhöh	Auslösg
KW42/2001	0:00:00	0:00:00	0:00:00	0	0	0	0	0	0	0
KW43/2001	0:00:00	0:00:00	0:00:00	0	0	0	0	0	0	0
KW44/2001	2:26:33	0:03:01	0:00:01	6	5	1	0	1	0	2
Summe	2:26:33	0:03:01	0:00:01	6	5	1	0	1	0	2


6.3.5 Indication mode Interference help



As soon as an error occurs, a message will appear in the status line. By the indication mode Interference help (<MENU><F5>) detailed information may be read out. The error message may be acknowledged by means of key <F5>.

Note:


Only the last error is indicated.




7 Putting into operation

In this section, the basic way of procedure is described when the REG-DP is put into operation which is done by means of a typical configuration of a deleted system.

REG - DP



Map 7.1: Regulator with Petersen-Coil



Note

The structure of the following sections and the menu-structure of "**Putting into operation**" into the regulator has been made in a way that a complete putting into operation of the regulator may be made if the single points are worked through **from the top to the bottom**.

7.1 Hardware - Wiring

The wirings which are listed in the following points are, if necessary, to be executed resp. to be checked:

- Auxiliary voltage. Please consider the admissible range of the auxiliary voltages of the regulator (See label)
- Final switches messages from the P-Coil to the regulator
(Auxiliary voltage for the final switch to be considered)
(Also consider the type of the final switch: open / close)
 - Final switch Higher (Input E1)
 - Final switch Lower (Input E2)
- Change commands from the regulator to the P-Coil
(Auxiliary voltage for the motor contactor to be considered)
 - Motor Higher (direction I_{max}: Relay R1)
 - Motor Lower (direction I_{min}: Relay R2)
- Connecting of the potentio meter in the required way of switching. There possibly is the need for changes at the wiring on the potentio meter at the coil. (Details see chapter: 8.2.3 P-coil)

Note:

Check the direction of the coil change: If the current (coil position) is incrementing, the voltage divider ratio will also have to be increased.


- Wiring to the control room / supervisory remote control

Note:

As a rule, here another auxiliary voltage is used than with the message and control signals to the P-coil. It may be necessary to set intermediate relays.

- messages regulator => control room
 - Status
 - Diverse regulator messages
- commands control room => regulator
 - Change of switching Hand / Auto
 - Higher / Lower, if wired by means of the regulator.
- Measuring value transmission regulator => control room
The following values may be transmitted
 - U_{en} Offset voltage
 - I_{pos} coil position in [A]
 - I_l real current through the P-coils

The scaling of the analog-output is either made by REG-L commands or by the parameterization software WinREG-DP (See chapter 11 WinREG-DP).



7.2 Putting into operation without medium-voltage system


The following points may be made without switching the P-coil to the system.

After the turning-on, the regulator is in the HAND - operation and the regulator-parameters are loaded with "Factory setting".


In the following steps, the P-coil regulator is adapted to the data of the P-coil.
The putting into operation menu is reached by striking the following keys:

<MENU><F2><F3>

Thus, the following screen pages are available for the input of the parameters:



The points marked with ✓ in the following chart are to be checked with the first putting into operation and be adapted, if necessary. It is provided that the wiring for the message of the final switches (E1, E2) from the P-coil to the regulator as well as the wiring of the setting commande from the regulator to the P-coil (R1, R2) has already been made during the following putting into operation.




	Menu point Putting into operation 1/2	Factory setting	Note
	F2: Voltage measuring		
✓	F2: knU	115.0	Transmission ratio of the voltage transformer for a 20kV system $knU = 11550[V] / 100[V] = 115$
✓	F3: nominal voltage Uen	100 V	Nominal voltage of the transformer to measure the offset voltage in V
	F4: measuring range Uen	20 V	Measuring range for high-resolution measuring of Uen (only when REG-DE-I is required)
	F5: 50Hz Filter	EIN	50 Hz Filter for Uen (only when REG-DE-I is required)
	F3: P-coil F2: data of the P-coil data P-coil 1/2...		
✓	F2: Imin:	20 A	Lower limit value of the P-coil acc. to label
✓	F3: Imax:	200 A	Upper limit value of the P-coil according to label
	F4: coil position connection	Pot	Type of the position messenger in the P-coil and of the applicable link technology (only with REG-DE-I)
	F5: coil position R-value	1 kOhm	Maximum value of the position messenger (only with REG-DE-I)
	data P-coil 2/2...		
✓	F2: Final switch:	Close	Type of the final switch in the P-coil
✓	F3: Soft-Final switch active	Off	Activation of current limitations through the final switches settable by software
✓	F4: Soft-Final switch Imin	0 A	Software Final switch near to Imin
✓	F5: Soft-Final switch Imax	9999 A	Software Final switch near to Imax
✓	F3: coil - calibration		Automatical adaptation of the position messenger to the inputs of the regulator
✓	F4: coil - linearization		Semi-automatical linearization of the coil characteristic
	F5: Fixcoil	0 A	Sum of the fixcoils in the deleting range

By the start of the automatical coil calibration with <F2> the following data of the P-coil are measured by the regulator.


- Assignment coil position to the final switches "Higher" and "Lower"
- Running time of the P-coil for the changing of the P-coil over the complete range
- coil-play
- Overshoot of the P-coil
- Check of the moving direction of the P-coil on change of commands
- Recognition of wiring errors within the range of the position messagers

Note:

When error messages see chapter 8.2.1 Interface to the Petersen coil




coil- calibration :






With the coil calibration, there is at first a search for the final switch "Lower". Then, the P-coil is changed into the final switch "Higher". After having done this, the coil-play and the coil-overshoot in the middle of the changing range is measured. In preparation for the following coil linearization, the P-Coil is simultaneously set to the lower final position.

The successful coil calibration is shown on the screen as follows:



The results of the calibration may be read on the following pages of the menu "coil calibration", which may be switched to by means of key <F1>.




If the non-linearity of the potentiometer-characteristic is too big ($> 2\%$), please check the wiring. When 2 phases are used, the non-linearity may be big. For details please see chapter "8.2.1 Interface to the Petersen coil" resp. "5.2.2.4 Terminal block 3: I_{pos} , U_{en} , U_{sync} and Auxiliary voltage"

Final switch not wired:


If the final switches from the P-Coil to the regulator are not wired, it will be necessary to indicate this when selecting the used final switches. The type of the final switches is to be set to "None".

In this case, the coil calibration will thus not effect before the selection of the final switch. The regulator will recognize the final positions by supervising the position message of the potentiometer. If no change of the Petersen-coil is made into the selected direction for quite some time, then this will not be interpreted as interference when indication "No final switch" but as final switch in the present moving direction. The coil-linearization then will be made as the selection of a final switch.




F4:coil - linearisation

By the coil calibration, only the two final switches are assigned to. If the scaling on the mechanical indication of the P-coil is non-linear ist, so please also make a linearization for the regulator.




The following procedure is recommended for the linearisation:


- Manual change of the P-coil in the lower final position
 - Selection of 8 support points; please use more supporting plates in the lower range of the P-coils because here the non-linearity in this range usually is bigger.
There should be only supporting plates which are characterized at the E- Coil on the mechanical indication. The approach of these supporting plates should not be else than from the bottom to the top so that possibly present mechanical plays will have no effects.
1. Change the P-coil to the next selected support point
 2. By the arrow key < ⇒ > select the next line
 3. By <F3> take over the ohmic value of the P-coil
 4. Correct the indicated value of the current in [A] to the value of the P-coils set locally
- Repeat the last 4 steps until all 8 values are set or until I_{max} has been reached.



Indication - Options

For the adaptation of the screen-indication, the following menu points are available:






	Menu point <i>Putting into operation 1/2</i>	Factory- setting	Note
	F4: Indication Options		
	F2: indication Uen in	%	Display of the offset voltage on the screen. Selection possibilities: % ... Uen referred to the nominal value V ... Secondary side of the voltage transform. kV ... Primary side of the voltage transformer
	F3: Parameter	Uen, Ir, lw	Display of the calculated parameters of the resonance wave Selection possibilities: Uen, Ires, lw k, v, d
	F4: Current indication incl. Slavepos.	Yes	In the Master-Slave operation, the current display for Ipos and Ires is made including the present coil position of the slave

If only the standard functions of the regulator are required, the following menu points may be missed out:

	Menu point <i>Putting into operation 1/2</i>	Factory- setting	Note
	F5: Input & Outputs		
	F2: Binary inputs		Detail see chapter: 8.2.4.2
	F3: Relay outputs		Detail see chapter: 8.2.4.3
	F4: LED's		Detail see chapter: 8.2.4.4
	F5: Analog Input/Outputs		Detail see chapter: 8.2.4.5
	F2: Delays		Detail see chapter: 8.2.4.6

	Menu point <i>Putting into operation 2/2</i>	Factory- setting	Note
	F2: Fault acknowledgement	menu	Details see chapter: 8.2.5
	F3: Current measuring		Details see chapter: 8.2.6
	F2: Current nominal value I1	1A	
	F3: kn1	1,00	
	F4: Current nominal value I2	1A	
	F5: kn2	1,00	

Essentially, now there is a lack of no more than the parameters for the regulation behaviour. It is best to completely check the menu points for the regulation (<MENU><F2><F2>) and to set the required parameter.



In the following, please find a **reduced** summary of the recommended setting values (list of details see chapter: 11.6.2 Parameter print-out acc. to regulator menu):

F2: Regulation

Regulation 1/2...

F2: Standard Param.

Standard-Param. 1/4..

F2: tolerance range	[%]
F3: Uen-Tolerance :	20.0 %
F4: Delay of the search by:	10.0 s (should be incremented to 180s)
F5: Delay of the forcing search:	10.0 s

Standard-Param. 2/4..

F2: Setpoint detuning in	[%]
F3: Setpoint detuning	+10.0 %
F4: positioning Tolerance[%]:	1.0
F5: minimum setting dIpos[%]:	5.0

Standard-Param. 3/4..

F2: Override resonance maximum:	YES
F3: Pulling of Uref [min]:	5.0
F4: Uen angle measuring	ON

Standard-Param. 4/4..

F2: Search cycles max.	10
F3: Motor running time max [min]	45
F4: Rest pos. Search	Last tuning position
F5: Rest pos. Search [A]	50.0

F3: Earth fault

Earth fault 1/2...

F2: Uerd-Treshold	30.0
F3: Transient earth fault[s]:	7.0
F4: Uerd-message delay [s]:	5.0
F5: Self-conduct with Uerd:	OFF

Earth fault 2/2...

F2: Correction Ipos	OFF
F3: Correction Chart	
F2: dlc_1 [A] =	0.0
F3: dlc_2 [A] =	0.0
F4: dlc_3 [A] =	0.0
F5: dlc_4 [A] =	0.0


F4: Umax

F2: Umax-Treshold [%]	30.0
-----------------------	------

F5: Umin

Uen < Umin 1/2...

F2: Umin-Treshold [%]	0.2
F3: final position	last tuning position
F4: Message Uen<Umin for [min]:	15.0



F5: new search for [min]: 60

U_{en} < U_{min} 2/2...

F2: dU_{en}-limitation in U_{min}[%]: 30.0

F3: Self-conduct when U_{min}: OFF

Regulation 2/2...

F2: R - Control

R-Control 1/3...

F2: Resistance control OFF

F3: ON delay [s]: 1.0

F4: R-ON time [s]: 1.0

F5: Self-conduct: Off

R-Control 2/3...

F2: R-ON time maximum[s]: 10.0

F3: R-temperature maximum [°]: 200.0

F4: R-Cooling time [min]: 60

R-Control 3/3...

F4: Repeat delay [s]: 1.0

F5: Repeat cycles: 0

F3: Parallel - Regulation

Parallel-Regulation 1/2 ...

F2: Parallel-Prog OFF

F3: Parallel-Prog active: OFF

F4: Slave identifier ---

F5: Pulling of slave No

Parallel-Regulation 2/2 ...

F2: Slaveposition when U_{min}: Stop

In the menu for the putting into operation, the inputs, relays and the LEDs may be assigned to the corresponding regulator functions. In addition to that, the following parameters may also be set there.

Putting into operation 1/2...

F5: Inputs&Outputs 2/2

F2: Delays

F2: Minimum hold time Relay[s]: 0.0

F3: Prolong. of impulse Mot-H/T [s]: 4.0

F4: Message delay Alarm [s]: 0.0

F5: Message delay Interference [s]: 0.0

Putting into operation 2/2...

F1: Fault acknowledgement Menu /H/A

F3: Current measuring

F2: Current nominal value I1 1 A

F3: knI1 100

F4: Current nominal value I2 1 A

F5: knI2 100

Options 1/2

F2: Local / Remote
F3: Loc/Rem Release:
F4: Loc/Rem Function

Local
locked
Off

Options 2/2

F2: Simulation

OFF

The system parameters like language, COM1, COM2, ELAN, password, status, date, clock-time may be found in menu point "System".


7.3 Putting into operation with medium-voltage system

The described steps for the putting into operation could be made without having had to link the P-coil to the medium-voltage system.

By the start-up of the medium-voltage system, the regulator may measure the offset voltage U_{en} . If the regulator is switched from HAND to AUTO, it will start a search run and make a tuning.

Note:


Please consider that the regulator is not switched to the simulation mode. In this case, an offset voltage would be simulated. In the simulation mode, the changing commands are not edited to the real P-coil. In the following map, the marks for the simulation mode is shown on top of the status line:



7.4 Check of the digital information regulator \Leftrightarrow supervisory remote control

After the successful tuning, the remaining links to the supervisory remote control may be parameterized and tested.

If the link is made to the control and instrumentation technology by the serial interface (e.g.: IEC 870-5-101 / 103), then the answers to the general questions may be found in the operation manual of the REG-P resp. on the Homepage www.a-eberle.de . For detailed questions, please refer to our project department under +49-(0)911-628108-78 resp. -86.



- Check of the messages regulator => control room
 - Status
 - regulator Hand
 - regulator Automation
- Check of the commands control room => regulator
 - Switching from Auto => Hand
 - Switching from Hand => Auto
 - Change of the P-coil: Higher
 - Change of the P-coil: Lower
- Check of the other messages regulator => control room

7.5 Check of the analog Information regulator => supervisory remote control

- Scaling and assignment of the analog outputs see chapter 8.2.4.5

7.6 Operation with Fixcoil

On the regulator, the "Actual-position" (lpos) and the point of resonance "lres" are always indicated, including the Fixcoil.

For the regulator, a preparameterized Fixcoil is activated by a binary input. The input may be chosen according to the user's requirement (See chapter "8.2.4.2 Binary Inputs")

The activation of the Fixcoil may be messaged through the regulator by means of a LED or a relay (See chapter "8.2.4 Inputs & Outputs")

Depending from the selection of the screen indication, there are the following possibilities:


- 1) indication on the screen, if the detuning is selected in [A]:

$$v_IST [A] = lpos [A] - lres [A]$$

d[A]

with

lpos	Present coil position including Fixcoil in [A]
lres	Coil position of the resonance maximum including fixcoil in [A]
v	Present detuning referred to the last found point of resonance lres. The indication is made in [A]
d	Operating loss of the system in [A]



2) Indication on the screen if the detuning is selected in [%]:


$$v_IST [\%] = 100 * (I_{pos} / I_{res} - 1)$$

$$d [\%] = 100 * d[A] / I_{res}$$

I_{pos}	Present coil position including fixcoil in [A]
I_{res}	Coil position of the resonance maximum including fixcoil in [A]
v	Present detuning referred to the last found point of resonance I_{res} . The indication effects in [%]
d	Operating loss of the system in [%]



8 SETUP



The following submenus may be reached by the Setup:

F2: Regulation

F2: Standard Parameter
F3: Earth fault
F4: Umax
F5: Umin

F2: R - Control
F3: Parallel-Regulation

F3: Putting into operation

F2: Voltage measuring
F3: P-coils
F4: indication Options
F5: Inputs & Outputs

F2: Fault acknowledgement
F3: Current measuring

F4: Options


F2: Local / Remote
F3: Loc / Rem Release
F4: Loc / Rem Function

F2: Simulation
F3: system model

F5: System

F2: language
F3: COM & E-LAN
F4: Station identification
F5: Station name

F2: LCD saver
F3: Date & Clock-time
F4: Password
F5: Status



8.1 Regulation

In the menu point Regulation, the following subgroups are settable

F2: Regulation

F2: Standard Parameter



F3: Earth fault


F4: Umax

F5: Umin

F2: R - Control

F3: Parallel-Regulation





8.1.1 Standard Parameter

For the parameterization the Regulation, the following menu displays are available:

REG - DP a-eberle

Status: ☒ M ☐ + ☐ $\uparrow\downarrow$ ☐ ω

A:REG-DP 17:05:27

Standard-Param. 1/4..

Toleranzbereich relativ

Uen-Toleranz [relativ%]: 20

Verzögerung der Suche um: 10 s

Verzögerung der Zwangssuche: 10 s

F1 F2 F3 F4 F5

AUTO \uparrow local param. EDC MENU

HAND \downarrow \leftarrow \rightarrow \swarrow

REG - DP a-eberle

Status: ☒ M ☐ + ☐ $\uparrow\downarrow$ ☐ ω

A:REG-DP 17:05:46

Standard-Param. 2/4..

Sollverstellung in [%_A]:

Sollverstellung [%_A]: 10

Positionierungstoleranz[%]: 1.0

Mindestverstell. dPos[%]: 5.0

F1 F2 F3 F4 F5

AUTO \uparrow local param. EDC MENU

HAND \downarrow \leftarrow \rightarrow \swarrow

REG - DP a-eberle

Status: ☒ M ☐ + ☐ $\uparrow\downarrow$ ☐ ω

A:REG-DP 17:06:20

Standard-Param. 3/4..

Resonanzmaximum überfahren: JA



Nachziehen von Uref [min]: 5

Uen Winkelmessung Ein

F1 F2 F3 F4 F5

AUTO \uparrow local param. EDC MENU

HAND \downarrow \leftarrow \rightarrow \swarrow



Explanation of the single parameters:

After a successful tuning process of the Petersen Coil, the present offset voltage U_{en} is taken as new reference value U_{ref} . From this time on, the offset voltage is steadily being supervised. From regarding the change of offset voltage, a switching action will be recognized. If the offset voltage leaves the defined tolerance range during the complete trigger-off time, a new tuning process will be started.

8.1.1.1 Tolerance range

Kind of the tolerance range :

Parameter	Description
relative	The indicated tolerance range is referred to the reference voltage U_{ref}
absolute	The indicated tolerance range is independent from the reference voltage. Values in per cent are referred to the nominal voltage.

8.1.1.2 U_{en} – Tolerance range

Value of the tolerance range:


Parameter	Description
relative / %	Tolerance range for U_{en} referred to U_{ref} (Voltage when successful tuning):
absolute	Tolerance range for U_{en} (absolute):

standard setting: 20%

Example:

A value of 20 % means that a search procedure will be started if offset voltage is outside the tolerance range from ($U_{ref} * 0.8$) to ($U_{ref} * 1.2$) during the complete time of the set search delay.

If there is only an amount measuring of the offset voltage, so the angle changes of the offset voltage will not be recognized.



However, if the measuring of the offset voltage is made to amount and angle, the "change of the angle" will also be evaluated. For the angle measuring, some system-synchrone reference voltage is required, which is also there during the earth fault. It is recommendable to use an interlinked voltage U_{12} . Since a change of the Petersen-Coil usually requires an auxiliary voltage of 230 VAC this one may also be used. The advantage compared to the use of the interlinked voltage U_{12} is that a necessary changeover is no longer required in a several busbar-operation.

In the following map, the tolerance range is shown in the complex level.




Abb. 8.1: Tolerance range for the start of the tuning

Evaluation of the amount of the Offset voltage: A searching procedure will be started if the offset voltage is either outside the biggest circle (1) or within the smallest circle (2) after the changeovers of the system during the complete time delay.

Evaluation of the amount and of the angle of the Offset voltage: A searching procedure will be started if the offset voltage is outside the circumference (3) after the changeovers of the system during the complete delay time.

It is evident that essentially more changeovers are recognized in the system by rating the amount and angle.

8.1.1.3 Delay of the Search by x s


During this set time, the offset voltage has to be outside of the tolerance band so that a search will be started. If the offset voltage returns into the tolerance band before the set time has run out, the counter will be set to its maximum previously set time. During the delay time, the remaining time to the start of the search is being displayed in the status line.

Note:

The usual setting value is within a range of 2 to 3 minutes (120 .. 180s), so that the changeovers of the system may be finished before a new search procedure will be started.

The factory setting is set to 10s in order to permit the reduction of waiting times when putting into operation.

standard setting: 180s



8.1.1.4 Delay of the forcing search: x s

A shortened reaction may be set by changes to which **no former history** of the system status must be taken into consideration, as it is for instance when switching from Hand to Automation locally or by the control and instrumentation technology.

standard setting: 10s

8.1.1.5 Setpoint detuning in %

By means of this parameter please select **how** the detuning is measured

Parameter	Description
%	The value of per cent refers to the resonance current I _{res} . (Caution: In big systems, the neutralization limit may possibly be exceeded)
A	The detuning always effects by the same amount independently from I _{res} .
V	The detuning is set in a way that the indicated offset voltage will be reached.

8.1.1.6 Setpoint detuning

In this menu point the quantity of the detuning is set.

Positive values define an overcompensation

(The E-Coil delivers more current than the capacities of the system in case of an earth fault => Overcompensation)

Negative values define an undercompensation.

A value of **zero** means a tuning to resonance.

standard setting: +10A

8.1.1.7 Positioning tolerance

With this parameter, the tolerance is set when the P-coil is being positioned. The value in per cent is referred to I_{max} of the P-Coil. A proposal for the positioning accuracy is measured by the regulator during the putting into operation through the measuring of the coilplay and of the overshoot.

Note


If the coil-play or the overshoot are too big, it will be possible to avoid oscillations by enlarging this value.

standard setting: 1%

8.1.1.8 Minimum change dlpos

For the evaluation of the resonance wave, a minimum change of the P-Coil is required in order to have enough support points for the calculation.

standard setting: 5%



8.1.1.9 Overriding the resonance maximum

The most exact parameters of the resonance wave may be measured by overriding the point of resonance. If the point of resonance is not overridden, it will only be possible to estimate the value of the resonance current through the 2P-procedure. On the contrary, if the point of resonance is overridden, even the active current and the voltage in the point of resonance of the system will be measured by the considerably more exact 3P-procedure.

Parameter	Description
YES	resonance maximum must be overridden
NO	resonance maximum does not have to be overridden

8.1.1.10 Pulling of Uref in [min]

Changeovers in the system are always relatively fast and will thus be finished within some minutes. Nevertheless, changes through weather and feedover of load current changes are mostly very slow. The number of search procedures may be reduced if the tolerance range is being pulled for the slow changes. If the offset voltage does not leave the tolerance field within the set time, the present offset voltage will be taken as reference voltage at the end of this supervised time period. The quantity of the tolerance range will not be changed.



If a value of 0 is inserted, this function will be deactivated.

standard setting: 5 min

8.1.1.11 Uen - Angle measuring

Parameter	Description
YES	If the hardware permits it and if the synchronization voltage is connected, there will be an angle measuring. This will essentially have effects on the tolerance range and of the number of recognized switching actions.
NO	The angle measuring is suppressed. There is only the amount of the offset voltage available as tolerance range.

8.1.2 Earth fault




8.1.2.1 Behaviour when Earth fault

An earth fault is recognized, when the amount of the offset voltage U_{en} is bigger than the set threshold value U_{erd} . In the following map, the time behaviour of the regulator is shown.

There are two kinds of messages through the earth fault:

- The **undelayed** earth fault message
This message is edited immediately after having recognized the earth fault.
- The **delayed** earth fault message.
This message is not edited before the set delay time. Furthermore, the earth fault must be during the whole delay time.




T_{EW} Transient earth fault-time
 T_V Delay time for the earth fault message

Abb. 8.2: Time behaviour of the earth fault

The settable "transient earth fault time" has no influence but on the behaviour of the regulator. Referred to the duration of the earth fault, the following cases may be determined:

- $t_{erd} < T_{EW}$
 If the regulator was tuned when the earth fault occurred and provided that the offset voltage returns to its initial value within "transient earth fault time", it will be assumed that the P-coil has deleted the arc successfully. This is presumably made without changing the P-coils and without switching-off of the phase sections. It will thus not be necessary to readjust the P-coil.
- $t_{erd} > T_{EW}$
 If the earth fault is longer than the set transient earth fault time, it will be most likely that it had been necessary to make switch-offs of phases in order to eliminate the earth fault. To be sure that the P-coil is set onto the correct value, a search run will be started even if the offset voltage has returned to its initial value.

If the regulator has been on the search for a new point of resonance when the earth fault occurred, the search procedure will immediately be aborted. After having finished the earth fault, a new search procedure will be started even if the earth fault time is less than the set transient earth fault time T_{EW} .



8.1.2.2 Uerd - Treshold [V]

If the amount of the offset voltage exceeds this set treshold, the regulator will recognize an earth fault. The behaviour of the regulator will be influenced by the following parameters. A possibly running search procedure will be aborted at any rate.

The unit of the voltage depends on the set display of the voltage in the resonance display (%, V, kV)

standard setting: 30 [%]

8.1.2.3 Transient earth fault [s]

Description as above mentioned

standard setting: $T_{EW} = 7s$

8.1.2.4 Uerd-Message delay [s]

Description as above mentioned

standard setting: $T_V = 7s$

8.1.2.5 Self-conduct when Uerd


As described above, the regulator will automatically start a new tuning procedure after having finished an earth fault after the set delay time. This may be suppressed by the self-conduct. If the self-conduct is activated, the regulator will switch to operation mode HAND after the transient earth fault time and will have to be switched back to Automation either manually or by the control and instrumentation technology.

This is made to prevent a change of the Peterson Coil in the case of a longer search for the earth fault and its possible necessary changeovers resp. switching-offs.

standard setting: OFF


8.1.2.6 Readjusting the P-coil during the earth fault.

To continue to minimize the current over the fault location, the resonance regulator REG-DP may change the P-coil in the case of an earth fault. In the following chart, please find a selection list for the behaviour of the regulator:



Parameter	Description
OFF	In the case of an earth fault, there is no readjustment of the the coil position.
Ires	Readjust to the point of resonance. After the transient earth fault time has run out, the P-coil is set to the last calculated point of resonance.
KorrTab	Readjust by a defined value After the transient earth fault time has run out, the P-coil is readjusted by a defined value. The measuring of the correction value is described below.
Ires+ KorrTab	Combination of the two upper points. Change will be made to the point of resonance plus current correction.

The correction chart may be inserted by the following menu:



If the system is operated in a way that no phase switching-offs are made for the search for faults, there will be the possibility to work with selection "Ires". In this case, the P-coils will be set to the calculated point of resonance.

However, if there switching-offs resp. changeovers to other systems in order to limit the earth fault, then, there will be the necessity to correct the present coil position by these switched-off resp. changed-over amount.

In the menu there are four current values available for the correction during the earth fault. The set values, however, are not activated but by the digital input. The change value results from the sums of the set values, e.g. there are 16 possibilities through the four inputs. The correction values are referred to the P-coil and are inserted in [A]. Positive values mean that the P-coils are enlarged by the set value in the case of an earth fault.

If this option is activated, the switching status of the binary input during the last search of the point of resonance will be considered. A change of the binary inputs will be recognized even during the earth fault and the Petersen-coil will be readjusted according to the requirements. In sound operation, a new tuning procedure will be started in any case as soon as there is a change of the binary input.

Example 3.1:

Set values in the menu:

line 1: - 80 A

line 2: - 40 A

Selection of the readjustment: Ikorr

Present values of the regulator:

Ires = 200 A

Ipos = 220 A (10 % overcompensation)




Abb. 8.3: Current over the fault location

When line 1 with a capacitive current of 80 A is being switched off (map 3.2 case a) as fault limitation in case of an earth fault, this will be messaged to the regulator by a digital input. The switch-off corresponds to a shift of the fault current wave to the left.

The regulator reacts with a correction of the present coil position by -80 A. The P-coils are set to a value of $220\text{ A} - 80\text{ A} = 140\text{ A}$.

If, in addition to that, line 2 is also switched off, there will be a further correction by -40 A to 100 A.

Example 3.2:

Set values in the menu:

line 1: - 80 A

line 2: - 40 A


Selection of the readjustment: Ires + Ikorr

Present values of the regulator:


Ires = 200 A

Ipos = 220 A (10 % overcompensation)

In case of an earth fault, the P-coil is firstly set to Ires. If, in the fault limitation, line 1 with a capacitive current of 80 A is being switched off, this will be messaged to the regulator by a digital input. The regulator reacts with an additional correction of the present coil position by -80 A. The P-coils are set to a value of $220\text{ A} - 80\text{ A} = 140\text{ A}$ (case b). If, in addition to that, line 2 is also switched off, there will be a further correction by -40 A to 80 A.



8.1.3 Umax



This parameter describes the upper voltage range up to which a tuning may be made.


If the regulator reaches this limit value during the search, so the search will be aborted. The message $U_{en} > U_{max}$ will be edited.

If, by a switching action, a status is reached in the system that the offset voltage lies in the range $U_{max} < U_{en} < U_{erd}$, the regulator will try to find a point which is lower than resp. equal to U_{max} . To do this, the search procedure is started in the direction of the rest position. If an increment of the offset voltage is recognized, the search direction will be reversed. The change is made as long as the offset voltage undershoots the limit value.



indication: "Umax"

output function: " $U_{en} > U_{max}$ "

standard setting: 30% resp. identical to U_{erd}



8.1.4 Umin



8.1.4.1 Umin - Treshold

Voltages lower than this limit value are taken as "noise". If, in the process of triggering-off, the offset voltage is lower than this voltage, the complete range of changing of the P-coils will be searched for an offset voltage $U_{en} > U_{min}$.


standard setting: 0.2%

8.1.4.2 Final position when Umin

For the calculation and rating of the resonance wave it is demanded that at least one measuring point must be bigger than this set treshold U_{min} . If no valid rating is possible, the P-coils will be changed into a waiting position. This waiting position may be:

- rest position or the
- last point of tuning
(point of resonance including the set compensation of the last calculation)

standard setting: point of tuning



A new search procedure will be started if

- the offset voltage U_{en} leaves the tolerance band or
- a cyclical check of the point of resonance is set at the regulator.

8.1.4.3 Delay of the message U_{min}

By the parameter T_{Umin} , the delay of the message for U_{min} is set. If no search run is started during this time T_{Umin} , the message " $U_{en} < U_{min}$ " will be activated.

The most frequent cause is that the transformer resp. the P-Coil is set out of function for a short time during the changeovers of the system. If the P-coil is not switched to the system again after the changeovers, there will be no sufficient offset voltage available for the regulation and the regulator will send this message.

standard setting: 15 min

8.1.4.4 New search for [min]

If the offset voltage U_{en} remains lower than the threshold value of U_{min} during the complete set time, there will be an automatical search for the point of resonance after the run-out of this time.

In symmetrical cable systems and with a big detuning, it may happen that a switching action has only a small effect on the change of the voltage. Through this automatical search, however, it is made sure that a possibly not recognized switching action will be tuned correctly at least after the set time.

standard setting: 60 min

8.1.4.5 Limitation of dU_{en} when U_{min}

Since the offset voltage is superimposed by "noise" in case of very low voltages, a limitation of the trigger-off threshold will be made when there are low offset voltages. This means that, in case a standard parameterization for low offset voltage, the threshold for the start of a search procedure will at least be 33% of U_{min} .


standard setting: 33%



Figure 1 consists of two line graphs, (a) and (b), plotting the rate of reaction against temperature. Both graphs have a y-axis labeled 'Rate of reaction' and an x-axis labeled 'Temperature'.

Graph (a) shows a bell-shaped curve. The rate of reaction increases from 0 at 0°C to a peak at 30°C, and then decreases as temperature increases further. The curve is labeled with 'a'.

Graph (b) shows a curve that rises sharply from 0 at 0°C and then levels off at 30°C. The rate of reaction remains constant at higher temperatures. The curve is labeled with 'b'.



8.1.5.1 In general

The resistance control to increment the residual ohmic current in the case of an earth fault protects the resistance from a thermal overload. The through-rating power in the resistance is reconstructed by a **thermal replica**.

The resistance control is a **parallel** implemented independent control function to the P-coil regulation and is **not** influenced by a changeover of the P-coil regulator between Hand/ Automation or by an interference condition in the regulating circle of the P-coil regulator.

8.1.5.2 Description of the functions

The offset voltage U_{en} measured by the regulator is permanently supervised. If the offset voltage overshoots the set "Earth fault - Voltage" U_{erd} in the case of an earth fault, a cycle for the residual ohmic current increase will be started, provided that the resistance control is activated. The resistance is linked after a settable time delay (T_{R_vz1}) as long as there is the set ON time (T_{R_on}). The transient earth fault time T_{EW} has only influence on the behaviour of the regulator for the P-Coil and has no influence on the temporal run of the resistance control.





Abb. 8.4: Temporal run of the resistance control

The link of the resistance may additionally be triggered off by a binary input or by the serial coupling to the control and instrumentation technology. By supervising the resistance temperature rise by means of a thermal model, it will be checked before switching of the resistance if the limit temperature of the resistance is exceeded. If there is the danger that this limit temperature will be exceeded, then, the switching of the resistance will be blocked. The switching will only be possible again if the resistance has been cooled down enough to be under the limit temperature during the ON time. This thermal overheating of the resistance will be sent as message.

When the switching of the resistance is triggered off manually by a binary input or by the link of the serial control and instrumentation technology, the switching is not made before the run-out of T_{R_vz1} . In a manual trigger-off, the switching is made, even if there is no earth fault.

**Automatical repeat cycle:**

By the parameter T_N_cycle, the number of the repeats of the 2. ON-switching cycle consisting of the times T_R_vz2 and T_R_on may be set. If a value here is set bigger than zero, there will be the trigger-off of further switchings of the resistance after the first one which is automatically triggered off by the increment of the residual ohmic current caused by the earth fault.

The new switching of the resistance will also be checked for these cycles by means of the "thermal replica".

The number of the repeats of the cycle consisting of T_R_vz2 and T_R_on depends on the parameter T_N_cycle.

Self-conduct:


If the self-conduct is active, a new start-up of the resistance will be avoided after the first automatical residual ohmic current increment after the begin of the earth fault. The resistance automation will go to blocking.

A manual trigger-off of the residual ohmic current increment by a binary input or by the serial coupling is possible at any time. However, the resistance automation supervises the temperature of the resistance by a thermal replica.

Through the self-conduct it may be prevented that it may come to a permanently repeating start-up of the resistance in the case of high-ohmic earth faults resp. in the case of re-igniting earth faults.

The resistance automation may be made "ready" again by a binary input or by the serial coupling. The turning off and on of the resistance automation may also make the resistance automation "ready".

If the self-blocking is set to **AUTO**, so there will be, after cooling time of the resistance T_R_cold, an automatical "ready" making of the resistance automation for the next earth fault.



Setting parameter:

Title	Range	Factory-setting	Description
R-Control	OFF ON	OFF	Switching status of the resistance automation
T_EW	0,1s ...	5s	Transient earth fault - time, delay time between the entering and the message of the earth fault
T_R_vz1	0,1s...20s	1s	ON-switching - delay time after recognition of the earth fault
T_R_on	0,1s...20s	1s	ON time of the resistance
Self-conduct	OFF On Auto		Self-blocking after the first residual ohmic current increment
T_R_on_max	5s...200s	10s	Maximum ON time of the resistance
T_R_Temp		200	Final temperature of the resistance after T_R_on_max provided that there is an ambient temperature of 40 °C
T_R_cold	60min ... 600min	120min	Cooling time of the resistance down to the temperature of 40°C ($T_{R_cold} = 3 \cdot \text{cool-down time constant}$)
T_R_vz2	0,1s ... 100s	1s	ON-switching - delay time 2, Repeat delay after the last resistance start-up.
N_cycle		0	Number of the repeats of the start-up cycle consisting of T_R_on and T_R_vz2(0: no automatical repeat)

Binary input functions:

Title	Description
R_auto_on	resistance control on: An impulse switches the resistance control on
R_auto_off	resistance control off: An impulse switches the resistance control off
R_auto_onoff	The On-switching status of the resistance control changes by every impulse on this input line
R_block	Blocking the resistance control.
R_block_T	Coincidental blocking of the resistance control and of the regulator e.g. by overtemperature of the P-coil (Buchholz relay)
R_start	Manual start of the resistance control. (The increasing edge of this signal is evaluated.)
R_ready	Cancelling the self-blocking

Relay Output functions:

Title	Description
R_auto	resistance control active
R_ready	resistance control is "ready"
R_T_on_max	Resistance is too hot (triggered off by the internal thermal replica)
R_on	Turn-on of the resistance
R_block	Sum message of the blocking of the resistance control. The resistance is either blocked by the thermal replica or by a binary input resp. by the control and instrumentation technology.




Abb. 8.5: Example for the protective circuit of the resistance control

The resistance control will be released by one of the following events:

- activation by the menu of the regulator
- Impulse by the binary input function E_R_auto_on
- First impulse by the binary input function E_R_auto_onoff
- Switch-on - command by the control and instrumentation technology


The resistance control will be switched off by one of the following events:

- deactivation by the menu of the regulator
- Impulse by the binary input function E_R_auto_off
- Second impulse by the binary input function E_R_auto_onoff
- Switch-off - command by the control and instrumentation technology

In case of an activated resistance control, a start-up of the resistance would be avoided if the limit temperature during the following ON time had been outranged. The thermal model does not only consider the switching-on and cool-down times but also the offset voltage available during the ON time. This means that the resistance may be linked more often with higher-ohmic earth faults for which the offset voltage is lower. With activated resistance control, the regulator display monitors the remaining number of the admissible resistance start-ups in the upper right-hand corner of the display for the case of a dead earth fault.


On request, as well the remaining ON time as also the present temperature of the thermal replica may be edited by an analog output or transmitted to the control and instrumentation technology by the serial link.

If the resistance control is activated, an automatical trigger-off of the resistance start-up will be made as soon as the offset voltage is outranged although regulator itself is on mode "HAND".




Indication:

The status of the resistance automation is shown in the upper right-hand corner of the LCD-display:



The following indications are possible:

Indication	Description
R:10	Resistance control active and 10 residual ohmic current increments are possible for full offset voltage
*R:10	The residual ohmic current increment is about to be made. During the complete connection time T_R on a star is shown.
R:0	The resistance is too hot. A new connection is not possible before the remaining residual ohmic current increments have taken at least a value of 1. The message that the resistance has reached its limit temperature will additionally be sent by a relay.
[R:10]	The resistance automation is blocked



8.1.6 Parallel - Regulation

The Parallel - Regulation permits the recognition if there is a link by the E_LAN to the second regulator or not. If both regulators are installed in the same transforming station, a link via the E_LAN will be possible and the regulators may interchange the information directly.

If the regulators are installed far from each other, a communication by the E_LAN is mostly not possible. Nonetheless, both regulators will see the same offset voltage U_{en} , as soon as they are switched together in an neutralization field.

8.1.6.1 Master-Slave Operation mode

In the easiest form of a Master-Slave operation, a regulator will be blocked, as soon as the coupling of the two regulators is recognized. The present coil position of the slaves will be transmitted to the master by the E-LAN and, if required, considered for the calculation of the compensation. For the calculation of the setpoint position of the Petersen-coil, even possibly switched fixcoils as well at the master as also at the slave are taken into consideration.

The setpoint detuning in a per centual compensation $v[\%]$ is calculated as follows:

$$I_{soll} = v / 100 * ((I_{pos} + I_{fix})_{Master} + (I_{pos} + I_{fix})_{Slave})$$

In the Master-Slave operation, the Master recognizes as well the present coil position as also the possible changing range of the slave. If the Master recognizes during its tuning process that it may not reach the required final position but that this would be possible if the slave was changed so this will be made if it is permitted by the parameterization.


The following parameters are available for the parallel-regulation:

Title	Range	Factory-setting	Description
Parallel - Prog	OFF; Master/Slave; without comm.	OFF	Type of the used Parallel regulation
Parallel - Prog. active	OFF ON coupling	OFF	Kind of the activation of the Parallel - Programms
Slave identifier	A: ... Z4	--	Identifier of the slave.
Pulling of slave	NO YES	NO	Is the Slave to be changed by the Master.
SlavePosition when Umin	Stop rest_Su tuning pos	Stop	Position of the Slave if the offset voltage is $U_{en} < U_{min}$.

Depending from the set parameter, the parallel regulation with communication by the E-LAN is activated by a binary input. This coupling information (coupling) may also be sent serially to the regulator by means of the control and instrumentation technology (Precondition: control and instrumentation technology link by REG-P).

If two regulators are declared as Master at the same time, the regulator with the higher identifier will be the Master.

The Master recognizes the parallel operation, shows this on its display and sends an information to the Slave that it has to a Slave now. The Slave receives the information cyclical that it is a slave



during the parallel operation. If this information fails, the regulator will be an autonomous regulator again.

The Slave shows its "Slave-status" in its status line. The Slave may only be set into this status if it was set to automation before.

The Slave delivers its present coil position including a possibly activated fixcoil to the Master by the E_LAN.

The activation as Slave will even be made if this regulator is set on HAND. However, in this case, the Master must not pull the Slave even if this option is activated. The operation mode HAND is given priority.

If the Slave is corrected by the Master, there will be an indication on the Slave that it is being positioned by the Master: "Slave is being positioned"

Finishing of the coupling

Master:

The regulator leaves the status "Master" and starts the search procedure after the long delay time (Finishing is recognized as switching action in the system).

Slave to AUTO:

Slave leaves its blocking status and starts its search procedure after long delay time (Finishing is recognized as switching action in the system).

Slave to HAND:

The indication "Slave" is deleted on the screen. The regulator changes into the status "HAND".

8.1.6.2 Possible scenes for the Master Slave- operation:

8.1.6.2.1 Sound system :

- Master recognizes the busbar-coupling by the binary input
- Master sends the information cyclically to the Slave that it is the Master now.
- The Master takes over the coil position of the Slave and of the fixcoil values for the calculation of the setpoint position. The coil position of the Slave is sent cyclically to the Master.
- After the run-out of the search delay a tuning test of the Master will begin
- If the setpoint position lies within the changing range of the Master, the Master will get into the status "**Tuned**".
- If the setpoint position lies outside the changing range of the Master, the necessary difference will be calculated so that the future setpoint position will be approx. 10% within the changing range of the Master. This coil difference is demanded by the Slave.
- The demand is only made if the pulling of the Slave is released in the Master.
- If the Slave is present and the function "Pulling of slave" is activated, the Slave will try to deliver this required coil-difference. The Master will get the following information from the Slave:
 - Slave is about to be "pulled"
 - Final position reached
 - Final switch reached
 - Error when positioning

- As soon as the Slave has reached its final position or the final switch, the Master will begin with a new tuning process (Delay: forcing search).
- If the setpoint position lies within the changing range of the Master, the Master will get into the status "**Tuned**".
- If the setpoint position lies outside the changing range of the Master, the Master will get into the status "**Tuned,not compensated**".

8.1.6.2.2 Sound system but $U_{res} < U_{min}$:

- Master / Slave Regulation essentially effects like in the sound system.
- Slave position when U_{min} : Off
Master once searches the complete changing range. If it does not find an offset voltage over U_{min} , the Master will drive to the rest position or to the last point of tuning (Selection Parameter in the menu). The Slave is not being changed.
- Slave position when U_{min} : rest position
 - Master once searches the complete changing range. If it does not find an offset voltage over U_{min} , the Master will, at first, remain in the final switch.
 - The Slave is regulated in its rest position
 - If Slave is positioned successfully, the Master will once again try to find an offset voltage bigger than U_{min} , e.g. the complete coil range will be driven through once again.
 - If the Master finds an offset voltage bigger than U_{min} during the search and may drive to the compensated value, the Master will get to the status "**Tuned**".
 - If the Master finds an offset voltage bigger than U_{min} during the search and if the compensated value is outside this range, the difference amount will be demanded by the Slave (if permitted).
 - If the search of the Masters is not successful, the Master will be positioned to its rest position resp. to the last point of tuning (Selection Parameter in the menu of the Master). The regulator changes to the status "**Tuned U_{min}** ".
- Slave position when U_{min} : last point of tuning before Slave - operation
The regulation is made as above but instead of the rest position the last point of tuning before the Slave-operation is used.


The number of searching procedures is supervised. If the regulator does not reach the status "**Tuned**", "**Tuned not compensated**" or "**Tuned U_{min}** " within the permitted searching procedure, an interference message will be produced..

8.1.6.2.3 Sound system but $U_{res} > U_{max}$:

Master changes to the regulation " **U_{max}** "

8.1.6.2.4 Earth fault

- Slave is blocked
- Only the Master is readjusted according to the setting in the menu:
 - Off
 - Ires
 - Chart
 - Ires + Chart



8.1.6.3 Parall - Regulation without communication by E-LAN

In this regulation, special data may no longer be interchanged by a communication system. In order to reach a stable regulation even for several regulators in a system sector, some marginal conditions must be adhered to:

The following parameters must be **equal** for all regulators present in the same neutralization field:

- Absolute compensation
- The same value of the compensation in [A]
- Option Parallel-Regulation without communication activated by E-LAN.

Principle of the procedure:

This procedure may be compared to the talk behaviour of humans in a small group. If there is an event, so that some in a group would have to say something one person would be a little bit faster and begin to speak. As soon as the others realize that someone has taken the word, they would wait politely until the first person has finished to speak. If there was still something to say, the next person would speak. The others would then recognize again that someone speaks and would again wait for reasons of politeness until this person has finished to speak. If no one has anything more to say, they would wait until the next event happened to be.

This simple procedure is rebuilt in the regulators but the common media now is the offset voltage U_{en} . If the offset voltage is changing slowly, this will be leading to the assumption that another regulator is making a tuning procedure.


In order to avoid that the reaction speed of the regulator to a switching position becomes different, the trigger-off time is linked to a random number. This means that a random number in the range between zero and the coil running time will be added to the menu time set in the menu.

Before the regulator begins its search run, the offset voltage recorded within the last 20 seconds is checked if this offset voltage has not left the tolerance band during these 20 seconds. The present offset voltage is used as reference value for the tolerance band. If this is not done, there will be assumed that the other regulators have finished their tuning procedures.

If the offset voltage is outside the tolerance field, but now referred to the last tuning process, a new searching procedure will be started.

This procedure is no restricted to two regulators. The time until the tuning of the complete system increments with the number of parallel switched regulators.

In this procedure it may also not be made sure that each regulator takes over a defined part of the compensation. The neutralization condition is only fulfilled for the complete system. Should the strategy exist that the first measurement in case of an earth fault is to divide the big system in smaller parts, then, this procedure should not be used there.



8.2 Putting into operation

In the menu point Putting into operation, all characteristics in the link of the regulator to the process are defined.

F3: Putting into operation

F2: Voltage measuring

F3: P-coils

F4: indication Options

F5: Inputs & Outputs

F2: Fault acknowledgement

F3: Current measuring

8.2.1 Interface to the Petersen coil

When putting into operation, a semi-automatic adaptation of the regulator to the P-coil is made. For the calibration procedure, at least the following parameters of the P-coil are required for the insertion:

Title	Description
Imin	Neutralization current in the lower final position of the P-coils
Imax	Neutralization current in the upper final position of the P-coils
E_Type	Type of the final switches (open, close, None)
E1	Nominal value of the P-coil voltage in the case of an earth fault.
Uen_nenn	Nominal value of the offset voltage in the case of a dead earth fault at the secondary side of the voltage transformer integrated in the P-coil

In the following block diagram please find the assignment of the position message and the final switches:



REG - DP





Abb. 8.6: Coil position and Final switch assignment




When putting into operation a check is made of the following points by the regulator:

- Phase failure from regulator to locator of the P-coil (Potentiometer)
- Correct sequence of the wiring of the potentiometer (Pot+, Pot s, Pot-)
- Control of the direction of the coil movement in connection with the final switching messages
- The assignment of the final switches to the upper / lower voltage divider ratio of the coil position display
- Selection of the final switch types (There may for example not be both final switches on at the same time)

Binary inputs:

The "Binary Inputs" for the final position messages consist of optocouplers which are suitable as well for alternating voltages as also for direct voltage geeignet sind. There are high-ohmic resistances to be switched before these optocouplers so that the on-switching threshold is approx. 35 VAC.



map. 8.7: principle switching of the binary input

The right type of final switch of the Petersen coil must be given for the functioning of the regulation and for the plausibility control.

Note:

When using long open lines, interferences may deliver very high voltage values. In particular, the lines to the E-Coil should be controlled in reference to 50 Hz - interferences.



Possible measurements when interferences are too high:

- parallel switching of condensators to the input: the additional capacity reduces the effects of the interferences by the better voltage divider ratio
- attenuation of the input by an additional resistance
- setting of interrelays with a higher response threshold

The binary inputs of the "Final switch Higher" and "Final switch Lower" are already delivered with a condensator ($1\mu F$) from the factory.

coil position:

The potentiometer is coupled with the drive of the P-coil by a gearing. Therefore, the divider ratio of the potentiometer corresponds to the air gap d in the iron circle of the P-coil. In a linear coil, the inductivity would be reversed proportional to this air gap. The real flowing current through the P-coil, if the P-coil is connected to the nominal voltage, is again reversed proportional to the inductivity. This, however, means that the current through the P-coil on the primary side when nominal voltage is proportional to the length of the air gap d in the P-coil. This is one of the reasons why the P-coil is geared in [A].



Map 8.8: principle structure of a Petersen Coil

In the reality, however, the flowing of the P-coil current through the P-coil when nominal voltage is not completely proportional to the length of the air gap resp. to the potentiometer status due to non-linear couplings of the magnetic fields. This may be seen on the non-linear distribution of the mechanical current display. This mechanical indication is adapted to the P-coils by a real measuring at a P-coil, which is made directly in the factory. The regulator, however, can only measure at the potentiometer. An adaptation to the non-linear connection of the P-coil to the gauged coil current of the mechanical indication is usually made when the combination regulator / P-coils is being put into operation.

In the following map the principle input switching to detect the coil position is shown:





Abb. 8.9: principle structure of the analog input to the determination of the coil position



Potential meter:

A voltage of approx. 5 V is given from the regulator to measure the coil position. In the regulator, a current limitation and protective resistors have been mounted into the terminal for the case of a short circuit of the terminal blocks. Thus, a short circuit between the three phases Pot+ , wiper and Pot- during the putting into operation is not dangerous. The input to measure the voltage at the wiper (Us) is very high-resistant.

By the jumper 1-2 of the row 1 there is the feeding of a voltage, which permits the recognition of a phase failure at the wiper.

For the measuring, the phase resistances from the regulator to the potential meter of the P-coil are added. These may be in the range of some Ohm if the P-coil is placed some 100 m away from the regulator.


Due to the making process of the P-coil it is usual to use only part of the changing range from the mounted potential meter. This means that from a 200 Ohm potential meter only, for example, the part range of 20 Ohm up to 150 Ohm is covered by the P-coils. This assignment may differ even with P-coils of the same type of construction which is due to production tolerances.

Current source 0...1mA to 0...20 mA

In these sensor-switches an additional displacement of potential meter status to a load-independent current is made already in the motor junction box of the P-coil. In some transducer, as well the offset may be freely programmed as also the reinforcement of the transducer. In some devices, even a linearization of the characteristic is possible with little work.

Position and Function of the jumpers on the Subprint

In the following map the corresponding positions of the jumpers on the Subprint of circuit board 3 are shown:




Map 8.2: Position of the jumpers for the coil position


Note:

In the row 1 the position 3-4 is an empty position and may serve as carrier for reserve-jumpers and is possibly be equipped (on the following maps: orange jumper).


Potentiometer (180 Ohm 3 kOhm)




Stromquelle 20 mA




Stromquelle 10 mA



Stromquelle 5 mA




Stromquelle 1 mA




Map 8.3: Plug-in of the jumpers depends on the input function

Note:

The usual delivery status of the jumpers for the position message is made by means of a potentiometer.



Map 8.4: Potentio meter in two-phase - wiring



If the potentiometer of the coil position is only available in two-phase connection, the switching shown in *Map 5.14* may be used. In this case the jumper 1-2 of the row 1 does not have to be equipped. Corresponding to the maximum resistance value of the potentiometer there must be the setting of a jumper in the row 2 considering the chart below and *Map 5.12*.

Resistance range of the Potentiometer	Equivalent current source mA
0 ... 225 Ohm	20
0 ... 450 Ohm	10
0 ... 900 Ohm	5
0 ... 4500 Ohm	1

Putting into operation:


Some functions have been implemented in the regulator to simplify the putting into operation. The following steps are taken with the putting into operation:

- Changing of the P-coil into the lower final position.
In the lower final position, the assignment of the present potentiometer position effects to the given minimum coil current I_{min} by the regulator. The lower final position itself is given by the "Final Switch Lower" recognized by the digital inputs. If the option "No final switches" is selected, the final switch will be recognized if there has been no return message of a coil changing for a longer period of time. In this case, no error message will be produced but the assignment I_{min} will be brought to the momentarily measured coil position.

If the P-coil has already been in the lower final position at the beginning of the coil calibration, the P-coil will at first be set into the direction of the upper final position for 5 s before the search run will start. Then the search procedure of the lower final position will begin as described.

- Changing of the P-coil into the upper final position
Analog to the lower setting, the assignment of the potentiometer position to the given minimum coil current I_{max} effects in the upper final settings. Here, too, the upper position is recognized by the message "Final switch Higher" resp. by selection of the option "No Final switches" by the potentiometer if there has been no return message of a coil changing for a longer period of time.
- Changing of the P-coil into the middle of the changing range
- Measuring of the "coil-overshoot" and of the coil play by evaluating the behaviour of the P-coil onto the direction reversal of the coil changing.

The following points are especially supervised with putting into operation through the regulator:



Signals	Action	Error description
ET=1 & EH=1		Wrong type of final switch has been selected
dlpos = 0	Mot ↑ resp. Mot ↓	There is no message back from the coil position after a changing command. Possible causes are: - Changing command is not edited by the regulator - Coil does not react on changing command - Motor protecting switch fallen - Contactor in the P-coil wrongly wired - Contactor in the P-coil deficient - Coupling Motor - Potentiometer not ok - Potentiometer in the P-coil connected incorrectly - Error in the wiring potentiometer - regulator
dlpos = -	Mot ↑	The change of the P-coil is made in the wrong direction
dlpos = +	Mot ↓	The change of the P-coil is made in the wrong direction
dlpos = 0 ET = 0 lpos = lmin	Mot ↓	The P-coil is already in "Final switch Lower". The motor junction box in the P-coil has already reacted. The message of the second final switch for den regulator is not messaged by the P-coil. => Check final switch assignments.
dlpos = 0 EH = 0 lpos = lmax	Mot ↑	Error behaviour as above in "Final switch Higher".
Us > Upot+		Phase failure at the wiper
lpos strongly non-linear		Connection at the potentiometer mixed - Pot+ ↔ Pot s - Pot - ↔ Pot s This error may not always be recognized immediately because, during a coil changing, a change of the divider ratio is recognized. This is due to the protective resistances and phase resistances. (See map 8.8: principle structure of a Petersen Coil)
lpos unsteady		Gaps in the potentiometer, for instance the sliding contact lifts up in certain positions
lpos in steps		Too rough grading of the potentiometer, for example wire potentiometer with only 13 windings
lpos Hysteresis		Coil play The core of the P-coil is changed but the corresponding movement is not edited by the potentiometer ausgegeben wird. This is caused by a mechanical play between the movement of the core and the movement of the potentiometer.
lpos with interferences		Interferences on the digital input of the final switching messages

The following images result from the errors described above

Assumption:

Pot+: (R+) + R_{line +} = 10 Ohm

Pot-: (R-) + R_{line -} = 10 Ohm

Pot: 200 Ohm (Total resistance of the potentiometer in the P-coil)

The range at the potentiometer is used from the P-coil between 10% and 80%.





Abb. 8.10: Wiring okay




Abb. 8.11: wiper and Pot+ mixed




Abb. 8.12: wiper and Pot- mixed






Abb. 8.13: Potentio meter with 13 steps



8.2.2 Voltage measuring



Setting the transmission ratio knU

knU corresponds to the conversion rate to the primary voltage of the offset voltage

$$knu = \frac{U_{Nenn}[V]}{100[V]} \quad (8.5)$$

Example:

$$\text{For a 20 kV system : } knu = \frac{20[kV]}{\sqrt{3}} * \frac{1}{100[V]} = \frac{11550[V]}{100[V]} = 115$$

standard setting: 115 (for 20 kV system)

nominal voltage


The indicated nominal voltage corresponds to the nominal voltage of the voltage transformer to measure the offset voltage on the secondary side. The values of 100 V and 110 V are usual.

standard setting: 100 V

measuring range Uen (Only with REG-DE Version 1)

For the version REG-DE I the following ranges may be selected:

1 V
5 V
20 V
100 V




Filter 50 Hz (Only with REG-DE Version 1)

For the regulation only the 50 Hz component of the offset voltage U_{en} may be used. In the zero system there are also harmonic voltages included which may lead to an incorrect tuning. To eliminate resp. reduce these harmonic voltages considerably, the 50 Hz Filter is activated. In the REG-DP II Hardware the filter is always switched on.

Selection possibilities:

ON	Das 50 Hz Bandfilter is activated.
OFF	Das 50 Hz Bandfilter is turned off.


8.2.3 P-coil



8.2.3.1 Data of the P-coil

In this menu the following values may be set:


Title	Factory-setting	Description
Imin		Neutralization current in the lower final position of the P-coil
Imax		Neutralization current in the upper final position of the P-coil
Ipos: connection		Only with REG-DE I: Selection of the connection version: Pot, 0..20 mA , 3phases, 4phases
Ipos: R-value		Only with REG-DE I: Resistance value of the locator as for example 1 kOhm
Final switch	close	Type of the final switch (open, close, None)
Soft-Final switch active	Off	If the final switches simulated by the software are active, the searching resp. positioning range of the Petersen Coil will be limited to these values. Will not be active before the coil calibration.
Soft-Final switch Imin	0 A	"Final switch Lower" simulated by software
Soft-Final switch Imax	999 A	"Final switch Higher" simulated by software



8.2.3.2 Coil calibration

In this menu the calibration procedures which have been described very clearly above are executed.


The calibration is started by the following menu display.



In the coil calibration there is primarily searched for the Final switch "Lower". Then the P-coil is set in den Final switch "Higher". After that, the coil-play and the coil-overshoot in the middle of the changing range is measured. The P-coil is immediately changed to the lower final position in preparation for the following coil-linearization.

The measured coil-overshoot and the **coil-play** are taken into consideration during the regulation.


The successful coil calibration is shown on the screen as follows




The results of the calibration are to be read on the following pages which may be turned by <F1>.



1. *Staphylococcus aureus*





For the linearization the following procedure is recommended:


- Manual change of the P-coil to the lower final position
- Selection of 8 support points, please use here in the lower range of the P-coil more supporting plates because the non-linearity in this range usually is bigger.


Please do only select supporting plates which are marked on the P-coil on the mechanical indication. The approach to these supporting plates should always be from the bottom to the top so that mechanical plays will have no effects.

5. Change the P-coil to the next selected support point
 6. By arrow key $< \Rightarrow >$ select next line
 7. By $<F3>$ take over the ohm value of the P-coil
 8. Rectify the indicated value of the current in [A] to the locally set value of the P-coil
- Repeat the last 4 steps until all 8 values are set or I_{max} is reached.

8.2.3.4 Indication Options

For the adaptation of the screen-indication the following menu points are available:






Menu point	Factory-setting	Note
<i>indication Options</i>		
F2: indication Uen in	%	Display of the offset voltage on the screen. Selection possibilities: % ... Uen referred to the nominal value V ... Secondary side of the voltage transformer kV ... Primary side of the voltage transformer
F3: Parameter	Uen, Ir, lw	Display of the calculated parameters of the resonance wave Selection possibilities: Uen, Ires, lw k, v, d
F4: current display incl. Slavepos.	Yes	Selection, if, in Master-Slave operation, the present coil position of the Slave is to be added and shown as sum to the present position of the Master.


8.2.3.5 Fixcoil

Sum of the Fixcoils in the neutralization range.

For the calculation the fixcoil will only be used if these ones are activated by the binary input or by the serial control and instrumentation technology link. Another possibility of activation is offered by the background programme in connection with the Parallel-Regulation programmes.



8.2.4 Inputs & Outputs



8.2.4.1 Binary Inputs and Outputs

The binary Inputs and Outputs of the regulator may directly be configured by the menu of the regulator. In the following map the principle coupling of binary inputs and outputs to the regulator process is shown:





Abb. 8.14: block diagram binary Inputs and Outputs



8.2.4.2 Binary inputs

Equivalent circuit

In the following map the principle structure of the binary inputs is shown.




Abb. 8.15: Simplified input switching

From Abb. 8.15 it is possible to see that the inputs are suitable as well for AC as also for DC. The switching is made in a way that the contact threshold lies at approx. 30 VAC.

For some input functions, **impulses** which are placed at the input are evaluated. From these impulses only the **incrementing edge** is used in the regulator. The impulse must have a length of **at least 500 ms** in order to be safely recognized. Joint with background programmes the necessary time may possibly be longer.

Note:

With long open lines, interferences may deliver very high voltage values. Especially the lines to the E-Coil should be controlled referred to 50 Hz - interferences.


Possible measurements if too high interferences:


- parallel switching of condensators to the input: The additional capacity reduces the effects of the interferences through the better voltage divider ratio
- attenuation of the input with an additional resistance
- Placing of interrelays with a higher contact threshold

The binary inputs of the "Final switch Higher" and "Final switch Lower" are already switched by a condensator ($1\mu\text{F}$) from the factory.

Configuration of the inputs

Please see menu display of the inputs 1 to 4 as example for the configuration possibilities of the digital inputs directly by the menu of the regulator





Function key <F1> switches to the other inputs E5 to E16.

In the first paragraph, the electrical level is shown in the square bracket and the following maps are possible:

```
[ ]... 0 (Uon < Uthreshold)
[x]... 1 (Uon > Uthreshold)
```

In the second paragraph, the names of the physical inputs are displayed (E1 to E4)

Immediately after the colon, the activated inverting for each corresponding input function is indicated by a "Minus" (see input E4).


In the last paragraph, the assignment of the physical input to the logical input function of the regulation process is monitored. In the given example, the input E1 is linked to the input function "End_H" (Final switch Higher) of the regulation process. This means that the regulator will realize it by the digital input E1, if the "Final switch Higher" is used.

Should the assignment be in **square brackets**, so this assignment is set by the factory and cannot be configured by the user.

It is easy to learn from *map. 8.16: principle switching of the binary input* that several physical inputs may be laid to one input function. The single inputs are switched together in the regulator, considering the inverting by an "OR – link".


Selection of the Assignment

Please press the function key of the corresponding input to change the assignment chart resp. the inverting. The following map shows the corresponding selection menu for the input E3



The selected input function, e.g. in this case the No. 21 for the manual start of the resistance control is indicated in a frame. By the selection keys <F2> and <F4> selection may be made of the input function above resp. below whereas each one of the keys <F1> and <F5> turns one page. The key Return takes over the setting übernommen and changes back to the input selection menu

By striking key <F3> (INVers) there may be the inverting of the signal.




Background Programming:

For the very mighty background programming, the following functions are available:

- The recognized electrical level may be read by command EspBI
- The command EspBI enables the background programme in the writing access to overwrite the recognized electrical value for 60 s. Thus, there is the possibility to give an input signal to the regulator by the background programme.
- The measured input function may be read from the background programme by the command EspBIFV (**B**inary **I**ntput **F**unction **V**alue). Here also is the possibility to overwrite this value for 60 s by the background programme.
- As well the inverting as also the assignment chart may be read by the background programming. The released assignments may also be changed by the background programme.

There may be the assignment of the following input functions to the physical inputs:

Nr.	Name	Function
0	OFF	The input is not assigned to an input function. The signals are practically sent to nowhere.
1	PROG	The input is only assigned to the background programme. The Standard regulation process is not used by this input
2	Motor_H	control and instrumentation technology to regulator: The P-coil should be set in the direction of „Higher“
3	Motor_T	control and instrumentation technology to regulator: The P-coil should be set in the direction of „Lower“
4	Imp_Mot_H	control and instrumentation technology-Impuls to regulator: The P-coil should be set in the direction of „Higher“. The incrementing edge of the input signal is rated and be prolonged by a value which is settable by the menu.
5	Imp_Mot_T	control and instrumentation technology-Impulse to regulator: The P-coil is to be changed in the direction of „Lower“. The incrementing edge of the input signal is rated and be prolonged by a value which is settable by the menu.
6	Mot_Lauf	P-coil to regulator: The running message is transmitted for the statistics. Therefore also motor running times are measured which are not caused by the regulator, as for instance by a local changing of the P-coil.
7	End_H	P-coil to regulator: „ Final position Higher “ has been reached
8	End_T	P-coil to regulator: „ Final position Lower “ has been reached
9	E:Hand	P-coil to regulator: P-coil was set to HAND locally. The regulator may not make a changing of the P-coil
10	E>Error	P-coil to regulator: P-coil has recognized an error
11	Imp:L	Supervisory remote impulse to regulator: regulator is to switch to operation mode „ Local “
12	Imp:F	Supervisory remote impulse to regulator: regulator is to switch to operation mode „ Remote “
13	Imp:L/F	Supervisory remote impulse to regulator: regulator is to change to operation mode „ Local / Remote “
14	Stat:F	A statical signal induces the regulator to remote operation.
15	Imp:AUTO	Supervisory remote impulse to regulator: regulator is to switch to operation mode „ AUTO “
16	Imp:HAND	Supervisory remote impulse to regulator: regulator is to switch to operation mode „ HAND “ . Furthermore, this switching serves to acknowledge error conditions
17	Imp:A/H	Supervisory remote impulse to regulator: regulator is to switch to operation mode „ AUTO / HAND “.




18	S:Block	Statical signal to regulator: Blocking of the regulator. After having finished the blocking, a search run will be triggered off.
19	S:BlockT	Statical signal to regulator: Blocking of the regulator through overtemperature of the P-coil. After having finished the blocking, a search run will be triggered off
20	Search	The incrementing edge of the signal triggers off a search run.
21	R_start	The incrementing edge of the signal triggers off a start-up of the resistance for the residual ohmic current increment. (Details see chapter "8.1.5 R - Control")
22	R_auto_on	Supervisory remote impulse to regulator: activation of the resistance automation
23	R_auto_off	Supervisory remote impulse to regulator: deactivation of the resistance control
24	R_auto_onoff	Supervisory remote impulse to regulator: Switching between activation / deactivation of the resistance control
25	R_block	Blocking of the resistor connection by an external signal, e.g. by an external temperature control of the resistance
26	SE_system	reserved
27	SE_ein	reserved
28	Slave	Statical signal to regulator: regulator is switched to Slave-operation
29	coupling	Statical signal to regulator: The busbar has been linked by a bus-tie or by a bus coupling. The Parallel-Regulation is activated
30	Fixcoil	Statical signal to regulator: a fixcoil is connected. This has mainly effects on the calculation of the relative compensation
31	Acknowl.	Acknowledgement of the interference message
32	Erd_Korr1	Statical signal to the regulator: In the case of an earth fault, the P-coil is rectified by one set value.
33	Erd_Korr 2	
34	Erd_Korr 3	
35	Erd_Korr 4	
36	R_ready	Self-conduct of the resistance automation is being finished. The resistance automation is made "ready" for the next earth fault


8.2.4.3 Binary outputs

Configuration of the outputs

The menu map for the outputs 1 to 4 is an example for the configuring possibilities of the digital outputs directly by the menu of the regulator



Function key <F1> switches to the other relay outputs R5 bis R10.



In the first paragraph, the edited status of the relay (or more accurately: the status of the relay excitation winding) is shown in the square bracket and the following maps are possible:

[]... 0 Relay not started up)
[x]... 1 Relay started up

In the second paragraph, the names of the physical outputs are displayed (R1 bis R10)

Immediately after the colon, the activated inverting for each corresponding output function is indicated by a "Minus" (see output R4).


In the last paragraph, the assignment of the physical output to the logical output function of the regulation process is monitored. In the given example, the output R1 is linked to the output function "Motor_H" (Motor Higher) of the regulation process. This means that the regulator may regulate the P-coil in the direction of "higher current" by this output.

Should the assignment be **in square brackets**, so this assignment is set by the factory and cannot be configured by the user.


Please learn from *Abb. 8.14: block diagram binary Inputs and Outputs* that several physical outputs may be laid to one output function. This corresponds to a **contact multiplication**. The single outputs are switched together in the regulator, considering the inverting by an "OR – link".

Selection of the Assignment

Please press the function key of the corresponding output to change the assignment chart resp. the inverting. The following map shows the corresponding selection menu for the output R3



The selected output function, e.g. in this case the No. 14 for the message that the regulator is in the status tuned is indicated in a frame. By the selection keys <F2> and <F4> selection may be made of the input function above resp. below whereas each one of the keys <F1> and <F5> turns one page. The key Return takes over the setting übernommen and changes back to the relay selection menu




Background Programming:

For the background programming, the following functions are available:
The edited relay status may be read by the command EspBI


- The regulation process may set the output function EspRelFV (**Relay Function Value**). The background programme has only reading access to this output function EspRelFV
- The background programme has reading and writing access to the output function EspRelPV (**Relay Programm Value**)
- By the „Inverting“ the output functions may be slightly inverted in the assignment chart. However, please consider that this is only a logical inverting which is only applicable as long as the instrument is connected to the auxiliary voltage.
- As well the inverting as also the assignment chart may be read by the background programming. The released assignments may also be changed by the background programme.

There may be the assignment of the following output functions of the regulation process to the physical outputs

No.	Name	Function
0	OFF	Relay is not assigned. A „0“ or a „1“ is edited depending on the inverting.
1	PROG	The relay is assigned to the background programming
2	Motor_H	Command to the P-coil: change in the direction of „Higher“
3	Motor_T	Command to the P-coil: change in the direction of „Lower“
4	Status	Message of the regulator status
5	AUTO	Message: The regulator is in the Operation mode AUTO
6	Uen>Uerd	Message: The offset voltage is bigger than the set earth fault-treshold
7	Uen>Uerd_vz	Message delayed: The offset voltage is bigger than the set earth fault-treshold
8	Uen>Umax	Message: The offset voltage is bigger than the set maximum offset voltage
9	Uen<Umin	Message: The regulator has controlled the complete changing range and has not found an offset voltage bigger than the set minimum offset voltage. The message is only edited after the set delay time for Umin.
10	End_H	Message: The regulator has recognized the final position „Higher“
11	End_T	Message: The regulator has recognized the final position „Lower“
12	End_H/T	Message: The regulator has recognized the final position „Higher“ OR „Lower“. It is the OR –link of the two previous messages
13	Mot_Lauf	Message: The regulator has recognized a change of the P-coil. The signal is an OR link to the setting commands „Motor Higher“, „Motor Lower“ and to the input „Mot_Lauf“
14	Abgest	Message Tuned : The search procedure has been finished successfully. The required compensation value has been set successfully.
15	Abg_nK	Message Tuned not compensated : The regulator has set the coil to the best possible value, taking the frame conditions into consideration. The required compensation value, however, could not be reached because, for example, this value lies outside the changing range of the P-coil
16	Umax_K	reserved
17	Block	Message: The regulator is in the operation mode AUTO but blocked by an event



18	Rest pos.1	Message: The regulator has reached the rest position 1. This rest position is depending on the parameterization of the function, see also: - Umin - Abort of the search
19	Rest pos.2	reserved
20	Remote	Message: The regulator has been switched to remote. At the regulator, the keys for „Motor Higher“, „Motor Lower“, „HAND“ and „AUTO“ are blocked by the software. A physical separation of the signals from the P-coil will not be made. An operation of the menu and selection of the different indication modes is continuously possible
21	Fixcoil	Message: The fixcoil is considered for the calculation of the compensation
22	coupling	Message: parallel operation of P-coils
23	R_auto_on	Message: resistance automation is activated
24	R_block	Message: resistance automation is active but blocked
25	R_on	Command: Resistor to the residual ohmic current increment is started-up
26	R T>>	Message: Resistor is too hot
27	SE	reserved
28	SIM	Internal simulation is activated.
29	Alarm	Alarm-Message: The regulator has problems with the measuring of Uen: - SearchTime run out (45 min) - SearchNumber exceeded
30	Alarm vz	Alarm-Message delayed.
31	AlarmInt	Alarm - Message Internal
32	E:Direct	Error-Message: P-coil drives in the wrong direction
33	E:Move	Error-Message: No change of the P-coil was recognized within the set time on the commands „Motor Higher“ resp. „Motor Lower“
34	Interference	Interference message: Sum message for recognized interferences: - Motor error o No movement on changing command o Wrong direction - Potentiometer error o Linebreak - Both final switches are recognized at the same time - Positioning error - Interference message of the P-Coil
35	Interference vz	Interference message delayed: delayed sum interference message
36	Stör_Sum	Bus- Interference message SumInterf = Interference + Alarm + Status Alarm: - SearchTime run out (45 min) - SearchNumber exceeded Interference: - Motor error o No movement on changing command o Wrong direction - Potentiometer error o linebreak - Both final switches are recognized at the same time - Positions- error - Interference message of the P-Coil Status: - All internal errors as for example o RAM o ELAN



		<ul style="list-style-type: none"> ○ Battery ○ ...
37	>n_Search	Message: After n Search cycles no successful tuning of the P-coil could be made.
38	>T_MotOn	Message: The set Motor Running time was exceeded
39	Pot_???	Message: Error recognized at the measuring of the coil position, for example linebreak
40	Uen_??	Message: Error recognized at the measuring of the offset voltage, for example value > 120 % the set nominal voltage
41	E:HAND	Message: Pass-through of the Input message "E-Hand"
42	E:ERROR	Message: Pass-through of the Input message "E-Error"
43	ELAN L	Message: Error recognized at the E-LAN L
44	ELAN R	Message: Error recognized at the E-LAN R
45	ELAN Error	Message: Sum message for errors at the E-LAN
46	U12<<	Reference voltage is very low
47	R_ready	Resistance control is ready. As soon as the next earth fault occurs, there will be an increment of the residual ohmic current
48	SuchVerz	Set if the regulator is in search delay, e.g. the offset voltage is outside the tolerance range and the regulator has not yet begun with the search. Is also set during the delay of the forcing search.
49	ParaProg	Will be set, if the Parallel-regulation is released and also is activated, for example by the coupling switch.
50	Local	The regulator is switched to Local
51	Remote	The regulator is switched to Remote
52	Uerd Pos	The P-Coil is being positioned during the earth fault
53	Search	Set during the searching procedure: Start until (Tuned v Abg. nK v Abgest. Umin) The message is set back to: Uerd, Blocking, Hand, Umax

8.2.4.4 LED - Outputs







Abb. 8.17: block diagram LED Funktionen

The assignment of the LEDs to the output functions is made completely analog to the assignment of the relays. There are even the same output functions available.

In the following map the assignment for the first four LEDs is shown



8.2.4.5 Analog Inputs/Outputs



There may be the installation of up to six **free programmable Analog - Outputs** for the range of -20mA ... 0 ... +20 mA in the regulator.



In the following map, the functional block map for the parameterization of the analog outputs is shown.




Abb. 8.18: block diagram of the analog outputs


By the assignment chart, the following quantities measured in the regulating process may be edited to the physical outputs:

Nr.	Name	Function
0	OFF	The analog output is not used
1	Prog	The analog output is assigned to the background programme
2	Uen	The offset voltage Uen is edited
3	I1	The measured value of the current transformer 1 is edited
4	I2	The measured value of the current transformer 1 is edited
5	Rproz	The measured value of the coil position is edited (voltage divider ratio of the position measuring, without linearization)
6	lpos	The linerarized coil position of the changing range is edited in per cent. (I _{max} corresponds to 100%, 0A corresponds to 0%)
7	RTemp	The temperature of the resistance, measured by the thermal replica, is edited.

For each channel, the kind of the transmission characteristic may be defined by three points so that as well a linear characteristic as also a bend characteristic may be produced.

Please consider that, in case of using REG-L language, the counting for the channels and for the support points begins with 0 and not with 1.

When the coil position is edited, the coil position measured by the linearization chart is used. Thus, there is the same coil position in the control room as at the coil itself.

**Example for a linear characteristic:**

The range of the offset voltage U_{en} from 0 to 100 V is to be shown on the range from 4 to 20 mA and be edited by channel 1:





Abb. 8.19: Linear transmission characteristic

Parameterization by menu:

Menu-point	Value	Function
Type	Output	A mA – Output module is used.
Nominal value	20 mA	Maximum value which the module may deliver physically. The standard modules deliver 20 mA
Input function	Une	(At present no difference between Input and Output, input see next point)
Output function	Une	Assignment of the required "analog measuring value" for the edit (see chart above)
Filter time	0	reserved
point 1x	0 V	0 V corresponding to the smallest value of U_{en} of 0V on the x-axis
point 1y	20 %	4mA on the y-axis correspond to 20% of 20mA
point 2x	100 V	100 V corresponding to the maximum value of U_{en} on the x-axis
point 2y	100 %	20 mA on the y-axis correspond to 100 %
point 3x	0	
point 4x	0	

When parameterization is made by REG-L, the following commands are necessary:

command	Function
ESPAIOType 0 2	channel 1 (0) as Output (2)
ESPAOFu 0 = 2	From the function chart, the voltage U_{en} (2) is assigned to channel 1 (0)
ESPAScalX 0 0 = 0	The minimum value of the voltage (0V) has to be given (channel 0, support point 0 = 0 V)
ESPAScalY 0 0 = 0.2	The normed value referred to 20 mA must be inserted: 4mA/20mA = 0.2 (channel 0, support point 0 = 0.2)
ESPAScalX 0 1 = 100	The maximum value of the voltage (100V has to be given (channel 0, support point 1 = 100 V)
ESPAScalY 0 1 = 1	The normed value referred to 20 mA must be inserted: 20mA/20mA = 1 (channel 0, support point 1 = 1)


Example for a bend-characteristic (zoom-in):

The display is to larger indicate the range of the voltage of 0 to 10V. Therefore the range of 0 to 10 V is shown on the range of 0 to 8 mA. The range of 10 V to 100 V is monitored on the remaining range of 8 to 10 mA . The edit is to be made by channel 2.




Abb. 8.20: Bend-characteristic (zomm-in)


Parameterization by menu:

Menu-point	Value	Function
Typ	Output	A mA – Output module is used.
Nominal value	20 mA	Maximum value which the module may deliver physically. The standard modules deliver 20 mA
Input function	Une	(at present no difference between Input and Output, insertion see next point)
Output function	Une	Assignment of the required "analog measuring value" for the edit (see chart above)
Filter time	0	Reserved
point 1x	0 V	0 V corresponding to the smallest value of Uen of 0V on the x-axis
point 1y	0 %	0 mA on the y-axis correspond to 0% of 20mA
point 2x	10 V	10 V corresponding to the bend point on the x-axis
point 2y	40 %	8 mA on the y-axis correspond to 40 % of 20 mA
point 3x	100 V	100 V correspond to the maximum value of Uen on the x-axis
point 3y	50 %	10 mA on the y-axis correspond to 50 % of 20mA

When parameterization is made by REG-L, the following commands are necessary:

Command	Function
ESPAIOType 0 2	channel 1 as output
ESPAOFu 0 = 2	From the function chart, the voltage U_{en} is assigned to channel 1
ESPAScalX 0 0 = 0	The minimum value of the voltage (0V) has to be given (channel 0, support point 0 = 0 V)
ESPAScalY 0 0 = 0.2	The normed value referred to 20 mA must be inserted: $4\text{mA}/20\text{mA} = 0.2$ (channel 0, support point 0 = 0.2)
ESPAScalX 0 1 = 10	The medium support point of the Voltage (10V) has to be given (channel 0, support point 1 = 10 V)
ESPAScalY 0 1 = 0.4	The normed value referred to 20 mA must be inserted: $8\text{mA}/20\text{mA} = 0.4$ (channel 0, support point 1 = 0.4)
ESPAScalX 0 2 = 100	The maximum value of the voltage (100V) has to be given (channel 0, support point 2 = 100V)
ESPAScalY 0 2 = 0.5	The normed value referred to 20 mA must be inserted: $10\text{mA}/20\text{mA} = 0.5$ (channel 0, support point 2 = 0.5)

8.2.4.6 Delays




Minimum hold time of the relay

The minimum hold time of the relay may be set here. Therefore it may be made sure that even short signals are recognized and transmitted by the supervisory remote control.

standard setting: 0 s

Impulse prolongation Motor Higher / Lower

The incrementing edge of the input signal to the regulator which is necessary to change the P-coil is prolonged here by the set value. Therefore, it is not necessary to remotely control the position and to react very fast.



For a P-coil with a running time of 200s and a changing range from 20 to 220 A, an impulse time of 2s seconds would correspond to a positioning possibility of 1%.

standard setting: 4 s

Message delay Alarm

The edit of the messages Alarm are delayed by the set time.

Standard setting: 0 s

Message delay Interference

The edit of messages interferences are delayed by the set time.


Standard setting: 0 s

8.2.5 Fault acknowledgement

Apart from the acknowledgement by a **binary Input (input function 31)**, the following versions made be selected:


Method	Description
Menu	The error may be acknowledged locally only by the menu "Interferences- help" and by the key <F5>.
Menu / Hand	The interference may additionally be acknowledged by the key HAND without having to get to the menu. Disadvantage: the detailed help text to the interference analysis is not indicated.
Menu / Hand / Auto	The interference may now also be acknowledged by the key AUTO.

The last two versions are of course identically applicable also for the binary Inputs to the change-over HAND / AUTOMATION.



8.2.6 Current measuring

There are two current channels available in the regulator to measure Amount and Angle.



Selection possibilities:

1 A
5 A

Note:

Consider Jumper on the Hardware!

$$kni = \frac{I_{Prim}[A]}{I_{sek}[A]} \quad (8.6)$$

knI corresponds to the conversion rate to the primary current and depends on the set Input current (1A or 5A)

In the following map, the corresponding positions of the jumpers are shown on circuit board 3:





Abb. 8.21: jumpers for the selection of the nominal range of the current input





8.3 Options

Menu point Options offers the possibility to parameterize additional functions.

F4: Options

F2: Local / Remote
F3: Loc / Rem Release
F4: Loc / Rem Function

F2: Simulation
F3: system model




8.3.1 Local / Remote

The regulator may be switched between local and remote operation by the key Local / Remote.

Operation Local:

All **orange marked keys** may be operated locally. The control and instrumentation technology has no access but a reading access by the serial coupling.



The operation of the menu is without restrictions


Operation Remote:

All **orange marked keys** except for the switching Local / Remote are locked. Therefore an erroneous change between the operation modes AUTO / HAND is impossible. A switching AUTO / HAND may only effect remotely. This also applies for the keys to change the coil position: "Motor Higher" and "Motor Lower"


The operation of the menu is without restrictions

For devices without key Remote /Local the switching effects in the above menu.

The switching status is additionally shown at the right side above the status display.



Parameter	Setting values	Description
Local / Remote	Local Remote	Local: All commands remotely by the binary inputs are locked Remote: The keys <AUTO>, <HAND>, <Higher> and <Lower> are locked.
Loc / Rem Release	locked permitted	Access permission only for the switching Local / Remote remotely, even when the regulator is on Local.
Loc / Rem Function	Off On	If the Local / Remote Function is turned off the local operation and the remote operation have the same permissions. In the Off- status, both LEDs at the front side are turned off.



8.3.2 Simulation

8.3.2.1 Principle of the system simulation in the REG-DP

In order to test the essential parts of the regulation procedure, a system simulation with a changeable P-coil and different system switching status has been implemented into the REG-DP. If this simulation is activated, the following input signals are superseded by the data simulated in the regulator:

- offset voltage U_{en} as function of the coil position
- coil position I_{pos}
- Final switch Higher
- Final switch Lower

The simulation is a process which is completely separated from the regulation and it does not influence the system during regulator operation.

8.3.2.2 Activation of the Simulation

For the simulation of the regulation behaviour, a simulation mode may be started in the regulator. For the simulation of the system with a P-coil, the following simplified diagram is applied to:





Abb. 8.1: Simplified system for the simulation

The conductivity components for this simplified system may also be calculated, for the defined voltage $E1$, on currents. Thus, the result is a considerably more detailed description of the system by the following parameters:


Parameter	Description
I_{res}	The coil position in which the zero system of the system is tuned to resonance. In this case, the offset voltage is biggest in the sound system. The current through the P-coil corresponds to the capacitive current of the system in this case.
I_u	The unsymmetry current I_u corresponds to the current over earth when solid earthing.
I_w	The active current I_w flows parallel to the resonance circle. This current would flow over the error position, if there was a dead earth fault.
Φ	Phase shift of the replacement voltage source in the range of $-180^\circ \dots +180^\circ$ referred to the real axis.

The offset voltage U_{en} in the point of resonance is calculated as follows:

$$U_{res} = 100\% \frac{I_u}{I_w + I_u} \quad (8.1)$$




By means of the following menu, there may be, on the one hand, the simulation **activated** and on the other hand, selection may be made between three already given systems.





The activation of the simulation may be recognized by the fact that on all screens the double line is interrupted and the active simulation status is characterized by the following procedure:

```
SIMLE
|
| Earth fault
| system 1
SIMulation
```

As above mentioned, the parameters of the three systems in the regulator may be changed by the menu. In the following map, the menu for the system 1 is shown as example.



In the last map from the series "system models" there may be data given for the simulated P-coil:




Parameter	Factory setting	Description
Coil running time	60s	Changing time of the P-coils from the lower final position "Final switch Lower" up to the upper final position "Final switch Higher".
Final switch Higher	95%	The "Final switch Higher" is recognized from a potentiometer position of > 95%.
Final switch Lower	5%	The "Final switch Lower" is recognized from a potentiometer position of < 5%.

8.3.2.3 Key assignment during the simulation

As soon as the simulation is activated, the function keys F3 to F5 are used to switch between the single systems. In addition to that, an earth fault may be simulated by function key F2. The earth fault is valid for the correspondingly selected system. The assignment of the keys is as follows:

- F2 Earth fault on / off
- F3 system model F3
- F4 system model F4
- F5 system model F5

The functions which are normally on these keys, which are essentially the changing between the different indication modes, are deactivated during the simulation.






8.4 System

F5: System


- F2: language
- F3: COM & E-LAN
- F4: Station identification
- F5: Station name

- F2: LCD saver
- F3: date & Clock-time
- F4: Password
- F5: Status






8.4.1 Language



8.4.2 COM & ELAN

8.4.2.1 COM1 and COM2




Key <F1> permits the changing between the two free configurable serial interfaces COM1 and COM2. In the left-hand part of the screen, the presently active interface is displayed.

Mode ECL <F2>

Selection possibilities:

MODE ECL	Standard telegramme of the regulator REG-DP
MODE DCF77	Telegramme for the time synchronization is being processed with. A DCF 77 receiver may serially be linked to the interface.



Baudrate <F3>

Selection possibilities:

1200
2400
4800
9600
19200
38400
57600
76800
115200

Parity <F4>

Selection possibilities:

even
none

Handshake <F5>

Selection possibilities:

RTS / CTS
Xon / Xoff
none

8.4.2.2 E-LAN




Abb. 8.1: Link with E-LAN: 2-wire BUS

2-Draht BUS






Abb. 8.2: Possible link with ELAN



Each regulator offers two complete E-LAN-Interfaces.

E-LAN LEFT defines the settings for Bus – left-hand
(Terminal block 6, terminals b6, b8, b10 and b12 see page 22).

E-LAN RIGHT defines the settings for Bus – right-hand
(Terminal block 6, terminals z6, z8, z10 and z12 see page 22).

Each one of these interfaces may work as well with a 2-wire-phase as also with the 4-wire-transmission technics (RS485).

Terminal block 6				
BUS-L Terminal	BUS-R Terminal	Function	2-wire	4-wire
b6	z6	EA+	"Input +" and "Output +"	"Output +"
b8	z8	EA -	"Input -" and "Output -"	"Output -"
b10	z10	E+	No function	"Input +"
b12	z12	E -	No function	"Input -"

The usual operation is with a 2-wire-phase because only this permits a bus configuration with several participants on the same bus line. To do this, please switch on the integrated final resistors at the **first** and at the **last** participant on the bus line (Selection: **"in finish"**).


Due to appearing reflections at the corresponding phase end, it is impossible to get a proper functioning of the bus without final resistor.

For long transmission distances >1000m or in the case of a booster (amplifier to increase the signal level for very long transmission distances), there must be an operation with 4-wire- transmission technics. The necessary final resistors are automatically activated (Selection **"in finish"** is no longer needed).

Baudrate <F1>

Selection possibilities:

62k5
125k



Note:

The transmission speed for the ELAN-L and the ELAN-R may be selected differently.

MODE <F2> and <F4>

Selection possibilities:

2-wire
4-wire

Note:

The operation mode for the ELAN-L and the ELAN-R may be selected differently.

Termination <F3> and <F5>


Selection possibilities:

Finish to be ended
Finish open

Note:


The operation mode for the ELAN-L and the ELAN-R may be selected differently.

8.4.3 Station identification




Note:

Devices operated at the bus (E-LAN) have to be marked with different addresses (A ... Z4) so that they may be addressed clearly.



8.4.4 Station name



The name of the regulator may be changed.
Maximum length of the name: 8 signs

8.4.5 LCD saver

The background illumination is switched off after approx. 15 min if no key has been pressed down. To save the LCD display the text and graphics are also deleted after approx. 1h. To turn it on again, please strike any key.

Caution:


The first pressing down of a key is rated even with dark screen. To switch to a light screen only, please use key <ESC>.


Selection possibilities:

ON
OFF

Switching off of the text and the graphics after approx. one hour
Text and graphics are not switched off

8.4.6 Date & Clock-time






8.4.7 Password

REG-DP a-eberle

Status	A:REG-DP 17:04:36		
<input checked="" type="checkbox"/>	Passwort	Benutzer 1	F1
<input type="checkbox"/>	Benutzer auswählen	Benutzer 2	F2
<input type="checkbox"/>		Benutzer 3	F3
<input type="checkbox"/>		Benutzer 4	F4
<input type="checkbox"/>		Benutzer 5	F5


☐ AUTO ☐ local remote ☐ ESC ☐ MENU

☐ HAND ☐ ☐ ☐ ☐




8.4.8 Status

In the mode Status some information is shown in a very comprimized form. This menu is applied for a fast rating of the system and for the putting into operation for some tests.




The Status-Map 1/4 shows the following values:

- Software Version with date
- Hardware Version of the measuring card
 - ERLP ... without angle measuring
 - NTZ2 ... with angle measuring and measuring range up to 120 VAC for Usync
 - NTZ2 / 230 V ... with angle measuring and measuring range up to 230 VAC for Usync
- quantity of the installed memory
- Status of the battery
- Present level to the physical input as HEX-number
- Present edit to the relay as HEX-number
- present indication of the LEDs as HEX-number




The Status Map 2/4 shows the following internal registers

- Status of the Local / Remote switching status
- Status of the regulation status: Blocking
- Status of the resistance control: R-Blocking
- Input function: coupling
- Activation status of the fixcoil




The Status Map 3/4 shows the following analog measuring values and all measuring values are referred to the regulator inputs. The values for knl resp. knU are not considered.

- Uen offset voltage (0...100V) (Amount and Angle)
- U12 The reference voltage is fixed to 100V
- I1 Current through the first current transformer (Ip), Amount and Angle
- I2 Current through the second current transformer (I2), Amount and Angle
- Ipos coil position in [A], after the linearization
- Ipos% coil position in [%] referred to Imax
- R temperature of the thermal equivalent (resistance automation)
- Poti voltage divider measured
- Poti% voltage divider measured, referred to 5V




The Status map 4/4 lists the activated features.




Moreover, there may be the trigger-off of a Master-Reset in this Status-menu:

Master -Reset:



In the case of a Master-Reset, all parameters are set back to the factory setting.
The Master-Reset may be triggered off by pressing key <F2> in one of the Status maps.




9 Update of the operation software

For an update of the operation software, a zero-modem cable is required. Due to the high baudrate a hardware-handshake is required. This is why the RTS / CTS - lines must be linked crosswise.

Zero-modem cable:


9 pol Sub-D Buchse

9 pol Sub-D Buchse




9.1 Operation system Windows 95/98, NT and Win2000

The following files are present on the installation disk resp. in the installation index:




File	Description
Update32	Windows programme for the transfer of the firmware into the regulator
DP._MO	Firmware of the regulator (comprimized)
HELDPDP._MO	Help file of the regulator contains the description of the REG-L commands (comprimized)




The following steps are to be made at the PC resp. Laptop:


- Start of the programme Update32




- Selection of the interface used **at the PC**.
After having confirmed by key OK, the interface of the PC is initialized to 115kBaud and RTS/CTS - Handshake. The Interface must not be blocked by another programme. (for example communication software for mobile phones ...)
- Selection: Update\ new firmware




- The Windows-Software demands the corresponding setting at the REG-DP:







- The regulator REG-DP must show the following map



- After having confirmed the setting at the PC, the download is made using the file dp._mo from the present index.



- The successful transfer is messaged by




and the regulator boots with the new software.

In the case of another message there is an interference and the download will have to be repeated.

Note:

For further questions please refer to the following address by e-mail: info@a-eberle.de or by phone to the hotline: 0911-628108-86 resp. -78



- The above procedure is to be repeated for the help-Texts.
- Please consider that the background programmes may possibly have to be loaded newly also.

9.2 Menu Functions of the Update32-Programme

9.2.1 Update

Here all functions are listed which refer to the download of new software. Please choose between the following possibilities:

Update all:

The complete firmware is brought up-to-date, e.g. the primeload and the help texts, which are stored in the meter.

new primeload:

The boot programme of the meter is brought up-to-date

new firmware:

The firmware of the meter is brought up-to-date

new help texts:

The help texts of the meter are brought up-to-date

REG-L download:

A REG-L background- or foreground programme may be transmitted from the PC to the regulator.

REG-L upload:

The REG-L background- or foreground programme may be transmitted from the regulator to the PC.

Communication Card Update:

Optionally, the REGSys meters are equipped with an additional card in order to permit the communication with control and instrumentation technological equipments.

With this menu point there may be made an update of the additional card.

End:

Finishes the programme.


9.2.2 Configure

ComPort:

Here please select the used interface (COM1 to COM4). The interface has to be physically present and must not be used by another device.

Baudrate:


In this dialog, the baudrate may be set and the standard value is 115200 Baud.



Under Windows 3.xx, however, high baudrates (> 57600 Baud) are not supported. The download programme uses a standard value of 57600 Baud in this case. Then, the selection point <115200 Baud> appears in grey and may not be selected.
After the change of the baudrate, the regulator has to be set accordingly by key <F4> .

Language:

Here, the language of the Download programme is selected. At present, the languages English, German and Spanish are available.



10 Maintenance and Current consumption

10.1 Change of fuse


Caution!

Before changing the fuse, the E-coil regulator REG -DE must be separated from the voltage supply!

Required fuse:

Fine-wire fuse T (Träge) 250 V, 2 A

Please find the fuse-holder on the lower side of circuit board 3 (LP-REG-NTZ2)



Map 10.1: change of fuse on circuit board 3

10.2 Change of batteries

Caution!

Before changing the fuse, do not forget to separate the E-coil regulator REG -DE from the voltage supply!

Required battery:


Lithium 3 V with soldering tags type VARTA AA-6127

Battery life:

In storage > 6 years


In operation if on-switching duration > 50%, the battery life is > 10 years

We recommend to let the battery change be made in the factory




10.3 Current consumption of the REG-DP

Meßschaltung (100 V DC)




Meßergebnisse

Einschalt-Spike bei 100 V DC




The measuring results should deliver hints to the selection of the fuses.



11 WinREG-DP

11.1 Installation

The installation programme is started automatically with the putting in of the CD. Alternatively, the Setup.exe in the Root-index of the CD may be started.



For the following installation, we suggest as a standard index path C:\Programme\WinREG3. If another path is to be used, please change it accordingly during the installation.

After the installation, a central control program is at your disposal





For the communication with the regulator, please select the used serial interface at the PC under menu "Option" and set the parameters at the regulator accordingly.


The regulator itself is set to 9600 baud from the factory. It is recommended to set the serial interface COM1 at the regulator in the menu: SETUP\ System\COM & E-LAN\COM1 to

Mode: ECL
BAUD: 115000
Parity: Off
Handshake: RTS/CTS


At the PC there will be the corresponding preparation, as for example the COM2 in the menu: Options\Verbindung




By submenu: Features




In order to operate several panels and thus several regulators **at the same time** by one serial interface, a special interface for the serial interface has been developed. After having finished the programme, this program remains active in the background and blocks the other programmes to get free access to the serial interface. This operation programme titled "HR-Server" may either be ended by the task-manager directly or resp. the waiting time to the automatical ending of the server may be set in menu: Options/settings. The factory setting is 60s, e.g. 60s after all communication programmes via the serial interface are finished, the serial interface will be released again for other programmes.





After the configuration of the serial interface the following programmes are available:

11.2 Panel



In this operation mode, the control surface of the regulator is simulated. There are the same functions available as may be made locally by the keyboard of the regulator.

Thus there is the possibility to operate and to parameterize the regulator remotely by a modem link.

If several regulators are linked by the E-LAN bus, several panels may be opened and operated with by one serial interface.

11.3 Terminal

By means of the terminal programme, the programming of the regulator may effect by the REG-L commands:


```

Terminal-Edit [locked]
Datei Bearbeiten Optionen Hilfe
Stationsparam.: STATION GRUPPE STATUS SPRACHE DATUMFORMAT
Mathematik:    SORT SIN COS ASIN ACOS DEG RAD EXP LOG LOG10 **
               ABS FRAC FIX INT INTR MAX MIN MOD
Stack-Op's:    + - * / & | ^ ~ && || ^ ^ ~ SHR SHL < > >
               DUP DROP SWAP PICK PRINT !
Verzweigungen: IF IFF ELSE ENDIF
Schleifen:     ALL NEXTA FORI I NEXTI DO DOWHILE EXIT RETURN
Programme:     P PLIST H HLIST HBREAK HTD ERR ERRNR LERR MEN
Variablen:     A ALIST H BLIST
ECS-LAN:       BUS DIR DIRN DIRS INDIR KENN SETKENN SYSTEST
Zeitbefehle:   ZEIT DATUM TM TMD HTD VON BIS DAUER SOWI
sonstige:      AUFZ FINDER DELIMITER DISPLAY MELD TASTE VER ERRS
               PASSWORT LOGIN LOGOUT WHOAMI TX1 TX2 DCI

Allgemein: INFO SYNTAX EXTENSION PARAMETER STRINGS STACK KEI
Spezielle Hilfe mit: HILFE <befehlsname> oder ? <befehlsname>

Beispiele für die Hilfe:
? Esp*         Liste aller REG-DP spezifischen Befehle.
? EspI*        Liste aller Gruppen in denen ein Befehl mit EspI be
? EspVo        Liste der Gruppe in der EspVo vorkommt.
? Buch         Erzeugt eine Beschreibung aller Befehle.

<A>
1
Direktbetrieb an COM 2
  
```

Moreover the following menus resp. functions are available

File

- Link
- Writing in File
- End

Edit

- Cut-out
- Copy
- Insert
- Go to end

Options

- Colours
 - Background
 - Foreground
- Fonts
- Translate (Converting the vowels for the indication under Windows)
- Lock-Mode
- Settings

11.4 Load

Load the Desktop File


11.5 Save

Save the Desktop File

11.6 RegPara

The RegPara is the central function around the regulator parameters with the following tasks:

- read parameters out of the regulator
- read parameters without coil data out of the regulator (present coil data in the memory are not overwritten)
- save parameters in a file
- read parameters from a file
- transmit parameters completely into the regulator
- transmit parameters without coil data into the regulator
- compare parameters in the memory of the PC to the parameters in the regulator and produce a difference list.
- compare parameters in the memory of the PC to the parameters in the file and produce a difference list.



The following menu structure is available:

File


- Read in meter
- Send to meter
- Load file
- Save as
- Print
- End

Edit

- Compare
- Additional data
- Online-actions
- Change type of meter
- Convert
- Settings

11.6.1 Cards

The following maps are an overview of the single "Cards" of the REG-DP.



WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe

Regelung 1 | **Regelung 2** | E/A-Funktionen | Konfiguration | System | P-Spule | Netzmodell | Analogausgänge

Umax
 Umax-Schwelle %

Umin
 Umin-Schwelle %

Endposition ...

Meldung Uen<Umin min

Neue Suche nach min

dUen-Begrenzung von Umin %

Selbsthaltung ☐

Widerstandssteuerung
 aktiv ☐

Einschaltverzögerung s

R-Einschaltzeit s

Selbsthaltung ...

Einschaltzeit maximal s

R-Temperatur maximal °C

R-Abkühlzeit min

Wiederholungsverzögerung s

Wiederholungszyklen

Parallelregelung
 Parallelprogramm ...

Parallelprogramm aktiv ...

Slave Pos. bei UMin ...

Slavekennung

Slave nachziehen ☐

Strom anzeigen inkl. Slave-Position ☒

WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe

Regelung 1 | Regelung 2 | **E/A-Funktionen** | Konfiguration | System | P-Spule | Netzmodell | Analogausgänge

Eingänge

E-01:	07: [End_H]
E-02:	08: [End_T]
E-03:	00: AUS
E-04:	00: AUS
E-05:	15: Imp: AUTO
E-06:	16: Imp: H&M
E-07:	02: Motor_H
E-08:	03: Motor_T
E-09:	00: AUS
E-10:	00: AUS
E-11:	00: AUS
E-12:	00: AUS
E-13:	00: AUS
E-14:	00: AUS
E-15:	00: AUS
E-16:	00: AUS

Relais

R-01:	02: [Motor_H]
R-02:	03: [Motor_T]
R-03:	00: AUS
R-04:	00: AUS
R-05:	00: AUS
R-06:	05: AUTO
R-07:	09: Uen<Umin
R-08:	06: Uen>Uerd
R-09:	36: Stör_Sum
R-10:	14: Abgest
R-11:	04: [Status]

LEDs

L-01:	04: [Status]
L-02:	36: [Stör_Sum]
L-03:	12: [End_H/T]
L-04:	13: [Mot_Lauf]
L-05:	06: [Uen>Uerd]
L-06:	00: AUS
L-07:	00: AUS
L-08:	00: AUS


Fehlerquittung ...

Mindesthaltezeit Relais s

Impulsverläng. Mot-H/T s

Meldungsverz. Alarm s

Meldungsverz. Störung s



WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe

Regelung 1 | Regelung 2 | E/A-Funktionen | **Konfiguration** | System | P-Spule | Netzmodell | Analogausgänge

Spannungswandler

Nennspannung V
knU

Für Reg-DE I Hardware

50 Hz Filter ☒
Meßbereich U_{en}

Stromwandler

Stromnennwert I1 ☒ 1 A
☐ 5 A
knI1

Stromnennwert I2 ☒ 1 A
☐ 5 A
knI2

WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe

Regelung 1 | Regelung 2 | E/A-Funktionen | Konfiguration | **System** | P-Spule | Netzmodell | Analogausgänge

Serielle Schnittstellen

	COM 1	COM 2
Mode	<input type="text" value="ECL"/>	<input type="text" value="ECL"/>
Baudrate	<input type="text" value="115200"/>	<input type="text" value="115200"/>
Parität	<input type="text" value="P-"/>	<input type="text" value="P-"/>
Handshake	<input type="text" value="RTS"/>	<input type="text" value="XON"/>

Local / Remote

aktiv

Einstellung

Freigabe durch Leittechnik

E-LAN

	links	rechts
Draht	<input type="text" value="2w"/>	<input type="text" value="2w"/>
Baudrate	<input type="text" value="62K5"/>	<input type="text" value="62K5"/>
Terminiert	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Geräteparameter


Hardwareversion

Sprache

LCD-Schoner ☐

Datum

Zeit



WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe

Regelung 1 | Regelung 2 | E/A-Funktionen | Konfiguration | System | **P-Spule** | Netzmodell | Analogausgänge

Petersen-Spule

I_{min} 20,0 A
 I_{max} 200,0 A
 Fixspule 0 A
 Type der Endschalter 00: Schließer

Linearisierungstabelle

Poti [%]	Stellung [A]
01:	0,0 0,0
02:	0,0 0,0
03:	0,0 0,0
04:	0,0 0,0
05:	0,0 0,0
06:	0,0 0,0
07:	0,0 0,0
08:	0,0 0,0

Kalibrierungsergebnisse

Endschalter Tiefer 0,0 %
 Endschalter Höher 0,0 %
 Spulenlaufzeit 0,0 s
 Spulennachlauf 0,0 A
 Spulenspiel 0,0 A
 Linearitätsfehler 0,0 %
 Spulenspiel-Schwelle 100,0 %

Software Endschalter

aktiv ☐
 I_{Min} 0,0
 I_{Max} 9999,0

Für Reg-DE I Hardware

Spulenposition Anschluß 00: 3-Leiter
 Spulenposition R-Wert 02: 1 kOhm

WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe


Regelung 1 | Regelung 2 | E/A-Funktionen | Konfiguration | System | P-Spule | **Netzmodell** | Analogausgänge

Simulation 00: AUS

Netzmodell

	1	2	3	
I_{res}	100,0	130,0	200,0	A
I_u	0,10	0,10	0,10	A
I_w	10,0	10,0	20,0	A
φ	0,0	0,0	0,0	°

Spulenlaufzeit 60 s
 Endschalter Höher 95,0 %
 Endschalter Tiefer 5,0 %



WinREG Parametrierung A:REG-DP

Datei Bearbeiten Hilfe

Regelung 1 | Regelung 2 | E/A-Funktionen | Konfiguration | System | P-Spule | Netzmodell | Analogausgänge

Kanal wählen

☒ Kanal 1 Typ: 02-Ausgang

☐ Kanal 2 Nominalwert: 01.20 mA

☐ Kanal 3 Ausgangsfunktion: 02-Une

☐ Kanal 4


☐ Kanal 5

☐ Kanal 6

Wert ([A], [V], [°])	% von Nominalwert
P1 0	0 %
P2 100	100 %
P3 0	0 %

The setting parameters may be printed out assortedly. The following options are available as selection criteria:

- sequence corresponding to the menu of the regulator
- sequence corresponding to the cards



11.6.2 Parameter print-out sorted according to menu of the regulator

REG-DP

Kommentar: UW-Standard

Quelle: Standard REG-DP.prm; Firmware: 2.0.18

Speicherdatum: 18. Nov. 01; Speicherzeit: 22:21:14

Ausdruck vom 18. Nov. 01, 10:40

Regelung - Standardparameter


Toleranzbereich	00:relativ
Uen Toleranz [%]	20
Uen Toleranz [A]	0,10
Verzögerung der Suche [s]	10
Verzögerung der Zwangssuche [s]	10
Sollverstimmung	00:% von Ire
Sollverstimmung [%]	10
Sollverstimmung [A]	10
Sollverstimmung [V]	7,0
Positionierungstoleranz [%]	1,0
Mindestverstell. dIpos [A]	5,0
Resonanzmax überfahren	01:JA
Nachziehen Uref [min]	5
Uen Winkelmessung	01:Ein
Suchzyklen max.	10
Motorlaufzeit max [min]	45
Endposition bei Abbruch	00:Ruhe_Su
Ruhepos. Suche [A]	50

Regelung - Erdschluss

Uerd-Schwelle [%]	30,0
Erdschlusswischer < [s]	7,0
Uerd-Meldeverz. [s]	7,0
Selbsthaltung	00:Aus
Korrektur Ipos	00:Aus
dIc_1 [A]	5,0
dIc_2 [A]	10,0
dIc_3 [A]	20,0
dIc_4 [A]	40,0

Regelung - U


Umax-Schwelle [%]	30,0
Umin-Schwelle [%]	0,2
Endposition	01:AbstimmP.
Meldung Uen<Umin nach [min]	15
Neue Suche nach [min]	60
dUen-Begrenzung von Umin [%]	33
Widerstandssteuerung aktiv	00:AUS
Einschaltverzögerung [s]	1,0
R-Einschaltzeit [s]	1,0
Widerstandssteuerung, Selbsthaltung	00:Aus
Einschaltzeit maximal [s]	10,0
R-Temperatur maximal [o]	200
R-Abkühlzeit [min]	60
Wiederholungsverzögerung [s]	1,0
Wiederholungszyklen	0
Parallelprogramm	00:Aus
Parallelprogramm: aktiv	00:Aus
Slavekennung	---
Slave nachziehen	00:Nein
Parallelprogramm: Slave Pos. bei Umin	00:Stop

**Inbetriebnahme**

knU	115,0
Nennspannung [V]	100,0
Messbereich Uen	01:20 V
50 Hz Filter	01:EIN
Imin [A]	20,0
Imax [A]	200,0
Spulenposition Anschluss	00:3-Leiter
Spulenposition R-Wert	02:1 kOhm
Software-Endschalter: aktiv	00:Aus
Type der Endschalter	00:Schließer
Software-Endschalter: I Min [A]	0,0
Software-Endschalter: I Max [A]	9999,0

Seite 2:

Schaltabstand zur gemessenen Endschalterpos. [%]	1,0
Fixspule [A]	0
Uen in	00:%
Netzparameter	01:Uen_Ir_Iw
Strom anzeigen inkl. Slave-Position	01:Ja
Eingänge E 1	07:[End_H]
Eingänge E 2	08:[End_T]
Eingänge E 3	00:AUS
Eingänge E 4	00:AUS
Eingänge E 5	15:Imp:AUTO
Eingänge E 6	16:Imp:HAND
Eingänge E 7	02:Motor_H
Eingänge E 8	03:Motor_T
Eingänge E 9	00:AUS
Eingänge E 10	00:AUS
Eingänge E 11	00:AUS
Eingänge E 12	00:AUS
Eingänge E 13	00:AUS
Eingänge E 14	00:AUS
Eingänge E 15	00:AUS
Eingänge E 16	00:AUS
Relais 1	02:[Motor_H]
Relais 2	03:[Motor_T]
Relais 3	00:AUS
Relais 4	00:AUS
Relais 5	00:AUS
Relais 6	05:AUTO
Relais 7	09:Uen<Umin
Relais 8	06:Uen>Uerd
Relais 9	36:Stör_Sum
Relais 10	14:Abgest
Relais 11	04:[Status]
LEDs 1	04:[Status]
LEDs 2	36:[Stör_Sum]
LEDs 3	12:[End_H/T]
LEDs 4	13:[Mot_Lauf]
LEDs 5	06:[Uen>Uerd]
LEDs 6	00:AUS
LEDs 7	00:AUS
LEDs 8	00:AUS
Mindesthaltezeit Relais [s]	0,0
Impulsverläng. Mot-H/T [s]	4,0
Meldungsverz. Alarm [s]	0,0
Meldungsverz. Störung [s]	0,0
Fehlerquittung	00:Menu
Stromnennwert I1	00:1A
knI1	1,00
Stromnennwert I2	00:1A
knI2	1,00




Fixspule	00:AUS
Querkupplung	00:AUS
Linearisierungstabelle R 1 [%]	0,0
Linearisierungstabelle R 2 [%]	0,0
Linearisierungstabelle R 3 [%]	0,0
Linearisierungstabelle R 4 [%]	0,0
Linearisierungstabelle R 5 [%]	0,0
Linearisierungstabelle R 6 [%]	0,0
Linearisierungstabelle R 7 [%]	0,0
Linearisierungstabelle R 8 [%]	0,0
Linearisierungstabelle Stellung 1 [A]	0,0
Linearisierungstabelle Stellung 2 [A]	0,0
Linearisierungstabelle Stellung 3 [A]	0,0
Linearisierungstabelle Stellung 4 [A]	0,0
Linearisierungstabelle Stellung 5 [A]	0,0
Linearisierungstabelle Stellung 6 [A]	0,0
Linearisierungstabelle Stellung 7 [A]	0,0
Linearisierungstabelle Stellung 8 [A]	0,0

Analogausgänge

Kanaltyp 1	02:Ausgang
Nominalwert 1	01:20 mA
Ausgangsfunktion 1	02:Une

Seite 3:


Eingangsfunktion 1	02:Une
Filter-Zeitkonstante 1 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 1	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 1	100,0
Punkt X3 (Einheit: Siehe Nominalwert) 1	0,0
Punkt Y1, normiert 1 [%]	0,000
Punkt Y2, normiert 1 [%]	100,000
Punkt Y3, normiert 1 [%]	0,000
Kanaltyp 2	02:Ausgang
Nominalwert 2	01:20 mA
Ausgangsfunktion 2	06:Ipos
Eingangsfunktion 2	06:Ipos
Filter-Zeitkonstante 2 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 2	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 2	400,0
Punkt X3 (Einheit: Siehe Nominalwert) 2	0,0
Punkt Y1, normiert 2 [%]	0,000
Punkt Y2, normiert 2 [%]	100,000
Punkt Y3, normiert 2 [%]	0,000
Kanaltyp 3	02:Ausgang
Nominalwert 3	01:20 mA
Ausgangsfunktion 3	03:I1
Eingangsfunktion 3	03:I1
Filter-Zeitkonstante 3 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 3	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 3	1,0
Punkt X3 (Einheit: Siehe Nominalwert) 3	0,0
Punkt Y1, normiert 3 [%]	0,000
Punkt Y2, normiert 3 [%]	100,000
Punkt Y3, normiert 3 [%]	0,000
Kanaltyp 4	02:Ausgang
Nominalwert 4	01:20 mA
Ausgangsfunktion 4	00:Aus
Eingangsfunktion 4	00:Aus
Filter-Zeitkonstante 4 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 4	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 4	0,0
Punkt X3 (Einheit: Siehe Nominalwert) 4	0,0
Punkt Y1, normiert 4 [%]	0,000




Punkt Y2, normiert 4 [%]	0,000
Punkt Y3, normiert 4 [%]	0,000
Kanaltyp 5	00:AUS
Nominalwert 5	00:AUS
Ausgangsfunktion 5	00:AUS
Eingangsfunktion 5	00:AUS
Filter-Zeitkonstante 5 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 5	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 5	0,0
Punkt X3 (Einheit: Siehe Nominalwert) 5	0,0
Punkt Y1, normiert 5 [%]	0,000
Punkt Y2, normiert 5 [%]	0,000
Punkt Y3, normiert 5 [%]	0,000
Kanaltyp 6	00:AUS
Nominalwert 6	00:AUS
Ausgangsfunktion 6	00:AUS
Eingangsfunktion 6	00:AUS
Filter-Zeitkonstante 6 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 6	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 6	0,0
Punkt X3 (Einheit: Siehe Nominalwert) 6	0,0
Punkt Y1, normiert 6 [%]	0,000
Punkt Y2, normiert 6 [%]	0,000
Punkt Y3, normiert 6 [%]	0,000
Endschalter Tiefer [%]	0,0
Endschalter Höher [%]	0,0
Spulenlaufzeit [s]	0,0
Spulennachlauf [A]	0,0
Spulenspiel [A]	0,0
Spulenspiel-Schwelle [%]	100,0
Linearitätsfehler [%]	0,0
Estimat1	0,5
Estimate2	0,6

Seite 4:

Ruhepos 2 [A]	100
Optionen	
Local / Remote Einstellung	00:Local
L / R Freigabe durch Leittechnik	00:gesperrt
Local / Remote aktiv	00:Aus
Simulation	00:AUS
Ires 1 [A]	100,0
Iu 1 [A]	0,10
Iw 1 [A]	10,0
phi 1 [°]	0,0
Ires 2 [A]	130,0
Iu 2 [A]	0,10
Iw 2 [A]	10,0
phi 2 [°]	0,0
Ires 3 [A]	200,0
Iu 3 [A]	0,10
Iw 3 [A]	20,0
phi 3 [°]	0,0
Spulenlaufzeit [s]	60
Endschalter Höher	95,0
Endschalter Tiefer [%]	5,0
System	
Sprache	Deutsch
COM 1 Mode	ECL
COM 1 Baudrate	115200
COM 1 Parität	P-
COM 1 Handshake	RTS



COM 2 Mode	ECL
COM 2 Baudrate	115200
COM 2 Parität	P-
COM 2 Handshake	XON
ELAN links Draht	2W
ELAN links Baudrate	62K5
ELAN links Terminiert	Ja
ELAN rechts Mode	2W
ELAN rechts Baudrate	62K5
ELAN rechts Terminiert	Ja
Kennung	A:
Name	REG-DP
LCD-Schoner	00:AUS
Datum	19.11.01
Zeit	00:14:45
Hardwareversion	2



11.6.3 Parameter print-out sorted according to index cards:

REG-DP


Kommentar: UW-Standard
 Quelle: Standard_REG-DP.prm; Firmware: 2.0.18
 Speicherdatum: 18. Nov. 01; Speicherzeit: 22:21:14
 Ausdruck vom 18. Nov. 01, 10:25

Regelung 1

Kennung	A:
Name	REG-DP
Toleranzbereich	00:relativ
Uen Toleranz [%]	20
Uen Toleranz [A]	0,10
Verzögerung der Suche [s]	10
Verzögerung der Zwangssuche [s]	10
Sollverstimmung	00:% von Ire
Sollverstimmung [%]	10
Sollverstimmung [A]	10
Sollverstimmung [V]	7,0
Positionierungstoleranz [%]	1,0
Mindestverstell. dIpos [A]	5,0
Uen in	00:%
Netzparameter	01:Uen_Ir_Iw
Resonanzmax überfahren	01:JA
Nachziehen Uref [min]	5
Uen Winkelmessung	01:Ein
Suchzyklen max.	10
Motorlaufzeit max [min]	45
Ruhepos. Suche [A]	50
Endposition bei Abbruch	00:Ruhe_Su
Uerd-Schwelle [%]	30,0
Erdschlusswischer < [s]	7,0
Uerd-Meldeverz. [s]	7,0
Selbsthaltung	00:Aus
Korrektur Ipos	00:Aus
dIc_1 [A]	5,0
dIc_2 [A]	10,0
dIc_3 [A]	20,0
dIc_4 [A]	40,0

Regelung 2

Umax-Schwelle [%]	30,0
Umin-Schwelle [%]	0,2
Endposition	01:AbstimmP.
Meldung Uen<Umin nach [min]	15
Neue Suche nach [min]	60
dUen-Begrenzung von Umin [%]	33
Selbsthaltung	00:Aus
Widerstandssteuerung aktiv	00:AUS
Einschaltverzögerung [s]	1,0
R-Einschaltzeit [s]	1,0
Widerstandssteuerung, Selbsthaltung	00:Aus
Einschaltzeit maximal [s]	10,0
R-Temperatur maximal [o]	200
R-Abkühlzeit [min]	60
Wiederholungsverzögerung [s]	1,0
Wiederholungszyklen	0
Parallelprogramm	00:Aus
Parallelprogramm: aktiv	00:Aus
Parallelprogramm: Slave Pos. bei UMin	00:Stop
Slavekennung	---
Slave nachziehen	00:Nein



Strom anzeigen inkl. Slave-Position

01:Ja

E/A-Funktionen

Eingänge E 1
Eingänge E 2
Eingänge E 3
Eingänge E 4
Eingänge E 5
Eingänge E 6
Eingänge E 7
Eingänge E 8

07:[End_H]
08:[End_T]
00:AUS
00:AUS
15:Imp:AUTO
16:Imp:HAND
02:Motor_H
03:Motor_T

Seite 2:

Eingänge E 9
Eingänge E 10
Eingänge E 11
Eingänge E 12
Eingänge E 13
Eingänge E 14
Eingänge E 15
Eingänge E 16

00:AUS
00:AUS
00:AUS
00:AUS
00:AUS
00:AUS
00:AUS
00:AUS
02:[Motor_H]
03:[Motor_T]
00:AUS
00:AUS
00:AUS
05:AUTO
09:Uen<Umin
06:Uen>Uerd
36:Stör_Sum
14:Abgest
04:[Status]
04:[Status]
36:[Stör_Sum
12:[End_H/T]
13:[Mot_Lauf
06:[Uen>Uerd
00:AUS
00:AUS
00:AUS
00:Menu
0,0
4,0
0,0
0,0

Relais 1
Relais 2
Relais 3
Relais 4
Relais 5
Relais 6
Relais 7
Relais 8
Relais 9
Relais 10
Relais 11

LEDs 1
LEDs 2
LEDs 3
LEDs 4
LEDs 5
LEDs 6
LEDs 7
LEDs 8

Fehlerquittung

Mindesthaltezeit Relais [s]

Impulsverläng. Mot-H/T [s]

Meldungsverz. Alarm [s]

Meldungsverz. Störung [s]

Konfiguration

Nennspannung [V]

knU

50 Hz Filter

Messbereich Uen

Stromnennwert I1

knI1

Stromnennwert I2

knI2

100,0
115,0
01:EIN
01:20 V
00:1A
1,00
00:1A
1,00

System

COM 1 Mode

COM 1 Baudrate

COM 1 Parität


COM 1 Handshake

COM 2 Mode

COM 2 Baudrate

COM 2 Parität


ECL
115200
P-
RTS
ECL
115200
P-



COM 2 Handshake	XON
ELAN links Draht	2W
ELAN links Baudrate	62K5
ELAN links Terminiert	Ja
ELAN rechts Mode	2W
ELAN rechts Baudrate	62K5
ELAN rechts Terminiert	Ja
Local / Remote aktiv	00:Aus
Local / Remote Einstellung	00:Local
L / R Freigabe durch Leittechnik	00:gesperrt
Hardwareversion	2
Sprache	Deutsch
LCD-Schoner	00:AUS
Datum	19.11.01
Zeit	00:14:45
P-Spule	
Imin [A]	20,0
Imax [A]	200,0
Fixspule [A]	0
Software-Endschalter: aktiv	00:Aus

Seite 3:


Type der Endschalter	00:Schließer
Software-Endschalter: I Min [A]	0,0
Software-Endschalter: I Max [A]	9999,0
Schaltabstand zur gemessenen Endschalterpos. [%]	1,0
Linearisierungstabelle R 1 [%]	0,0
Linearisierungstabelle R 2 [%]	0,0
Linearisierungstabelle R 3 [%]	0,0
Linearisierungstabelle R 4 [%]	0,0
Linearisierungstabelle R 5 [%]	0,0
Linearisierungstabelle R 6 [%]	0,0
Linearisierungstabelle R 7 [%]	0,0
Linearisierungstabelle R 8 [%]	0,0
Linearisierungstabelle Stellung 1 [A]	0,0
Linearisierungstabelle Stellung 2 [A]	0,0
Linearisierungstabelle Stellung 3 [A]	0,0
Linearisierungstabelle Stellung 4 [A]	0,0
Linearisierungstabelle Stellung 5 [A]	0,0
Linearisierungstabelle Stellung 6 [A]	0,0
Linearisierungstabelle Stellung 7 [A]	0,0
Linearisierungstabelle Stellung 8 [A]	0,0
Spulenposition Anschluss	00:3-Leiter
Spulenposition R-Wert	02:1 kOhm
Endschalter Tiefer [%]	0,0
Endschalter Höher [%]	0,0
Spulenlaufzeit [s]	0,0
Spulennachlauf [A]	0,0
Spulenspiel [A]	0,0
Linearitätsfehler [%]	0,0
Spulenspiel-Schwelle [%]	100,0
Netzmodell	
Simulation	00:AUS
Ires 1 [A]	100,0
Iu 1 [A]	0,10
Iw 1 [A]	10,0
phi 1 [°]	0,0
Ires 2 [A]	130,0
Iu 2 [A]	0,10
Iw 2 [A]	10,0
phi 2 [°]	0,0
Ires 3 [A]	200,0
Iu 3 [A]	0,10



Iw 3 [A]	20,0
phi 3 [°]	0,0
Spulenlaufzeit [s]	60
Endschalter Höher	95,0
Endschalter Tiefer [%]	5,0
Analogausgänge	
Kanaltyp 1	02:Ausgang
Nominalwert 1	01:20 mA
Ausgangsfunktion 1	02:Une
Eingangsfunktion 1	02:Une
Filter-Zeitkonstante 1 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 1	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 1	100,0
Punkt X3 (Einheit: Siehe Nominalwert) 1	0,0
Punkt Y1, normiert 1 [%]	0,000
Punkt Y2, normiert 1 [%]	100,000
Punkt Y3, normiert 1 [%]	0,000
Kanaltyp 2	02:Ausgang
Nominalwert 2	01:20 mA
Ausgangsfunktion 2	06:Ipos
Eingangsfunktion 2	06:Ipos
Filter-Zeitkonstante 2 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 2	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 2	400,0
Punkt X3 (Einheit: Siehe Nominalwert) 2	0,0
Punkt Y1, normiert 2 [%]	0,000
Punkt Y2, normiert 2 [%]	100,000
Punkt Y3, normiert 2 [%]	0,000
Kanaltyp 3	02:Ausgang

Seite 4:

Nominalwert 3	01:20 mA
Ausgangsfunktion 3	03:I1
Eingangsfunktion 3	03:I1
Filter-Zeitkonstante 3 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 3	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 3	1,0
Punkt X3 (Einheit: Siehe Nominalwert) 3	0,0
Punkt Y1, normiert 3 [%]	0,000
Punkt Y2, normiert 3 [%]	100,000
Punkt Y3, normiert 3 [%]	0,000
Kanaltyp 4	02:Ausgang
Nominalwert 4	01:20 mA
Ausgangsfunktion 4	00:Aus
Eingangsfunktion 4	00:Aus
Filter-Zeitkonstante 4 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 4	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 4	0,0
Punkt X3 (Einheit: Siehe Nominalwert) 4	0,0
Punkt Y1, normiert 4 [%]	0,000
Punkt Y2, normiert 4 [%]	0,000
Punkt Y3, normiert 4 [%]	0,000
Kanaltyp 5	00:AUS
Nominalwert 5	00:AUS
Ausgangsfunktion 5	00:AUS
Eingangsfunktion 5	00:AUS
Filter-Zeitkonstante 5 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 5	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 5	0,0
Punkt X3 (Einheit: Siehe Nominalwert) 5	0,0
Punkt Y1, normiert 5 [%]	0,000
Punkt Y2, normiert 5 [%]	0,000
Punkt Y3, normiert 5 [%]	0,000



Kanaltyp 6	00:AUS
Nominalwert 6	00:AUS
Ausgangsfunktion 6	00:AUS
Eingangsfunktion 6	00:AUS
Filter-Zeitkonstante 6 [s]	0
Punkt X1 (Einheit: Siehe Nominalwert) 6	0,0
Punkt X2 (Einheit: Siehe Nominalwert) 6	0,0
Punkt X3 (Einheit: Siehe Nominalwert) 6	0,0
Punkt Y1, normiert 6 [%]	0,000
Punkt Y2, normiert 6 [%]	0,000
Punkt Y3, normiert 6 [%]	0,000

Interne Parameter

Estimatel	0,5
Estimate2	0,6
Querkupplung	00:AUS
Fixspule	00:AUS
Ruhepos 2 [A]	



12 Background - programming REG-L

12.1 The programming language REG-L

The programming language REG-L (REG-Language) has been especially developed for the requirements of the voltage regulation system REGSys with the aim to offer a simple line-orientated dialogue language. Meanwhile, the REG-L has been enlarged by commands for the P-coil regulator REG-DP.

The language leans on the programming languages Forth and BASIC which had been developed for a fast close-to-the-machine control. Forth permits a simple summary of command series to new commands. Forth uses the "Reversed Polish Notation" (UPN) which is well-known from the scientific HP-calculators.

The programming of the regulator may be made by any ASCII - terminal. The programme lines are edited as text in the regulator and stored by <Return> when all is typed in.

The programme lines are read from the interpreter in the regulator and worked through cyclically in the "background".

In the following please find extracts of the available commands in the REG-DP. This list may also be polled by the help text in the terminal mode. (After the Prompt, which includes the regulator address, an <A> in our example, please insert a ? and a <Return>)

12.2 List of the REG-L / ECL-Interpreter-commands

A>?

Verzeichnis der REG-L/ECL-Interpreter-Befehle:


----- REG-DP: Version 2.0.18

```
Messdaten:      Esp...
Schreiber:      RecSCAN RecSTOP RecCLEAR
Analogwerte:    ANA ANAMIN ANAMAX ANAFAKTOR ANAOFFSET ANAMODE
Stationsparam.: STATION GRUPPE STATUS SPRACHE DATUMFORMAT
Mathematik:     SQRT SIN COS ASIN ACOS DEG RAD EXP LOG LOG10 **
                ABS FRAC FIX INT INTR MAX MIN MOD
Stack-Op's:     + - * / & | ^ ~ && || ^^ ~~ SHR SHL < <= > >= == !=
                DUP DROP SWAP PICK PRINT !
Verzweigungen: IF IFF ELSE ENDIF
Schleifen:      ALL NEXTA FORI I NEXTI DO DOWHILE EXIT RETURN PAUSE
Programme:      P PLIST H HLIST HBREAK HTD ERR ERRNR LERR MENUAPP REM
Variablen:      A ALIST B BLIST
ECS-LAN:        BUS DIR DIRN DIRS INDIR KENN SETKENN SYSTEST
Zeitbefehle:    ZEIT DATUM TM TMD HTD VON BIS DAUER SOWI
sonstige:       AUFZ FINDER DELIMITER DISPLAY MELD TASTE VER ERRSTAT ERRKAN
                PASSWORT LOGIN LOGOUT WHOAMI TX1 TX2 DCF
```

Allgemein: INFO SYNTAX EXTENSION PARAMETER STRINGS STACK KENNUNG RS232
Spezielle Hilfe mit: HILFE <Befehlsname> oder ? <Befehlsname>

Beispiele für die Hilfe:

```
? Esp*          Liste aller REG-DP spezifischen Befehle.
? EspI*         Liste aller Gruppen in denen ein Befehl mit EspI beginnt.
? EspVo         Liste der Gruppe in der EspVo vorkommt.
? Buch          Erzeugt eine Beschreibung aller Befehle.
```



12.3 REG-DP specific commands

<A>? ESP*

REG-DP spezifische Befehle

=====

Diese Befehlsgruppe beginnt stets mit ESP...

Allgemeine Form: ESPxxxxxxx [<aufzählung>] [= <wert>]

Ausgabe: Ja (außer bei Ext. '-' oder entsprechendem Hinweis)

Stack (Lesen): - >>> <rückgabewert>

Stack (Schreiben): - >>> -

Ext.: - + % # . & \$

modifizierende Ext.: * _ (bei entsprechendem Hinweis)

- Die Befehlsausgabe ist rückschreibbar (sofern der entsprechende Befehl eine Zuweisung erlaubt). Ausnahme: Numerische Parameter beim Lesen mit der Extension *: sie liefern die Bereichsgrenzen als String in der Form [<min>,<max>] und legen den eingestellten Wert auf den Stack. Beim Schreiben in der *-Form wird bei Überschreitung der Bereichsgrenzen der nächstliegende Grenzwert eingestellt, statt die Meldung <<Argumentbereich überschritten>> zu bringen.
- Unterstützt der Befehl eine <aufzählung>, so ist der <rückgabewert> stets die Summe aus allen Rückgabewerten der <aufzählung>.

Befehlsliste:

Momentanwerte:

EspVo, EspVoPhi, EspVl2, EspIo, EspIoPhi, EspI2, EspI2Phi, EspIpos, EspIposR, EspTimer, EspCounter

Betriebsmoden:

EspAuto, EspMotUp, EspMotUpI, EspMotDown, EspMotDownI, EspMotGoto, EspLRActive, EspEnableLR, EspRemote, EspLocal, EspBlock, EspSearch, EspGoIHome, EspEFault, EspIFixOn, EspBusBar, ESPerrAckM, ESPerrAck, EspPState

Berechnete Netzgrößen:

EspUres, EspUresPhi, EspIres, EspIu, EspIw, EspUref, EspUrefPhi

Anzeige-Optionen:

EspLcdVo, EspLcdPar, EspLcdVoCnt, EspLCDSaver, Language, EspAddSlPos

Standardparameter:

ESpdVoType, ESPdVoRel, ESPdVoAbs, EspTSearch, EspTuneType, EspTuneAP, EspTuneAA, EspTuneVV, EspMaxDPos, SPdIpMin, EspVresPass, EspTFollow, EspUseAngle, EspSrchCnt, EspTMotMax, EspIhome, EspIhome2

Erdschlußparameter:

EspVEarth, EspTEFSpike, EspTDVearth, EspEFCorrMod, EspEFCorr, EspEFToMan

Umax-Parameter:


EspVMax

Umin-Parameter:

EspVMin, EspVminPos, EspTDVmin, EspSrchT, EspVminMin, EspVminToMan

Signalverzögerungen:

EspTonRel, EspTonPuls, EspTDAlarm, EspTDError



Widerstandssteuerung:

EspRBlock, EspRStart, EspRTemp,
EspRActive, EspRTon, EspRTonMax, EspRTcold, EspRTdelay1, EspRTdelay2,
EspRNcycle, EspRTempMax

Parallelregelung:

EspParaProg, EspParaProgA, EspParaGr, EspSlaveMove, EspSlUminPos,

Binäre Ein/Ausgänge:

EspBIFu, EspBIInv, EspRelFu, EspRelInv, EspLedFu, EspLedInv, EspRelFVOvr,
EspBI, EspBI32, EspBITC, EspRel, EspRel32, EspLed, EspLed32, EspBIFV,
EspBIFV32, EspRelFV, EspRelFV32, EspLedFV, EspRelPV, EspLedPV

Analoge Ein/Ausgänge:

EspAIOType, EspAIOnom, EspAIFu, EspAOFu, EspAIOFIL, EspAScalX, EspAScalY,
EspAIFV, EspAOFV, EspAOPV

Spannungsmessung:

EspHardware, EspKnVo, EspVoRated, EspVoRange, EspVo50Hz

Daten der Petersen-Spule:

EspIMin, EspIMax, EspRType, EspRValue, EspIFix, EspLinR, EspLinI,
EspSwitchL, EspSwitchH, EspTMotLH, EspMotDly, EspMotHyst, EspMHystThr, EspRError,
EspEndAvail, EspSoftEnd, EspSoftEndH, EspSoftEndL

Strommessung:


EspI1Rated, EspKnI1, EspI2Rated, EspKnI2

Spulen-Daten:

EspCalOpen, EspCalU0, EspCalU2, EspCalI01, EspCalI05, EspCalI21, EspCalI25
EspCalRU, EspCalRO, EspCalState

Simulation:

EspSimul, EspNet1Ires, EspNet1Iu, EspNet1Iw, EspNet1Phi, EspNet2Ires, EspNet2Iu
EspNet2Iw, EspNet2Phi, EspNet3Ires, EspNet3Iu, EspNet3Iw, EspNet3Phi,
EspNetMotLH, EspNetEndH, EspNetEndL, EspNetHyst, EspEst1, EspEst2



Momentan-Werte lesen

EspVo Momentanwert der Verlagerungsspannung (sekundär)
 EspVoPhi Winkel der Verlagerungsspannung in ° bezogen auf U12

 EspV12 [= <wert>] Momentanwert der Vergleichsspannung U12 (sekundär)

 EspIpos linearisierte Spulenposition in A
 EspIposR Messwert der Spulenposition in % vom Meßbereich des Widerstandes
 Nennwert des Widerstandes entspricht 100% bzw. beim Potentiometer
 der oberen Endstellung.

 EspIo [= <wert>] Momentanwert des gemessenen Petersen-Spulenstroms (sek.)
 EspIoPhi [= <wert>] Winkel des gemessenen P-Spulenstroms in ° bezogen auf U12

 EspI2 [= <wert>] Momentanwert des 2. Stromeingangs (sekundär)
 EspI2Phi [= <wert>] Winkel des 2. Stromeingangs in ° bezogen auf U12

 EspTimer <aufz> [<KW>] [= <wert>] aktuelle Statistiker-Zeiten lesen/setzen in [s]
 <aufz>: 1:Auto-Betrieb, 2:Motorlaufzeit, 3:Erdschlusszeit
 ohne <KW>: liest/setzt die Summen-Zeiten
 mit <KW>=1..53: liest/setzt die KW-Zeiten
 Zuweisungen: nur mit Extension '*' möglich;
 zuweisbarer Bereich: 0...1e9;
 Nachkommastellen werden ignoriert
 EspCounter <aufz> [<KW>] [=0] aktuelle Statistiker-Zählerstände
 <aufz>: 1:SuchAnzahl, 2:Abgestimmt, 3:AbgestNK,
 4:AbgestUmin, 5:ErdschlussWischer, 6:Erdschluss,
 7:WattRestStrom, 8:Auslösungen
 ohne <KW>: liest/setzt die Summen-Zähler
 mit <KW>=1..53: liest/setzt die KW-Zähler
 Zuweisungen: nur mit Extension '*' möglich;
 zuweisbarer Bereich: 0...1e9;
 Nachkommastellen werden ignoriert
 EspStatist [<KW>] [<KW2>] liefert Tabelle aller Zählerstände
 ohne Parameter: liefert Summenzählerstände
 mit <KW>: liefert die Zählerstände der KW
 mit <KW> und <KW2>: liefert die Stände von KW bis KW2

Soweit die Werte zuweisbar sind, wird der zugewiesene Wert bei eingeschalteter Simulation zurückgeliefert.

Betriebsmodes lesen/ändern


EspAuto [= <wert>] 1: Automatikbetrieb
 0: Handbetrieb
 EspMotUp [= <wert>] Motor höher für <wert> Sek.; Lesen liefert die Restzeit;
 =0 stoppt den Motor
 EspMotUpI [=1] Motor höher für im Menü parametrisiert Impulszeit;
 Lesen liefert die Restzeit
 EspMotDown [= <wert>] Motor tiefer für <wert> Sek.; Lesen liefert die Restzeit
 =0 stoppt den Motor
 EspMotDownI [=1] Motor tiefer für im Menü parametrisierte Impulszeit;
 Lesen liefert Restzeit
 EspMotGoto [= <wert>] Zuweisung: gewünschte Position der Spule [A] im Handbetrieb (ohne
 Fixspule)
 Lesen: liefert =1, wenn Position erreicht; sonst 0


 EspLRActive [= <wert>] 1: Local-/Remotebetrieb ist aktiv
 0: Local-/Remotebetrieb ist nicht aktiv
 (Bedienung ist nicht eingeschränkt)
 EspEnableLR [= <wert>] 1: Umschaltung Local/Remote über Reg-L erlaubt
 0: Umschaltung Local/Remote über Reg-L gesperrt
 Zuweisung nur in der *-Form möglich


Die Kommandos EspAuto, EspMot., EspBlock, EspSearch, EspGoIHome2, EspIFixOn und EspBusBar wirken nicht im Localbetrieb; in der *-Form immer.

EspUres	Verlagerungsspannung im Resonanzpunkt in V
EspUresPhi	Winkel der Unsymmetriespannung bezogen auf U12
EspIres	Resonanzpunkt (Spulenposition, ohne Fixspule)
EspIu	Unsymmetriestrom
EspIw	Wattreststrom
EspUref	Referenzspannung für Auslösung im Abstimmpunkt
EspUrefPhi	Referenzwinkel bezogen auf U12 für Auslösung im Abstimmpunkt

Die Kommandos `EspRBlock` und `EspRStart` wirken nicht im Localbetrieb; in der *-Form immer.







Widerstandssteuerung

EspRActive [= <wert>] Hauptschalter für Widerstandssteuerung;
 0: aus,
 1: ein
 EspRTempMax [= <wert>] Maximal zulässige Widerstandstemperatur nach EspRTonMax
 EspRTonMax [= <wert>] Maximale Einschaltzeit des Widerstands in s
 EspRTcold [= <wert>] Abkühlzeit des Widerstands von RTempMax auf 40°C in min
 (entspricht 3x Zeitkonstante)
 EspRTon [= <wert>] Einschaltzeit des Widerstandes für einen einzelnen
 Impuls in s
 EspRTdelay1 [= <wert>] Verzögerung vom Erdschlußeintritt bzw. manueller
 Auslösung bis zum 1. Impuls in s
 EspRTdelay2 [= <wert>] Verzögerung zwischen den einzelnen Impulsen in s
 EspRNcycle [= <wert>] Anzahl der zusätzlichen Impulse pro Auslösung
 EspRAutoBlk [= <wert>] Selbstblockierung nach Auslösung durch Erdschluß:
 0: aus
 1: ein, Quittierung nur manuell möglich
 2: auto, Selbstblockierung erlischt nach RTcold

Das thermische Abbild arbeitet nach folgenden Regeln:

Aufheizung: linear, die Temperatur steigt in RTonMax von 40°C auf RTempMax

Abkühlung: exponentiell mit Zeitkonstante RTcold/3, die Ausgleichstemperatur ist so gewählt, daß der Widerstand in RTcold von RTempMax auf 40°C abkühlt.

Parallelregelung


EspParaProg [= <wert>] Auswahl der Parallelbetriebs-Art
 00:Aus
 01:Master/Slave
 EspParaProgA [= <wert>] Aktivieren des Parallelbetriebs
 00:Aus
 01:Ein
 02:SSKupplung (mit binärer Eingangsfunktion 29:Kupplung)
 EspParaGr [= <KennungsNummer>] Kennung des Parallelregel-Partners
 Infos zu <KennungsNummer> bei KENN
 EspSlaveMove [= <wert>] Master/Slave-Betrieb: das Nachziehen(Positionieren) vom
 Slave erlauben
 00:Nein
 01:Ja
 EspSlUminPos [= <wert>] Master/Slave-Betrieb: Positionieren vom Slave bei Umin
 00:Stop (kein Positionieren)
 01:Ruhe_Su (Positionieren auf IRuhe)
 02:AbstimmP. (Positionieren auf letztgültigen Abstimmungspunkt)

Binäre Ein/Ausgänge

Der Einfachheit halber ist im Folgenden immer von "dem" Ein- oder Ausgang die Rede, obwohl eine Adressierung über <aufz> vorliegt. Wie für alle Aufzählungen gilt: beim Lesen werden alle Einzelwerte gelistet und die Summe auf den Stack gelegt, bei Zuweisungen werden alle adressierten Werte gesetzt.

binäre Eingänge:

Alle Eingänge und Eingangsfunktionen können mit "EspBI", "EspBIFV" zugewiesen werden: Der Wert wird für 60s überschrieben. Zuweisung eines beliebigen Wertes mit Extension "*" hebt den Override sofort wieder auf.



EspBIFu <aufz>[=<wert>] Funktion des Eingangs
 ListBIFu Liste der möglichen Eingangsfunktionen
 EspBIInv <aufz>[=<wert>] Inversschaltung des Eingangs;
 0: normal,
 1: invertiert
 Die Eingangsinvertierung wirkt zwischen Eingang und
 Eingangs-Funktion, wird also bei EspBiFV sichtbar,
 bei EspBI nicht
 EspBI <aufz>[=<wert>] Zustand des Eingangs; Achtung bei Zuweisung !!!
 0: kein Signal,
 1: Signal
 EspBI32 Zustand aller Eingänge: Bit 0 entspricht Eingang 1 etc.
 EspBITC <aufz>[=<wert>] Anzahl der 0/1-Flanken am Eingang seit dem letzten Aufruf;
 die *-Form setzt den Zähler nicht zurück, es wird also
 tatsächlich die Anzahl seit dem letzten Aufruf ohne * geliefert.
 EspBITCT <aufz>[=<wert>] Anzahl der 0/1-Flanken am Eingang seit dem letzten
 Reset. Dieser Befehl ist nützlich, falls mehrere
 Instanzen die Flanken des gleichen Eingangs auswerten wollen.
 EspBIFV <aufz>[=<wert>] Zustand der Eingangsfunktion; alle nicht mit
 Eingängen verknüpften Eingangsfunktionen liefern
 immer 0; alle mit mehreren Eingängen verknüpften
 Eingangsfunktionen liefern die verODERung der Eingänge
 EspBIFV32 <aufz> Zustand aller Eingangsfunktionen in Gruppen zu 32 Bit:
 Bit0 entspricht Eingangsfunktionen 0:AUS etc.

Relais:


 EspRelFu <aufz>[=<wert>] Relais-Funktion
 ListRelFu Liste der möglichen Binär-Ausgangsfunktionen
 EspRelInv <aufz>[=<wert>] Relais-Inversschaltung
 Die Relaisinvertierung wirkt zwischen Ausgangsfunktion
 und Ausgang, wird also bei EspRel sichtbar, bei EspRelFV nicht
 EspRel <aufz> Zustand des Relaisausgangs.
 EspRel32 Zustand aller Relaisausgänge: Bit 0 entspr. Relais 1 etc.
 EspRelFV <aufz>[=<wert>] Zustand der Ausgangsfunktionen; eine Zuweisung ist nur möglich,
 wenn vorher "EspRelFVOvr =1" gesetzt wurde (siehe dort)
 EspRelFV32 <aufz> Zustand aller Ausgangsfunktionen in Gruppen zu 32 Bit:
 Bit0 entspricht Ausgangsfunktionen 0:AUS etc.
 EspRelPV <aufz>[=<wert>] Zustand der Ausgangsfunktion "Prog", mit <aufz>
 wird hier das Relais adressiert

LED's:

 EspLEDFu <aufz>[=<wert>] LED-Funktion
 ListLEDFu Liste der möglichen Ausgangsfunktionen (identisch zu ListRelFu)
 EspLEDInv <aufz>[=<wert>] LED-Inversschaltung (vgl. EspRelInv)
 EspLED <aufz> Zustand der LED.
 EspLED32 Zustand aller LEDs: Bit 0 entspricht LED 1 etc.
 EspLEDFV <aufz> Zustand der Ausgangsfunktionen; wie EspRelFV
 EspLEDPV <aufz>[=<wert>] Zustand der Ausgangsfunktion "Prog", mit <aufz>
 wird hier die LED adressiert

Testfunktionen:

 EspRelFVOvr [=<wert>] Override der Ausgangsfunktionen; !!!! Nur für Testzwecke !!!!:
 0: Normalbetrieb, Ausgangsfunktionen werden vom Regler bedient
 1: Ausgangsfunktionen vom Regler abgekoppelt und stattdessen
 zuweisbar für max. 10 min
 ACHTUNG: die zugewiesenen Werte werden über Relais/LEDs ausgegeben!
 Fehlbedienung kann u.U. zu Schäden in der Anlage führen!



Analoge Ein/Ausgänge

Der Einfachheit halber ist im Folgenden immer von "dem" Ein- oder Ausgang die Rede, obwohl eine Adressierung über <aufz> vorliegt. Wie für alle Aufzählungen gilt: beim Lesen werden alle Einzelwerte gelistet und die Summe auf den Stack gelegt, bei Zuweisungen werden alle adressierten Werte gesetzt.

ESPAIOType <aufz> Typ des Analogkanals;
 0: nicht bestückt,
 1: Eingang,
 2: Ausgang

ESPAIONOM <aufz> Installierter Nennwert des Analogkanals;
 0: unbekannt/nicht bestückt,
 1: 20 mA
 2: 10 mA
 3: 5 mA
 4: 2.5 mA
 5: 10 V

ESPAIFu <aufz>[=<wert>] Eingangsfunktion des AnalogEingangs
 ESPAOFu <aufz>[=<wert>] Ausgangsfunktion des AnalogAusgangs
 ESPAIOFIL <aufz>[=<wert>] Filter-Zeitkonstante des Analogkanals in s
 ESPAScalX <aufz><index>[=<wert>] X-Komponente der Stützstellen für die geknickte Kennlinie, <index>=0/1/2
 ESPAScalY <aufz><index>[=<wert>] Y-Komponente der Stützstellen für die geknickte Kennlinie, <index>=0/1/2

EspAIFV <aufz> Wert der Analog-Eingangsfunktion
 EspAOFV <aufz> Wert der Analog-Ausgangsfunktion
 EspAOPV <aufz>[=<wert>] Wert der Analog-Ausgangsfunktion "Prog"; mit <aufz> wird hier der Analogkanal adressiert

Spannungsmessung


EspHardware Mess-Hardware: 0: unbekannt
 1: LPER (Reg-DE)
 2: NTZ2 (Reg-DP)

EspKnVo [=<wert>] Wandlerübersetzung für Verlagerungsspannung
 EspVoRated [=<wert>] Nennspannung der Verlagerungsspannung (sek.)
 EspVoRange [=<wert>] Meßbereich für U0-Messung (nur LPER);
 0: 100 V
 1: 20 V
 2: 5 V
 3: 1 V
 bei höheren Spannungen als angegeben wird automatisch auf 100V umgeschaltet. Die NTZ2-Hardware arbeitet von vorneherein mit höherer Auflösung und ohne Meßbereichsumschaltung.

EspVo50Hz [=<wert>] 50Hz-Filter (nur LPER);
 0: Aus,
 1: Ein

Daten der Petersen-Spule

EspIMin [=<wert>] Nennstrom der Petersenspule in der Endstellung "Tiefer"
 EspIMax [=<wert>] Nennstrom der Petersenspule in der Endstellung "Höher"
 EspRType [=<wert>] Art der Widerstandsmessung für Spulenposition;
 0: 3-Leiter (nur LPER, siehe EspHardware)
 1: 4-Leiter (nur LPER)
 2: Potentiometer (nur NTZ2)



EspRValue [=<wert>] Meßbereich für Widerstandsmessung (nur LPER);
 0: 200 Ohm
 1: 500 Ohm
 2: 1000 Ohm
 3: 3000 Ohm

Spulenlinearisierung mit 8 Stützstellen:

EspLinR <aufz>[=<wert>] Spulenposition in % vom R- bzw. Poti-Meßbereich
EspLinI <aufz>[=<wert>] zugehöriger Nennstrom in A

EspSwitchL [=<wert>] Spulenposition am unteren Endschalte
EspSwitchH [=<wert>] Spulenposition am oberen Endschalte
 jeweils in % vom R- bzw. Poti-Meßbereich

Ergebnisse aus Spulenkalisierung:

EspTMotLH [=<wert>] Motorlaufzeit vom unteren bis zum oberen Endschalte in s
EspMotDly [=<wert>] Spulennachlauf in A
EspMotHyst [=<wert>] Spulenspiel in A
EspMHystThr [=<wert>] Schwelle für Spulenspiel in A, ab der auf ein
alternatives Positionierverfahren umgeschaltet wird
EspRError [=<wert>] Maximaler Linearitätsfehler der R- bzw. Poti-Messung
 in % vom Meßbereich

Fixspule:

EspIFix [=<wert>] Nennstrom der Fixspule

Endschalter:

EspEndAvail [=<wert>] Endschalte-Typ
 0: Schließer
 1: Öffner
 2: nicht angeschlossen


EspSoftEnd [=<wert>] aktivieren der Software-Endschalte
 0: nein
 1: ja
EspSoftEndH [=<wert>] Position oberer Software-Endschalte in A
EspSoftEndL [=<wert>] Position unterer Software-Endschalte in A

Strommessung

EspI1Rated [=<wert>] Nenneingangsstrom des Stromwandlers 1 des Reglers (Ip);
 0: 1 A,
 1: 5 A
EspKnI1 [=<wert>] Wandlerübersetzung für Strom 1
EspI2Rated [=<wert>] Nenneingangsstrom des Stromwandlers 2 des Reglers;
 0: 1 A,
 1: 5 A
EspKnI2 [=<wert>] Wandlerübersetzung für Strom 2

Simulation

EspSimul [=<wert>] Hauptschalte für Simulation:
 0: Aus,
 1: Netz-Modell 1
 2: Netz-Modell 2
 3: Netz-Modell 3



```
EspNet1Ires [=<wert>] Modell 1: Resonanzpunkt in A
EspNet1Iu   [=<wert>] Modell 1: Unsymmetriestrom in A
EspNet1Iw   [=<wert>] Modell 1: Wirkanteil in A
EspNet1Phi  [=<wert>] Modell 1: Winkel Ures gegen Uln
```

```
EspNet2Ires [=<wert>] Modell 2: Resonanzpunkt in A
EspNet2Iu   [=<wert>] Modell 2: Unsymmetriestrom in A
EspNet2Iw   [=<wert>] Modell 2: Wirkanteil in A
EspNet2Phi  [=<wert>] Modell 2: Winkel Ures gegen Uln
```

```
EspNet3Ires [=<wert>] Modell 3: Resonanzpunkt in A
EspNet3Iu   [=<wert>] Modell 3: Unsymmetriestrom in A
EspNet3Iw   [=<wert>] Modell 3: Wirkanteil in A
EspNet3Phi  [=<wert>] Modell 3: Winkel Ures gegen Uln
```

Simulation der Petersen Spule:

```
EspNetMotLH [=<wert>] simulierte Motorlaufzeit vom unteren bis zum oberen
                    Endschalter in s
EspNetEndH   [=<wert>] simulierter Endschalter "Höher" in % vom R-Meßbereich
EspNetEndL   [=<wert>] simulierter Endschalter "Tiefer" in % vom R-Meßbereich
EspNetHyst   [=<wert>] simuliertes Spulenspiel in % vom R-Meßbereich
EspEst1      [=<wert>] interner Parameter für Netzberechnung
EspEst2      [=<wert>] interner Parameter für Netzberechnung
```

13 Control and instrumentation technology

13.1 In general

All comes/goes-messages are due to make the general poll.

For the free messages of the pass-through function, a decision will be made in the communication plug-in group or in the REG-DP if it is a comes/goes-Message or a transient message. In case of the setting of a comes/goes-Message, this message is due to be go through the general poll.

The measuring value telegramme must always include all (at present 7) measuring values. If a measuring value is not available for the transmission, so this measuring value will be transmitted with the value 7FFFh (corresponds to a failure identification).

Advantage: The measuring values always have the same address for all configurations.

Since the measuring values are not due to make the general poll, they will have to be transmitted in the case of a general poll.


13.2 Communication behaviour

Approach message

The E-coil regler REG-DP presents itself to the Master as UMZ-protection.

Time delay when general poll

When sending a general poll command, there will be a delay before the general poll is being responded to totally. In this moment, the communication plug-in group demands the present values from the regulator. There will not be the transmission of the last values sent for the general poll but the present values from the regulator.




13.3 Data points of the command direction


Description	IEC-Telegramme (values in DEZ) DATA Fkt-Typ Inf-Nr DB1 DB2 -UNIT	ILS-Telegramme (values in HEX) DT DN2 DN3 DB1 DB2	Scaling (values decimal) value = carried-over value
Hand / Automation-operation	232 160 16 02 00 Auto 232 160 16 01 00 Hand	E8 A0 10 02 00 Auto E8 A0 10 01 00 Hand	
Motor run direction I_{max} (always 2 = On)	232 160 17 02 00	E8 A0 11 02 00	
Motor run direction I_{min} (always 2 = On)	232 160 18 02 00	E8 A0 12 02 00	
Remote / Local Switching	232 160 19 02 00 Remote 232 160 19 01 00 Ort	E8 A0 13 02 00 Remote E8 A0 13 01 00 Ort	
free	232 160 20 02 00 on 232 160 20 01 00 Off	E8 A0 14 02 00 on E8 A0 14 01 00 Off	
Residual ohmic current blocking	232 160 21 02 00 on 232 160 21 01 00 Off	E8 A0 15 02 00 on E8 A0 15 01 00 Off	
Res. Ohm. Current start (always 2 = On)	232 160 22 02 00	E8 A0 16 02 00	
Regulator in Home-Position 2 (always 2 = On)	232 160 23 02 00	E8 A0 17 02 00	
Search (always 2 = on) Fixed E-Coil is on	232 160 24 02 00 20 160 31 02 00 on 20 160 31 02 01 Off	E8 A0 18 02 00	
SS-coupling	20 160 32 02 00 on 20 160 31 02 01 Off		
Position in A	144 176 58 00 00		0...2047 (16bit value)

13.4 Data points of the message direction


Description	IEC-Telegramme (values in DEZ) DATA Fkt-Typ Inf-Nr DB1 DB2 -UNIT	ILS-Telegramme (values in hex) DT DN2 DN3 DB1 DB2	Scaling (values decimal) value = carried-over value
position in %	09 160 144 00 00	04 A0 90 00 00	100,0 = 1000
position in A	09 161 144 00 00	04 A1 90 00 00	100,0 = 1000
Offset voltage in mV (Amount)	09 162 144 00 00	04 A2 90 00 00	100,0 = 1000
Offset voltage (Angle)	09 163 144 00 00	04 A3 90 00 00	-180,0° - +180,0° = * 100
Current through E-Coil (Amount)	09 164 144 00 00	04 A4 90 00 00	100,0 = 1000
Current through E-Coil (Angle)	09 165 144 00 00	04 A5 90 00 00	-180,0° - +180,0° = * 100
Resistance temperature	09 166 144 00 00	04 A6 90 00 00	-40,0°C - +50,0°C = * 100
Hand / Automation-operation	01 160 16 02 00 Auto 01 160 16 01 00 Hand	0D A0 10 02 00 Auto 0D A0 10 01 00 Hand	
Motor run direction I_{max}	01 160 17 02 00 comes 01 160 17 01 00 goes	0D A0 11 02 00 comes 0D A0 11 01 00 goes	
Motor run direction I_{min}	01 160 18 02 00 comes 01 160 18 01 00 goes	0D A0 12 02 00 comes 0D A0 12 01 00 goes	
Remote- / Local-Switching	01 160 19 02 00 Rem. 01 160 19 01 00 Local	0D A0 13 02 00 Remote 0D A0 13 01 00 Local	
regulator in blocking	01 160 20 02 00 comes 01 160 20 01 00 goes	0D A0 14 02 00 comes 0D A0 14 01 00 goes	
Residual ohmic current blocking	01 160 21 02 00 comes 01 160 21 01 00 goes	0D A0 15 02 00 comes 0D A0 15 01 00 goes	
Res. Ohm. current on	01 160 22 02 00 comes 01 160 22 01 00 goes	0D A0 16 02 00 comes 0D A0 16 01 00 goes	
Res.ohm.current Automation active	01 160 23 02 00 Yes 01 160 23 01 00 No	0D A0 17 02 00 Yes 0D A0 17 01 00 No	
regulator in Interferences-Position (j/h)	01 160 30 02 00 Yes	0D A0 1E 02 00 Yes	



Description	IEC-Telegramme (values in DEZ) DATA Fkt-Typ Inf-Nr DB1 DB2 -UNIT					ILS-Telegramme (values in hex) DT DN2 DN3 DB1 DB2					Scaling (values dezimal) value = carried-over value
	01	160	30	01	00 No	0D	A0	1E	01	00 No	
Fix E-Coil is on	01	160	31	02	00 comes	0D	A0	1F	02	00 comes	
	01	160	31	01	00 goes	0D	A0	1F	01	00 goes	
<i>coupling is on</i>	01	160	32	02	00 comes	0D	A0	20	02	00 comes	
	01	160	32	01	00 goes	0D	A0	20	01	00 goes	
Final switch I_{max} (E2)	01	160	33	02	00 comes	0D	A0	21	02	00 comes	
	01	160	33	01	00 goes	0D	A0	21	01	00 goes	
Final switch I_{min} (E1)	01	160	34	02	00 comes	0D	A0	22	02	00 comes	
	01	160	34	01	00 goes	0D	A0	22	01	00 goes	
Number of the search cycles exceeded	01	160	35	02	00 comes	0D	A0	23	02	00 comes	
	01	160	35	01	00 goes	0D	A0	23	01	00 goes	
regulator tuned, not compensated	01	160	36	02	00 comes	0D	A0	24	02	00 comes	
	01	160	36	01	00 goes	0D	A0	24	01	00 goes	
regulator ist tuned	01	160	37	02	00 comes	0D	A0	25	02	00 comes	
	01	160	37	01	00 goes	0D	A0	25	01	00 goes	
$U_0 > U_{erd}$	01	160	38	02	00 comes	0D	A0	26	02	00 comes	
	01	160	38	01	00 goes	0D	A0	26	01	00 goes	
$U_0 > U_{max}$	01	160	39	02	00 comes	0D	A0	27	02	00 comes	
	01	160	39	01	00 goes	0D	A0	27	01	00 goes	
$U_0 < U_{min}$	01	160	40	02	00 comes	0D	A0	28	02	00 comes	
	01	160	40	01	00 goes	0D	A0	28	01	00 goes	
U_{12} too small (reference phase)	01	160	41	02	00 comes	0D	A0	29	02	00 comes	
	01	160	41	01	00 goes	0D	A0	29	01	00 goes	
$I_{pos} > I_{max}$	01	160	42	02	00 comes	0D	A0	2A	02	00 comes	
	01	160	42	01	00 goes	0D	A0	2A	01	00 goes	
Direction error	01	160	43	02	00 comes	0D	A0	2B	02	00 comes	
	01	160	43	01	00 goes	0D	A0	2B	01	00 goes	
Drive error	01	160	44	02	00 comes	0D	A0	2C	02	00 comes	
	01	160	44	01	00 goes	0D	A0	2C	01	00 goes	
Potentiometer cable breakdown	01	160	45	02	00 comes	0D	A0	2D	02	00 comes	
	01	160	45	01	00 goes	0D	A0	2D	01	00 goes	
Running time supervision	01	160	48	02	00 comes	0D	A0	30	02	00 comes	
	01	160	48	01	00 goes	0D	A0	30	01	00 goes	
Free message 01 (Pass-through function)	01	160	60	02	00 comes	0D	A0	3C	02	00 comes	
	01	160	60	01	00 goes	0D	A0	3C	01	00 goes	
Free message 02 (Pass-through function)	01	160	61	02	00 comes	0D	A0	3D	02	00 comes	
	01	160	61	01	00 goes	0D	A0	3D	01	00 goes	
Free message 03 (Pass-through function)	01	160	62	02	00 comes	0D	A0	3E	02	00 comes	
	01	160	62	01	00 goes	0D	A0	3E	01	00 goes	
Free message 04 (Pass-through function)	01	160	63	02	00 comes	0D	A0	3F	02	00 comes	
	01	160	63	01	00 goes	0D	A0	3F	01	00 goes	
Free message 05 (Pass-through function)	01	160	64	02	00 comes	0D	A0	40	02	00 comes	
	01	160	64	01	00 goes	0D	A0	40	01	00 goes	
Free message 06 (Pass-through function)	01	160	65	02	00 comes	0D	A0	41	02	00 comes	
	01	160	65	01	00 goes	0D	A0	41	01	00 goes	
Free message 07 (Pass-through function)	01	160	66	02	00 comes	0D	A0	42	02	00 comes	
	01	160	66	01	00 goes	0D	A0	42	01	00 goes	
Free message 08 (Pass-through function)	01	160	67	02	00 comes	0D	A0	43	02	00 comes	
	01	160	67	01	00 goes	0D	A0	43	01	00 goes	
Free message 09 (Pass-through function)	01	160	68	02	00 comes	0D	A0	44	02	00 comes	
	01	160	68	01	00 goes	0D	A0	44	01	00 goes	
Free message 10 (Pass-through function)	01	160	69	02	00 comes	0D	A0	45	02	00 comes	
	01	160	69	01	00 goes	0D	A0	45	01	00 goes	
Free message 11 (Pass-through function)	01	160	70	02	00 comes	0D	A0	46	02	00 comes	
	01	160	70	01	00 goes	0D	A0	46	01	00 goes	



Description	IEC-Telegramme (values in DEZ) DATA Fkt-Typ Inf-Nr DB1 DB2 -UNIT	ILS-Telegramme (values in hex) DT DN2 DN3 DB1 DB2	Scaling (values dezimal) value = carried-over value
Free message 12 (Pass-through function)	01 160 71 02 00 comes	0D A0 47 02 00 comes	
	01 160 71 01 00 goes	0D A0 47 01 00 goes	
Warning coll.message	01 160 46 02 00 comes	0D A0 2E 02 00 comes	
	01 160 46 01 00 goes	0D A0 2E 01 00 goes	
Interferences coll..message	01 160 47 02 00 comes	0D A0 2F 02 00 comes	
	01 160 47 01 00 goes	0D A0 2F 01 00 goes	



14 Definition of the abbreviations and icons

Abbreviation	Definition
OFF	OFF
AUTO	Automation
HAND	HAND, resp. Manual
EndsH	Final switch "Higher"
EndsT	Final switch "Lower"
Ends H/T	Final switches "Higher" or "Lower"
Higher	Changing command to the E-coil in the direction of "Higher" (Imax)
Lower	Changing command to the E-coil in the direction of "Lower" (Imin)
PROG	Function is triggered off by background programme
Uen	Offset voltage
Uerd	Earth fault - Voltage
Umax	Maximum offset voltage up to which is regulated
Umin	Minimum offset voltage. Values below are regarded as interferences
Uo_akt	present offset voltage
Ufmax	upper limit of the tolerance band determined by "F"
Ufmin	lower limit of the tolerance band determined by "F"
Ires	current in the point of resonance. Corresponds to the complete capacitive current of the system
Ifix	neutralization current of a parallel Fixcoil
Isoll	setting the E-Coil in the tuned status
Ipos	present coil position (setting of the E-Coil)
Ip	real measured current through the E-Coil
k	Unsymmetry of the system
v	Detuning (see chapter "4.3 Principle of the regulation")
d	operating loss (see chapter "4.3 Principle of the regulation")
E1 ... E16	Binary inputs (48V ... 320 V)
kni	Transmission ratio of the primary current transformer
knu	Transmission ratio of the primary voltage transformer
R1 ... R11	Relay outputs
Uh	Auxiliary voltage (supply voltage)of the regulator



15 Index

A

active component..... 13
arc 15
automation island 11, 12

C

control and instrumentation technology..... 12

D

Delivery contents 10

E

earth fault
 dead 15
 high-ohmic 15
E-Coil 13

N

Neutral point..... 13

P

Petersen Coil..... 13

R

REGSys 11

U

Unbalance impedance..... 14

V

VDE 228..... 17

W

Warnings 9

Z

Zero phase-sequence system 14

(7)

(8)

(9)

(10)