



## Preliminary remarks:

The documentation for the Protronic 100 / 500 / 550 includes the following parts:

<b>Installation Manual Protronic 100 / 500 / 550</b> .....	<b>42/62-50011</b>
Commissioning Manual: Configuration and parameter setting Protronic 100 / 500 / 550 / Digilric 500 .....	42/62-50012
Operating Manual Protronic 100 / 500 .....	42/62-50013
respective	
Operating Manual Protronic 550 .....	42/62-55013

Also available on request:

Description of interfaces (MODBUS) .....	42/62-50040
--	-------------